



SCT RCU2E-C50 Multi Camera User Guide

[Home](#) » [SCT](#) » SCT RCU2E-C50 Multi Camera User Guide 

Contents

1

SCT RCU2E-C50 Multi Camera

2

CONNECTIONS

3

DIMENSION

4

Models

5

Documents / Resources

6

Related Posts



SCT RCU2E-C50 Multi Camera



CONNECTIONS



Panasonic AW-UE40

RCC-M005-0.3M
USB-A (RCU2E-CE™) to USB-C


RCC-C002-0.3M
RJ45 (RCU2E-CE™) to RJ45

PPC-005-0.3M
DC Power Plug (RCU2E-CE™)
To DC Power Plug



RCU2E-CE™

SCTLink™ Cable Specs
Integrator-Supplied CAT5e/CAT6 STP/UTP Cable
T568A or T568B (100m Max Length)



RCU2E-HE™ Front Panel
Field-Upgradeable microSD Slot



RCU2E-HE™

SCTLink™ Cable
Power, Control & Video

The SCTLink™ cable must always be a single, point-to-point CAT cable with no couplers or interconnections.

WPS-12 30VDC
100-240V 47-63Hz
Power Supply



Laptop

RCC-H016-1.0M
RJ45 (RCU2E-CE™) to RJ45

RCC-M004-1.0M
USB-B (RCU2E-HE™) to USB-A

RCC-M014-1.0M
USB-B (RCU2E-HE™) to USB-C

DIMENSION

Module Dimensions

• RCUZE-CE™:

- **H:** 0.789" (20mm)
- **W:** 2.264" (57mm)
- **D:** 3.725" (94mm)

• RCU2E-HE™:


- **H:** 1.448" (36mm)
- **W:** 3.814" (96mm)
- **D:** 3.578" (90mm)

Models

The RCU2E-C50™™ supports multiple Panasonic camera models:

- Panasonic AW-HE20
- Panasonic AW-UE20
- Panasonic AW-UE40
- Panasonic AW-UE50

Documents / Resources

	SCT RCU2E-C50 Multi Camera [pdf] User Guide RCU2E-C50, RCU2E-C50 Multi Camera, Multi Camera, Camera
---	--