



SCT RCU2E-E70 Poly Studio User Guide

[Home](#) » [SCT](#) » SCT RCU2E-E70 Poly Studio User Guide 

SCT RCU2#E-E70 Poly Studio User Guide



Contents

- [1 Sound Control Technologies](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

Sound Control Technologies

Poly Studio EFO



RCC-MQ05-0.3M

USB-A (RCUZ5-CE™) to USB-C

RCC-CO02-0.3M

RJ45 (RCUZS-CE™) to RJ45

RCUZE-CE™



SCTLink Cable Specs

Integrator Supplied CATS/CAT6 STP/UTP Cable
T568A or T568B (300m Max Length)



RCUZE-HE™ Front Panel

Field-Upgradeable microSD Slot



RCUZE-HE™

WP5-12 30VDC 100-240V 47-63Hz Power Supply



SCTLink™ Cable

Power, Control & Video

The **SCTLink™** cable must always be a single, point-to-point CAT cable with no couplers or interconnections

CC-MO04-1.0M

USB-B8 (RCU25-HE™) to USB-A
Poly G7500




Module Dimensions RCU2S-CE:

- H:** 0.789" (20mm) x
- W:** 2264" (57mm) x
- D:** 3725 (94mm) CU25-
- HET:**
- H:** 1.448" (36mm) x
- W:** 3814" (96mm) x
- D:** 3.578" (90mm)



Documents / Resources

	SCT RCU2E-E70 Poly Studio [pdf] User Guide RCU2E-E70, RCU2E-E70 Poly Studio, Poly Studio, Studio
---	---