



SCT RM-C200 Audio DSP-Control System User Guide

[Home](#) » [SCT](#) » SCT RM-C200 Audio DSP-Control System User Guide 

SCT RM-C200 Audio DSP-Control System



Contents


1 Connectivity And Description

2 Documents / Resources

3 Related Posts


Connectivity And Description

- Audio
- Control
- Power
- SCTLink™
- Control/Power



SCTLink™ Cable Specs


Integrator-Supplied CAT6 STP/UTP Cable
T568A or T568B (10m-100m min/max)



The **SCTLink™** cable must always be a single, point-to-point CAT cable with no couplers or interconnections.



Sound Control
Technologies



[SCT RM-C200 Audio DSP-Control System](#) [pdf] User Guide
RM-C200 Audio DSP-Control System, RM-C200, Audio DSP-Control System, DSP-Control System, Control System