

SCT RTK-X57 Transmitter Module User Guide


SCT RTK-X57 Transmitter Module User Guide



Contents


- 1 [Connections](#)
- 2 [Module Dimensions](#)
- 3 [Documents / Resources](#)

Connections



***SCTLink™ Cable Specs**

Integrator-Supplied CAT5e/CAT6 STP/UTP Cable
EIA568A or EIA568B (10m-100m min/max Length)



Module Dimensions

- **RTK-X57-TX™:** H: 1.39" (35mm) x W: 10.22" (259mm) x D: 4.51" (114mm)
- **RTK-X57RX™:** H: 1.39" (35mm) x W: 10.22" (259mm) x D: 4.51" (114mm)



Documents / Resources

	SCT RTK-X57 Transmitter Module [pdf] User Guide RTK-X57-TX, RTK-X57-RX, RTK-X57, RTK-X57 Transmitter Module, Transmitter Module, Modu le
--	---