



SCT TC8 USB-PDI Plus Remote Table Transmitter Module User Guide

[Home](#) » [SCT](#) » SCT TC8 USB-PDI Plus Remote Table Transmitter Module User Guide 




Sound Control Technologies

Contents

- 1 TC8 USB-PDI Plus Remote Table Transmitter Module
- 2 Documents / Resources
 - 2.1 References


TC8 USB-PDI Plus Remote Table Transmitter Module

USB-PDI™ + RemoteTableKit™ RTK-X57-PSU™ Design Guide
Last Update: 3/8/2024



*SCTLink™ Cable Specs

Integrator-Supplied CAT5e/CAT6 STP/UTP Cable EIA568A or EIA568B (10m-100m min/max Length)



Documents / Resources

	SCT TC8 USB-PDI Plus Remote Table Transmitter Module [pdf] User Guide TC8, TC8 USB-PDI Plus Remote Table Transmitter Module, USB-PDI Plus Remote Table Transmitter Module, Remote Table Transmitter Module, Table Transmitter Module, Transmitter Module, Module
--	--

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.