



SDC 512 Monitoring Switch Kit Instruction Manual

[Home](#) » [SDC](#) » SDC 512 Monitoring Switch Kit Instruction Manual 




512 Monitoring Switch Kit Instruction Manual

Contents

- [1 512 Monitoring Switch Kit](#)
- [2 WIRING SPECIFICATION](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

512 Monitoring Switch Kit



WIRING SPECIFICATION

COM	– WHT
N\O	– YEL
N\C	– ORG

5AMP MAX RESISTIVE

1. Connect Wires.
2. Remove Bracket (A) to remove spring assembly.
3. Mount switch bracket (B), using screw and nut.
4. Place spring assembly back into housing.
5. Position switch assembly (C) as shown and secure to door.

P:\INST INSTRUCTIONS\EGRESS CONTROLS\INST-512 REV C 07-21

Any suggestions or comments to this instruction or product are welcome. Please contact us through our website or email engineer@sdsecurity.com

SECURITY DOOR CONTROLS

WWW.SDCSECURITY.COM

[t] 800.413.8783


805.494.0622

E-mail: service@sdsecurity.com

801 Avenida Acaso, Camarillo, CA 93012

PO Box 3670, Camarillo, CA 93011

Documents / Resources



[SDC 512 Monitoring Switch Kit](#) [pdf] Instruction Manual
512 Monitoring Switch Kit, 512, Monitoring Switch Kit, Switch Kit, Kit