



SDC Intergrated Pneumatic Timer Switch Installation Guide

[Home](#) » [SDC](#) » SDC Intergrated Pneumatic Timer Switch Installation Guide 



SECURITY DOOR CONTROLS

WWW.SDCSECURITY.COM

[t] 800.413.8783 ■ 805.494.0622 ■ E-mail: service@sdsecurity.com ■ 801 Avenida Acaso, Camarillo, CA 93012 ■ PO Box 3670, Camarillo, CA 93011

Contents

[1 INSTALLATION INSTRUCTIONS](#)

[2 Specification:](#)

[3 Documents / Resources](#)


[4 Related Posts](#)

INSTALLATION INSTRUCTIONS

413PN / 423P

INTEGRATED PNEUMATIC TIMER SWITCH

1-45 SECOND ADJUSTMENT




Specification:

Contact:	Form Z 5A @ 125VAC 3A @ 30VDC
Timer:	1 ~ 45 seconds

P:\INST INSTRUCTION\EGRESS CONTROLS\INST-413PN_423P REV C 03-21
 Any suggestions or comments to this instruction or product are welcome. Please contact us through our website or email engineer@sdsecurity.com

Documents / Resources

	SDC Intergrated Pneumatic Timer Switch [pdf] Installation Guide SDC, 413PN, 423P, 1-45 SECOND, ADJUSTMENT, Intergrated, Pneumatic, Timer, Switch
---	--