



SDC LRP2L Phi Latch Monitoring Switch Kit Instruction Manual

[Home](#) » [SDC](#) » SDC LRP2L Phi Latch Monitoring Switch Kit Instruction Manual 



INSTALLATION INSTRUCTIONS LRP2L PHI LATCH MONITORING SWITCH KIT MODELS: 2200 & 2800 VERTICAL ROD DEVICES


Contents

- [1 LRP2L Phi Latch Monitoring Switch Kit](#)
- [2 SWITCH SPECIFICATION](#)
- [3 Documents / Resources](#)
 - [3.1 References](#)

LRP2L Phi Latch Monitoring Switch Kit

Remove head cover. Install Switch Bracket using supplied screws, inserting the longer screw through supplied cable tie. Route wires through tie. Re-attach head cover.

NOTE: Regardless of handing, the Switch Bracket is always attached to the top side of the device head. The Switch Lever may require adjustment after installation of vertical rods.



SWITCH SPECIFICATION

WHT – COM
YEL – N/O
ORG – N/C 5
AMP @ 125 VAC
RESISTIVE

Any suggestions or comments to this instruction or product are welcome. Please contact us through our website or email engineer@sdsecurity.com

SECURITY DOOR CONTROLS

WWW.SDCSECURITY.COM


[t] 800.413.8783 805.494.0622

E-mail: service@sdsecurity.com

801 Avenida Acaso, Camarillo, CA 93012 PO Box 3670, Camarillo, CA 93011

P:\INST INSTRUCTIONS\ELR KITS\INST-LRP2L
REV D 08-22

Documents / Resources



[SDC LRP2L Phi Latch Monitoring Switch Kit](#) [pdf] Instruction Manual
LRP2L Phi Latch Monitoring Switch Kit, LRP2L, Phi Latch Monitoring Switch Kit, Latch Monitoring Switch Kit, Monitoring Switch Kit, Switch Kit

References

- [SDC Electric Strikes, Magnetic Locks, Electric Door Locksets](#)

[Manuals+](#)