Manuals+ — User Manuals Simplified.

Seagate STJL2000400 Basic External Portable Hard Drive Specifications And Datasheet

Contents

Seagate STJL2000400 Basic External Portable Hard Drive

Introduction

The Easy Way to Store and Go
Take on your day with a simple, reliable backup. Simple, compact, and PC compatible, Seagate® Basic portable drive gives you additional on-the-go storage and lets you take along large files when you travel.

- Leverage simple drag-and-drop usability
- Expand your computer's capacity with a lightweight, compact solution
- Take advantage of instant plug-and-play PC compatibility
- Transfer files fast with USB 3.0, backward-compatible with USB 2.0

Set-up for PCs is simple and straightforward: simply connect a single USB cable and you are ready to go. The drive is powered by a USB cable, so there is no need for an external power supply. And, it is automatically recognized by the Windows®1,2 operating system, so there is no software to install and nothing to configure. Just connect and take advantage of the fast data transfer speeds with the USB 3.0 interface by connecting to a SuperSpeed USB 3.0 port.

1. Reformatting for use with Mac is required.
2. Compatibility may vary depending on the user's hardware configuration and operating system.

Specifications

Specifications				
Capacity 2 TB and below	**Product Dimensions**	**Box Dimensions**	**Master Carton Dimensions**	**Pallet Dimensions**
Length (in/mm)	4.606 in/117 mm	5.512 in/140 mm	7.008 in/178 mm	40 in/1016 mm
Width (in/mm)	3.15 in/80 mm	4.055 in/103 mm	5.433 in/138 mm	47.992 in/1219 mm
Depth (in/mm)	0.583 in/14.8 mm	1.22 in/31 mm	4.567 in/116 mm	43.268 in/1099 mm
Weight (lb/kg),	0.375 lb/0.17 kg	0.573 lb/0.26 kg	2.535 lb/1.15 kg	860.707 lb/390.41 kg
Capacity 4 TB and above	**Product Dimensions**	**Box Dimensions**	**Master Carton Dimensions**	**Pallet Dimensions**
Length (in/mm)	4.606 in/117 mm	5.591 in/142 mm	7.008 in/178 mm	40 in/1016 mm
Width (in/mm)	3.15 in/80 mm	4.055 in/103 mm	6.772 in/172 mm	47.992 in/1219 mm
Depth (in/mm)	0.787 in/20 mm	1.555 in/39.5 mm	4.567 in/116 mm	43.268 in/1099 mm
Weight (lb/kg)	0.595 lb/0.27 kg	0.728 lb/0.33 kg	3.263 lb/1.48 kg	837.227 lb/379.76 kg
Quantities				
Boxes per Master Carton	4			
Master Cartons per Pallet	320 (1 TB, 2 TB), 240 (4 TB, 5 TB)			
Pallet Layers	8			

What's Included

- Seagate® Basic external portable drive USB cable
- Quick start guide

System Requirements

- Windows®10, Windows 8, and Windows 7 operating system1,2
- SuperSpeed USB 3.0 port (required for USB 3.0 transfer speeds, or backward compatible with USB 2.0 ports at USB 2.0 transfer speeds)2

Region	Model Number	Capacity	Limited Warranty (years)	UPC Code	EAN Code	Multi-Pack UPC
AMER	STJL1000400	1TB	1	763649140741	3660619408245	10763649140748
AMER	STJL2000400	2TB	1	763649140680	3660619408184	10763649140687
AMER	STJL4000400	4TB	1	763649140697	3660619408191	10763649140694
AMER	STJL5000400	5TB	1	763649140703	3660619408207	10763649140700
EMEA	STJL1000400	1TB	2	763649140741	3660619408245	10763649140748
EMEA	STJL2000400	2TB	2	763649140680	3660619408184	10763649140687
EMEA	STJL4000400	4TB	2	763649140697	3660619408191	10763649140694
EMEA	STJL5000400	5TB	2	763649140703	3660619408207	10763649140700
APAC	STJL1000400	1TB	3	763649140741	3660619408245	10763649140748
APAC	STJL2000400	2TB	3	763649140680	3660619408184	10763649140687
APAC	STJL4000400	4TB	3	763649140697	3660619408191	10763649140694
APAC	STJL5000400	5TB	3	763649140703	3660619408207	10763649140700

1. Reformatting may be required for Mac.
2. Compatibility may vary depending on the user's hardware configuration and operating system.

Trademarks

FAQ's

What is the storage capacity of the Seagate STJL2000400 Basic External Portable Hard Drive?

The Seagate STJL2000400 has a storage capacity of 2 terabytes (TB).

Is the Seagate STJL2000400 compatible with both Mac and Windows operating systems?

Yes, the Seagate STJL2000400 is compatible with both Mac and Windows operating systems.

Does the Seagate STJL2000400 require an external power source?

No, the Seagate STJL2000400 is powered through the USB connection and does not require an external power source.

What is the data transfer interface used by the Seagate STJL2000400?

The Seagate STJL2000400 uses a USB 3.0 interface for data transfer, which is backward compatible with USB 2.0 ports.

Is the Seagate STJL2000400 compatible with USB-C ports?

Yes, the Seagate STJL2000400 is compatible with USB-C ports. You may need a USB-C to USB-A adapter or cable to connect it to devices with USB-C ports.

Does the Seagate STJL2000400 support automatic backup or scheduled backups?

The Seagate STJL2000400 does not have built-in backup software. However, you can use third-party backup software or manually copy and paste your files to the drive.

Can the Seagate STJL2000400 be used to expand the storage capacity of a gaming console like PlayStation or Xbox?

Yes, the Seagate STJL2000400 can be used as an external storage device for gaming consoles that support external hard drives.

Is the Seagate STJL2000400 shock-resistant or ruggedized?

The Seagate STJL2000400 is not specifically designed to be shock-resistant or ruggedized. However, it has a durable build and provides reasonable protection for normal handling and transport.

What is the warranty period for the Seagate STJL2000400?

The warranty period for the Seagate STJL2000400 is typically 2 years, but it's always recommended to check the specific warranty terms provided by Seagate.

Can I password-protect or encrypt my data on the Seagate STJL2000400?

The Seagate STJL2000400 does not have built-in hardware encryption or password protection features. You can use third-party software or operating system tools to encrypt your data if desired.

Can the Seagate STJL2000400 be used as a bootable drive for operating systems?

Yes, the Seagate STJL2000400 can be used as a bootable drive for compatible operating systems. However, the specific steps to set it up as a bootable drive may vary depending on your system configuration.

How can I safely disconnect the Seagate STJL2000400 from my computer?

On Windows, you can safely disconnect the Seagate STJL2000400 by right-clicking on the drive icon in the system tray and selecting "Eject." On Mac, you can drag the drive icon to the trash bin and wait for it to disappear before disconnecting the drive physically.

Download This PDF Link: [Seagate STJL2000400 Hard Drive – Device.report](#)