

SEAGATE ST7S1031 Firmware Update Tool for Windows User Guide

[Home](#) » [Seagate](#) » SEAGATE ST7S1031 Firmware Update Tool for Windows User Guide 




Contents


- 1 ST7S1031 Firmware Update Tool for Windows
- 2 Documents / Resources
 - 2.1 References

ST7S1031 Firmware Update Tool for Windows


1. Open UpgradeFW_ST7S1031_v2.00_20180118.exe with administrator privilege and click “Yes” if asked to allow program from unknown publisher make changes to this computer.




2. Check the box of all drives that you want to upgrade, click “rescan” icon if you don’t see target drive shown up. This program only upgrades from drives with ST7S1030 firmware.



3. Click "Upgrade Firmware" icon and wait for few seconds until "Pass" popped up at upper right corner.



4. Click "rescan" icon again to confirm if firmware version changed to "ST7S1031",



5. Firmware Upgrade is completed successfully.



Documents / Resources

	SEAGATE ST7S1031 Firmware Update Tool for Windows [pdf] User Guide ST7S1031 Firmware Update Tool for Windows, ST7S1031, Firmware Update Tool for Windows, Update Tool for Windows, Tool for Windows
--	--

References

- [User Manual](#)