

SEALEY AP12160 1.2M Work Bench with Drawer Instruction Manual

Home » SEALEY » SEALEY AP12160 1.2M Work Bench with Drawer Instruction Manual



Contents

- 1 SEALEY AP12160 1.2M Work Bench with
- **Drawer**
- 2 SAFETY
- **3 INTRODUCTION**
- **4 SPECIFICATION**
- **5 CONTENTS**
- 6 ASSEMBLY
- 7 Specifications
- 8 FAQ
- 9 Documents / Resources
 - 9.1 References
- **10 Related Posts**



SEALEY AP12160 1.2M Work Bench with Drawer



MODEL NO: AP12160

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to instructions



Wear protective gloves



Wear safety footwear



Wear protective clothing

SAFETY

GENERAL SAFETY

WARNING! Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using this bench.

- · Locate a bench in a suitable work area.
- Keep the work area clean, and uncluttered, and ensure there is adequate lighting.

WARNING! Use a bench on level and solid ground, preferably concrete.

- Keep the bench clean and tidy in accordance with good workshop practice.
- Keep children and unauthorized persons away from the work area.

- DO NOT use the bench for any purpose other than that for which it is designed.
- DO NOT undertake work on the bench without the workpiece being adequately secured. Use clamps or a vice (not included) to secure the workpiece – available from your Sealey stockist.
- DO NOT use the bench outdoors.
- DO NOT get the bench wet or use in damp or wet locations or areas where there is condensation.
- DO NOT exceed the maximum load for the work surfaces, worktop 100kg, bottom shelf and drawer 20kg.
 Avoid heavy impacts when placing objects onto the surfaces.
- DO NOT clean the bench with any solvents which may damage the surface or the protective coating on the worktop.

INTRODUCTION


Boltless design makes the unit easy to assemble, with minimal tools being required. One large drawer with ball bearing slides, fitted with two handles. MDF Worktop measures 1210 x 605mm (W x D), and has a comfortable work height of 900mm. Fitted with anti-slip foot protectors.

SPECIFICATION


- Size (W x D x H):1210 x 605 x 900mm
- Worktop:1210 x 605mm.
- Max Worktop Capacity:100kg evenly distributed.
- Max Capacity of drawer:20kg evenly distributed.
- Max Capacity of lower shelf: 50kg evenly distributed.


CONTENTS


METHOD OF CONSTRUCTION





ASSEMBLY












- 1. Study each diagram and identify the components required with reference to the parts list/drawing on page 1.
- 2. Build up the basic frame as shown in diagrams 1,2,3 & 4.
- 3. Attach the drawer supports to the basic frame as shown in diagram 5.
- 4. Assemble the drawer with reference to diagram 6. Place the 6mm MDF drawer base into the bottom of the drawer frame. Insert the drawer into the drawer runners as shown in diagrams 7 and 8.
- 5. Place the 15mm MDF board onto the top of the frame as shown in diagram 9 to form the worktop. Insert the other 6mm MDF board into the lower part of the frame and move it into position on the lower support beams to form the lower shelf. See diagrams 9 & 10.



Parts support is available for this product. Please email sales@sealey.co.uk or telephone 01284 757500

ENVIRONMENT PROTECTION

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories, and packaging should be sorted, taken to a recycling center, and disposed of in a manner that is compatible with the environment. When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

- **Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specifications, and component parts without prior notice.
- Important: No Liability is accepted for incorrect use of this product.
- Warranty: The guarantee is 12 months from the purchase date, proof of which is required for any claim.

Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR 01284 757500 01284 703534 sales@sealey.co.uk www.sealey.co.uk www.sealey.co.uk

Specifications

• Model No.: AP12160

• Size (W x D x H): 1210 x 605 x 900mm

• Worktop: 1210 x 605mm

Max Worktop Capacity: 100kg evenly distributed
 Max Capacity of drawer: 20kg evenly distributed
 Max Capacity of lower shelf: 50kg evenly distributed

FAQ

Q: What is the maximum load capacity for the worktop?

A: The maximum load capacity for the worktop is 100kg evenly distributed.

Q: Can the bench be used outdoors?

A: No, the bench should not be used outdoors or in wet locations.

Q: How should I clean the bench?

A: Do not clean the bench with solvents that may damage the surface. Use a mild cleaning solution and a soft cloth to clean the bench.

Documents / Resources



<u>SEALEY AP12160 1.2M Work Bench with Drawer</u> [pdf] Instruction Manual AP12160, AP12160 1.2M Work Bench with Drawer, AP12160, 1.2M Work Bench with Drawer, Bench with Drawer, Drawer

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.