**Manuals+** — User Manuals Simplified.



### SEALEY AP7200.V2 5 Level Racking Unit 200kg Capacity Per **Level Instructions**

Home » SEALEY » SEALEY AP7200.V2 5 Level Racking Unit 200kg Capacity Per Level Instructions

SEALEY AP7200.V2 5 Level Racking Unit 200kg Capacity Per Level



Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL RE QUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONA L INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE U SE.

#### Refer to instructions



### **Contents**

- 1 SAFETY
- **2 INTRODUCTION**
- **3 CONTENTS**
- **4 ASSEMBLY**
- **5 Parts List:**
- 6 Documents /

Resources

- **6.1 References**
- **7 Related Posts**

### **SAFETY**

- % WARNING! Ensure Health & Safety, local authority, and general workshop practice regulations are adhered to when using this racking unit.
- ✓ Locate racking unit in a suitable work area.
- ✓ Keep the work area clean, uncluttered and ensure there is adequate lighting.
- % WARNING! Use racking unit on level and solid ground, preferably concrete. For added safety fix unit to a wall.
- ✓ Keep the racking unit clean and tidy in accordance with good workshop practice.
- ✓ Keep children and unauthorized persons away from the work area.
- **X** DO NOT use the racking unit for any purpose other than that for which it is designed.
- **X** DO NOT use the racking unit outdoors.
- **X** DO NOT place the racking unit in a damp or wet location or an area where there is condensation.
- **X** DO NOT clean the racking unit with any solvents which may damage the surfaces or the protective coating.
- **X** DO NOT move the racking unit when there are items placed on it.
- **X** DO NOT overload the racking unit.

### INTRODUCTION

Fully painted steel frame with five MDF shelves. 200kg capacity per level giving a maximum capacity of 1000kg per rack. Bolt-less design means no tools required to assemble. Two piece uprights allow use as a single bay rack or split into two separate shelf systems or workstations. Ideal for use in conjunction with Model No. AP7150C corner racking unit.

**Dimensions** W x D x H: 900 x 400 x 1830mm

### **CONTENTS**

- 3.1. Unpack the unit and confirm that all the parts listed below are present. Refer to Parts List below.
- **3.2.** Assemble the unit on a solid, level surface. Avoid carpet. A second person will be required to help with assembly.


### **ASSEMBLY**

- **4.1.** Assemble the racking unit in the sequence below, referencing the parts list overleaf.
- **4.2.** Use a rubber mallet to tap the brackets together.

### Step 1

Place foot end caps onto the bottom of the 4 legs 'D'. Note upright position.


Place shelving bracket 'A' onto the legs 'D'. A rubber mallet can be used to lightly tap all brackets into the keyholes of the legs into place. Allow one keyhole free between the foot end cap and the shelving bracket




# Allow one keyhole free between the foot cap and the shelving bracket.

### Step 2

Use shelf bracket 'B' for the side brackets using the shelf bracelet from Step 1 as a guide for height. Allow 1 keyhole free from the ground as shown in the diagram. Use same shelving bracelets for opposing sides as shown in the diagram. Place brace 'C' as shown.



Parts List:




## NOT TO SCALE


### Step 3

Place MDF board on bottom shelf to minimize buckling. Join the upper legs to the lower legs with the connector pins. Note upright position. Note: The legs are designed to sit directly on top of each other – don't overlap them. Handy Hint:


Flathead screwdriver rimy be used to tap in connector pins.




**Step 4**Fix brackets 'B' so that the top rivets sit on the upper legs and the bottom rivets sit on the lower legs. Repeat with brackets 'A'-, followed by brace 'E' as shown.




**Step 5**Fix brackets 'B' at the very top allowing room for the MDF board to sit flush against the legs. Repeat with brackets 'A'.



Step 6
Apply remaining brad as above to desired height. Ensure that braces 'C' are fixed to all shelves



**Step 7**Place the MDF boards on shelves, ensure they are sitting flush against the edge of the shelf brackets



Parts support is available for this product. Please email <a href="mailto:sales@sealey.co.uk">sales@sealey.co.uk</a> or telephone 01284 757500



### **ENVIRONMENT PROTECTION**

Recycle unwanted materials instead of disposing of them as waste. All tools, accessories and packaging should be sorted, taken to a recycling centre and disposed of in a manner which is compatible with the environment. W hen the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.

**Note:** It is our policy to continually improve products and as such we reserve the right to alter data, specification s and component parts without prior notice. Please note that other versions of this product are available. If you r equire documentation for alternative versions, please email or call our technical team on **technical@sealey.co. uk** or 01284 757505. **Important:** No Liability is accepted for incorrect use of this product.

Warranty: Guarantee is 12 months from purchase date, proof of which is required for any claim.

# Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR 01284 757500 01284 703534

sales@sealey.co.uk www.sealey.co.uk



### **Documents / Resources**



SEALEY AP7200.V2 5 Level Racking Unit 200kg Capacity Per Level [pdf] Instructions AP7200.V2, 5 Level Racking Unit 200kg Capacity Per Level, Unit 200kg Capacity Per Level, C apacity Per Level, 5 Level Racking Unit, Racking Unit



SEALEY AP7200.V2 5 Level Racking Unit 200kg Capacity Per Level [pdf] Instruction Manua

AP7200.V2 5 Level Racking Unit 200kg Capacity Per Level, AP7200.V2, 5 Level Racking Unit 200kg Capacity Per Level, Racking Unit 200kg Capacity Per Level, 200kg Capacity Per Level, Capacity Per Level, Level

### References

• Sealey - Leading Professional Tool & Workshop Equipment Supplier

Manuals+,