

SEALEY
HT300R
Rechargeable
Head Torch



SEALEY HT300R Rechargeable Head Torch Owner's Manual

[Home](#) » [SEALEY](#) » SEALEY HT300R Rechargeable Head Torch Owner's Manual 

Contents

- 1 SEALEY HT300R Rechargeable Head Torch
- 2 Product Usage Instructions
- 3 FAQ
- 4 SAFETY
- 5 INTRODUCTION
- 6 SPECIFICATION
- 7 OPERATION
- 8 MAINTENANCE
- 9 Warranty
- 10 CONTACT
- 11 Documents / Resources
 - 11.1 References



SEALEY HT300R Rechargeable Head Torch



Product Usage Instructions

- DO NOT shine directly into your, another person's, or an animal's eyes.
- DO NOT allow children to use the torch.
- DO NOT use the torch if you suspect that the battery or the torch casing is damaged.
- DO NOT leave batteries in a discharged state. Before storage, remove batteries and dispose of them correctly.
- Press the power button once to turn the unit on.
- The battery charge state is indicated by the 4 blue LEDs.
- Press the power button again to light the primary light.
- Press the power button again to also light the secondary light.
- Press the power button again to turn the unit off.
- The headtorch has 4 possible lockable positions: 0°, 20°, 40°, and 60°.
- Twist the light unit through 45° to remove it from the headband mounting.
- Connect the USB lead to the port on the side of the unit and to a USB power supply socket at the other end.

FAQ

- **Q: How do I know when the battery is fully charged?**
 - **A:** The battery charge state is indicated by the 4 blue LEDs on the torch.
- **Q: Can I leave the torch on while charging?**
 - **A:** It is recommended not to leave the torch on while charging to prevent any potential hazards.
- **Q: What should I do if the torch gets wet?**
 - **A:** If the torch gets wet, dry it thoroughly before use to prevent any damage to the internal components.

Thank you for purchasing a Sealey product. Manufactured to a high standard, this product will, if used according to these instructions, and properly maintained, give you years of trouble-free performance.

IMPORTANT: PLEASE READ THESE INSTRUCTIONS CAREFULLY. NOTE THE SAFE OPERATIONAL REQUIREMENTS, WARNINGS & CAUTIONS. USE THE PRODUCT CORRECTLY AND WITH CARE FOR THE PURPOSE FOR WHICH IT IS INTENDED. FAILURE TO DO SO MAY CAUSE DAMAGE AND/OR PERSONAL INJURY AND WILL INVALIDATE THE WARRANTY. KEEP THESE INSTRUCTIONS SAFE FOR FUTURE USE.



Refer to
instructions

SAFETY

GENERAL SAFETY

- DO NOT shine directly into your, another person's, or an animal's eyes.
- DO NOT allow children to use the torch.
- DO NOT use the torch if you suspect that the battery or the torch casing is damaged.
- DO NOT leave batteries in a discharged state. Before storage remove batteries and dispose of them correctly.

BATTERY SAFETY

- **WARNING!** To reduce the risk of burns or fire:
- DO NOT attempt to open the battery.
- DO NOT crush, puncture, short contacts or dispose of in fire or water.
- DO NOT expose to temperatures above 60°C (140°F).
- If the electrolyte in the batteries gets on your skin, thoroughly rinse with water. If it gets in your eyes, rinse thoroughly with cool water and seek immediate medical attention.

INTRODUCTION

- 3W COB + 1W SMD Rechargeable headlight with sensor function.
- Also includes 3 SMD LEDs producing 300 Lumens.
- Can also act as a separate mini worklight with a magnet. 3.7V 1000mAh Li-Poly battery with 0.5m USB cable included.
- Charging and battery indicator capabilities. Maximum 4hr runtime using COB LED.


SPECIFICATION

MODEL NO:	HT300R
Battery:	3.7V 1000mAh Li-Poly battery
Charging Time:	3-4hr
LED Type:	COB + SMD
Lumen Output:	COB – 150lm SMD – 300lm
Nett Weight:	0.095
Operating Time:	COB/SMD 4hr/2hr

OPERATION

TORCH OPERATION

1. Press the power button (fig.1) once to turn the unit on.
2. The battery charge state is indicated by the 4 blue LEDs.
3. Press the power button again to light the primary light.
4. Press the power button again to also light the secondary light.
5. Press the power button again to turn the unit off.



LIGHT SENSOR

1. Press the sensor button to enable sensing.
2. Pass hand in front of the light until the light comes on.
3. Pass the hand in front of the light again and the light goes off.
4. Press the sensor button to disable sensing.

TILTING HEAD

1. The headtorch has 4 possible lockable positions, 00, 200, 400, and 600.

DISMOUNT TORCH

1. Twist the light unit through 450 to remove it from the headband mounting.

CHARGING

1. Connect the USB lead to the port on the side of the unit and a USB power supply socket on the other.

MAINTENANCE

- Keep the torch clean by wiping it with a damp cloth.

ENVIRONMENT PROTECTION



- Recycle unwanted materials instead of disposing of them as waste.
- All tools, accessories, and packaging should be sorted, taken to a recycling center, and disposed of in a manner that is compatible with the environment.
- When the product becomes completely unserviceable and requires disposal, drain any fluids (if applicable) into approved containers and dispose of the product and fluids according to local regulations.



WEEE REGULATIONS

- Dispose of this product at the end of its working life in compliance with the EU Directive on Waste Electrical and Electronic Equipment (WEEE).
- When the product is no longer required, it must be disposed of in an environmentally protective way.
- Contact your local solid waste authority for recycling information.



BATTERY REMOVAL

- Under the Waste Batteries and Accumulators Regulations 2009, Jack Sealey Ltd is required to inform potential purchasers of products containing batteries (as defined within these regulations), that they are registered with Valpak's registered compliance scheme.
- Jack Sealey Ltd's Batteries Producer Registration Number (BPRN) is BPRN00705.



Note: It is our policy to continually improve products and as such we reserve the right to alter data, specifications, and parts without prior notice.

Important: No Liability is accepted for incorrect use of this product.

Warranty

- The guarantee is 12 months from the purchase date, proof of which is required for any claim.

CONTACT

- Sealey Group, Kempson Way, Suffolk Business Park, Bury St Edmunds, Suffolk. IP32 7AR
- 01284 757500 sales@sealey.co.uk. www.sealey.co.uk

Documents / Resources

	<p>SEALEY HT300R Rechargeable Head Torch [pdf] Owner's Manual HT300R Rechargeable Head Torch, HT300R, Rechargeable Head Torch, Head Torch, Torch</p>
---	--

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.