



SeaLife Micro 3.0 Camera Firmware Updating Instructions

[Home](#) » [SeaLife](#) » SeaLife Micro 3.0 Camera Firmware Updating Instructions 

SeaLife Micro 3.0 Camera Firmware Updating



Contents

- [1 Firmware Updating Instructions for SeaLife Micro 3.0 Camera](#)
- [2 Firmware Update Procedures](#)
- [3 Documents / Resources](#)
- [4 Related Posts](#)

Firmware Updating Instructions for SeaLife Micro 3.0 Camera

The latest firmware release for the Micro 3.0 camera is version V1.05, which improves the following:

- WiFi connection stability with Android devices
- Compatibility updates for Apple iOS 14
- App user Interface enhancements
- Improved quality of RAW capture image files
- Date/time setting bug fix
- Other minor bug fixes

You may update the firmware using the SeaLife Micro 3+ app or following the below instructions. Updating the firmware using the app is the fastest, easiest way. Please refer to the online troubleshooting instructions if you need help updating the firmware using the SeaLife Micro 3+ app.


Firmware Update Procedures

1. Before starting firmware update, make sure camera's battery has at least 50% charge.
2. Download firmware from the following link and save it to your PC desktop:
<https://www.dropbox.com/sh/jngpzrzcnts2rhe/AABX5RmaQuRFMhzqQdWLCSTIa?dl=0>
3. Connect camera to your PC using the USB cable. For Windows PC, the camera will appear as a drive called "MICRO3.0" located in "My Computer". For Mac, the camera USB drive will appear on your desktop.
4. Copy the "*sealife_fw.bin*" file from your desktop and paste it to the "MICRO3.0" drive. Note: Make sure the "*sealife_fw.bin*" file name has not been altered (must be "*sealife_fw.bin*") and that it's located under the *DCIM* folder, like this:

Name	Date modified	Type	Size
DCIM	9/21/2020 5:21 PM	File folder	
MISC	9/21/2020 5:21 PM	File folder	
sealife_fw.bin	9/2/2020 3:13 AM	BIN File	47,504 KB

5. Disconnect the camera from the computer and Power on camera.
6. "Processing..." appears on the display, indicating FW update is in progress. It takes about 30 seconds to update. The FW file automatically deletes after the update has successfully been installed in the camera.
7. To confirm that the firmware has updated correctly, power on the camera, push the Menu key, select "System Settings" using the up/down keys and push shutter button to confirm. Scroll up one step to "Firmware Version:" which should show V1.05. That's it. Happy Diving!

Documents / Resources

	<p>SeaLife SeaLife Micro 3.0 Camera Firmware Updating [pdf] Instructions SeaLife, Micro 3.0, Camera, Firmware, Updating</p>
---	---