



# SEAWARD PATGuard 3 PAT Testing Software User Guide

[Home](#) » [SEAWARD](#) » SEAWARD PATGuard 3 PAT Testing Software User Guide 

## Contents

- [1 SEAWARD PATGuard 3 PAT Testing Software](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 How To Transfer](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)



## SEAWARD PATGuard 3 PAT Testing Software



## Product Information

## Specifications

- **Product Name:** PATGuard 3
- **Version:** 3.3.2
- **License Transferability:** Yes
- **Internet Connection:** Required for license transfer

## Product Usage Instructions

### How to Transfer License or Serial Number

To transfer the PATGuard 3 license from one computer to another, follow these steps:

1. Ensure that PATGuard 3.3.2 is installed on both computers.
2. On the computer with the original installation, open PATGuard 3 and go to the Login window.
3. Select "Deactivate License from this PC" to deactivate the original program.
4. Close PATGuard 3 on the original computer.
5. On the new computer, open PATGuard 3 and go to the login screen.
6. Select "Activate New Serial Number" and follow the activation process.

**Note:** The license transfer process requires an internet connection.

If you are trying to use an older version of PATGuard 3, please upgrade using the following steps:

1. Contact us at <https://www.seaward.com/gb/enquire/> for assistance.

## FAQ

- **Q: How can I contact Seaward for further assistance?**

A: You can contact Seaward at the following address:

## How To Transfer

### How to transfer a licence or serial number?

If you have PATGuard 3.3.2 installed it is possible to move the PATGuard 3 licence from one computer to another. Simply select "Deactivate Licence from this PC" at the Login window to deactivate the original program. On the login screen of the new install, select "Activate New Serial Number" and follow the activation process. The above Transfer process requires an internet connection.

Note if you are trying to use an older version of PATGuard 3, please upgrade using:

1. If you are having problems with this you can also download a fresh copy of the software from the link below and install it over the top of the old – we recommend backing up your database before attempting this.
2. If you are having problems with this you can also download a fresh copy of the software from the link below and install it over the top of the old – we recommend backing up your database before attempting this.

<http://www.seaward.com/pg3>

If you require more help, please contact us at <https://www.seaward.com/gb/enquire/>.

15-18 Bracken Hill, South West Industrial Estate, Peterlee, County Durham, SR8 2SW, United Kingdom  
t: +44 (0) 191 586 3511 | f: +44 (0) 191 586 0227 | e: [sales@seaward.com](mailto:sales@seaward.com)  
[seaward.com](http://seaward.com)

## Documents / Resources

[illegible]

## References

- [!\[\]\(511a36c244659513b679df9c639945de\_img.jpg\) Electrical Safety Test Equipment Manufacturers | Seaward](#)
- [!\[\]\(2c0783baf87a2728b2fe49eb1c34c456\_img.jpg\) PATGuard 3 PAT Testing Software | Free Trial Available | Seaward](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.