

SECOMP HDMI Extender Over Twisted Pair Instructions

Home » SECOMP * SECOMP HDMI Extender Over Twisted Pair Instructions



Contents

- 1 Safety Instructions:
- 2 Documents / Resources
 - 2.1 References

Safety Instructions:

14.01.3468 ROLINE HDMI Extender over Twisted Pair, Cat.5/6, chainable, 100 m 14.01.3469 ROLINE HDMI Receiver over TP, for 14.01.3468, 100 m

- This device is for indoor use only.
- Please do not use it in places with high humidity or moisture.
- Please do not place any objects on top of the devices while using it.
- It is normal that the HDMI Extender will get a little bit warm while the device is working.
- Please use the enclosed power adapter and plug the charger into a socket with a voltage of 100V~240VAC.
- A Cat.5e or above UTP cable is recommended
- When plugging in or unplugging cables or HDMI devices, do not use excessive force to avoid damaging the connection.
- Do not open the cover or disassemble this product.
- Do not stack this device or place heavy objects on it.
- If the device does not work properly, please contact your vendor.



Documents / Resources

Excital Limited Limited Sections of the Control of

SECOMP HDMI Extender Over Twisted Pair [pdf] Instructions

14.01.3468, 14.01.3469, HDMI Extender Over Twisted Pair, Extender Over Twisted Pair, Over Twisted Pair, Twisted Pair

References

• User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.