



Contents [[hide](#)]

[1 SECURA TM034 60 Minute Countdown Visual Timer](#)

[2 Parts Names](#)

[3 Instructions for use](#)

[4 Cleaning](#)

[5 Manufacturer's Limited Warranty](#)

[6 Documents / Resources](#)

[6.1 References](#)

SECURA®

SECURA TM034 60 Minute Countdown Visual Timer



Welcome to the Secura Family!

- Congratulations on being the proud owner of your new Secure product.


- We believe in manufacturing only the highest quality kitchen, home and personal care products for our customers. We are a U.S. -based manufacturer and all our products meet strict standards for manufacturing, safety and performance.
- We also believe in providing the best customer service and support in the industry. That is why we Offer a 2-year warranty on this product that ensures your satisfaction – so you can enjoy it for years to come. If you have questions or need any assistance, email CustomerCare@thesecura.com. For fastest response, please include product name and model #, proof of original purchase, complete contact information, and detailed information about the issue, including pictures when applicable.
- Your feedback and suggestions are also important to us, so email them to us at CustomerCare@thesecura.com.

The Secure Team

Copyright 2022-2023 Secura, Inc. All rights reserved.

- The material in this publication is protected under International and Federal Copyright Laws and Treaties, and as such, any unauthorized reprint or use of this material is strictly prohibited.
- No part of this book may be reproduced or transmitted in any form without the written permission of the author, except for the inclusion of brief quotations in a review.
- Reproduction or translation of any part of this work without the express permission of the copyright holder is against the law.


Parts Names



Instructions for use

Insert batteries


Slide the cover to open the battery compartment and insert 2×1.5V AAA batteries (not included) according to the positive and negative symbols shown.



Timer setting

Turn the rotary knob clockwise to desired time interval, the timer will count down. When

the rotary disk reaches “O” position, the timer will beep. Press the pause / stop button to turn off the alarm.




WARNING:







Do not turn the knob counterclockwise when the disk is on the 0 position, otherwise the clock will be damaged.


Pause

To pause during countdown, press the pause / stop button, the indicator light will illuminate red. Press the button again to restart the countdown.



Alarm duration and volume setting

- “3  60”
 - 3 = alarm duration 3 sec
 - 60 = alarm duration 60 sec
- “  
-  = alarm volume low
-  : alarm volume high



Low battery reminder

When the battery is low, the timer will beep and the indicator light will flash every two seconds until the timer is unable to beep or flash.

Cleaning

- Remove batteries during cleaning.
- Do not submerge the timer in water or any other liquid.
- Use a soft dry cloth to wipe the surface. Do not use abrasive or harsh materials or chemicals to clean.
- Do not place the timer in wet or extreme conditions.

Manufacturer's Limited Warranty

The Manufacturer of this product warrants to the original purchaser of this product that this product will be free from defects in material and workmanship under normal use and service for 2 years from date of purchase. Manufacturer will, at its option, repair or replace with a new or refurbished product. Providing a replacement product does not renew or extend the warranty period from the original date of purchase. The Manufacturer reserves the right, before having any obligation under this limited warranty, to inspect the product, and all costs of shipping the product for inspection and warranty service shall be borne solely by the purchaser.

For the fastest processing of a warranty claim, the Purchaser should e-mail CustomerCare@thesecura.com and include the product name and model #, proof of original purchase, complete contact information, and detailed information about the issue, including pictures when applicable.


The manufacturer's limited warranty is valid only in accordance with the following conditions:

1. The product is purchased directly from manufacturer or an authorized reseller or distributor.
2. Only the original purchaser is covered by this warranty. This warranty is not transferable.
3. Product is for personal use only. This warranty is void if the product is used in a commercial or institutional establishment.
4. This warranty does not cover normal wear and tear or damage caused by misuse, abuse, negligence, accident, acts of nature, or unauthorized modification or repair.
5. Purchaser must present acceptable proof of purchase for the product.
6. This warranty gives you specific legal rights, and you may also have other rights which vary from state to state.

Secura, Inc.

- CustomerCare@thesecura.com
- Lake Forest, California
- Secura Inc.
- [888-792-2360](tel:888-792-2360) (North America)
- Lake Forest, California
- www.thesecura.com

Documents / Resources

	<p>SECURA TM034 60 Minute Countdown Visual Timer [pdf] Instruction Manual</p> <p>TM034 60 Minute Countdown Visual Timer, TM034, 60 Minute Countdown Visual Timer, Minute Countdown Visual Timer, Countdown Visual Timer, Visual Timer</p>
---	---

References

- [User Manual](#)

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.