

# **SECURITYMAN B087RQ Adjustable Door Window Security Bar User Manual**

Home » SecurityMan » SECURITYMAN B087RQ Adjustable Door Window Security Bar User Manual



SECURITYMAN B087RQ Adjustable Door Window Security Bar User Manual



#### **Contents**

- 1 Introduction
- 2 Features
- 3 Restrictions
- **4 Contents**
- 5 Setup & Installation
- **6 Specifications**
- 7 Warranty
- 8 Documents /

Resources

- 8.1 References
- 9 Related Posts

#### Introduction

The SecurityMan **SECURITYBAR** is a heavy duty; dual function security bar made from high grade iron that can secure just about any hinged and/or sliding doors and windows. The **SECURITYBAR** is fully adjustable with an angled rubber bottom that assures full contact and strong grip on all types of floors without scratching them.

#### **Features**

- · Extra security for door and window
- · Adjustable to fit most doors and windows
- · Simple to use
- · Rugged heavy duty iron

## **Important**

This guide provides important information on the use and operation of your **SECURITYBAR** and the images/features shown throughout the manual are subject to change without notice due to system and firmware upgrades. Please read all the information carefully prior to using the product for the best performance and to prevent any damage/injuries or misuse of the device(s). Customers are entitled to have read through this complete user's manual before using the **SECURITYBAR**. Any unapproved changes or modifications will void your warranty. Please ensure to have a complete understanding of the following restrictions.

#### Restrictions

When using this product, the safety precautions below must be taken to avoid legal liabilities and damages. Retain and follow all product safety and operating instructions. Observe all warnings in the product operating instructions. To reduce the risk of bodily injury and damage to the equipment, observe the following precautions.

- Always use door and window locks in conjunction with the security bar.
- Always make sure that the caps at the end of the bar are pushed in tightly.
- Do not modify the security bar. Improper modifications can cause it to be inoperable and or cause damages to peripheral equipment.
- Never place the rubber foot of the **SECURITYBAR** on loose rugs or mats.

## **Contents**


## • SECURITY BAR



## • DOOR CAPS



## • SLIDING DOOR/WINDOWCAPS



• User's Manual




## Setup & Installation

The **SECURITYBAR** can be used on both hinged and/or sliding doors and windows. The following guide will show you how to place the **SECURITYBAR** on both applications.

#### **SLIDING DOORS AND WINDOWS**


1. Attach the white caps to the ends of the **SECURITYBAR**, and adjust the length of the bar by pressing in the gold button and slightly rotate either tube so that the alignment holes and button are misaligned, then slide the smaller tube in or out to make your adjustments.






2. Once you've reached the desired length, rotate the tubes so that the button and holes are realigned and the button pops back out of the alignment hole.






3. Place the **SECURITYBAR** in-between the sliding door /window and the sliding door/window frame.






#### **HINGED DOORS**

1. Attach the rubber foot and fork to the ends of the **SECURITYBAR** and angle the rubber foot end 12-18 inches from the bottom of the door.




2. Adjust the length of the bar by pressing in the gold button and slightly rotate either tube so that the alignment holes and button are misaligned, then slide the smaller tube in or out to make your adjustments. Once you've reached the desired length, rotate the tubes so that the button and hole are realigned and the button pops back out of the alignment hole.




3. Place the fork's flat end of the **SECURITYBAR** under the door knob.





4. Slide the bottom rubber foot in towards the door until its snug and tight.





**IMPORTANT:** For maximum grip, please refrain from placing the rubber foot of the **SECURITYBAR** on loose rugs or mats.

## **Specifications**

| 2-in-1 Material Force | For door knob, sliding door, & window                                 |
|-----------------------|---|
| Material              | High grade iron tube  |
| Force                 | 350lbs max pressure   |
| Adjustable Length     | 22.25" to 43.7" (inch)  |
| Adjustable hole       | 15 ports  |
| Gauge                 | 1/16"" (thickness)  |
| Color                 | White   |
| Size                  | Outer bar 20.5"x1" / Inner bar 20.5" x .875" (without fee t attached) |
| Weight (net / gross)  | 1.65 lbs / 2.65 lbs   |

## Warranty

SecurityMan warrants that this product will be free from defects in materials and workmanship for one year or otherwise specified on the product packaging. This limited warranty shall commence from the date of purchase. SecurityMan Products warranty is not transferable and is limited to the original purchaser. If the product is found to be defective then, as your sole remedy and as the manufacturer's only obligation, SecurityMan will repair or replace the product. This warranty shall not apply to products that have been subjected to abuse, misuse, abnormal electrical or environmental conditions, normal wear and tear or any condition other than what can be considered normal use.

#### **Copyright Notice**

This manual is furnished under license and may be used or copied only in accordance with the terms of such license. Except as permitted by such license, no part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or any means, electronic, mechanical, recording, or otherwise, including translation to another language or format, without the prior written permission of SecurityMan. The content of this manual is furnished for informational use only, is subject to change without notice, and should not be construed as a commitment by SecurityMan. SecurityMan assumes no responsibility or liability for any errors or inaccuracies that may appear in this book. All other product names, trademarks and registered trademarks in this document are the proper-ties of their respective holders.

#### SecurityMan®

4601 E. Airport Drive, Ontario, CA 91761, USA

Tel: 888-977-3777 or 909-230-6668 Fax: 909-230-6889

Email: info@securitymaninc.com

Website: http://www.securitymaninc.com

Copyright 2017 by SecurityMan v2.2

If you encounter any difficulty in the operation of this product after reading the manual, please feel free to contact us. You can reach us by phone at 1-888-977-3777 from 8:30 AM to 5:30 PM Monday through Friday (Pacific Standard Time) or by email <a href="techsupport@securitymaninc.com">techsupport@securitymaninc.com</a>. We will be happy to answer your questions and help you in any way we can.

For Customer Service: 888-977-3777



## **Documents / Resources**



SECURITYMAN B087RQ Adjustable Door Window Security Bar [pdf] User Manual B087RQ Adjustable Door Window Security Bar, B087RQ, Adjustable Door Window Security Bar, Door Window Security Bar, Window Security Bar, Bar

#### References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.