



[Home](#) » [SeenDa](#) » **SEENDA COE311 Multi Device Ergonomic Keyboard Mouse Combo User Manual** 

Contents [[hide](#)]

- [1 SEENDA COE311 Multi Device Ergonomic Keyboard Mouse Combo](#)
- [2 Product Features](#)
- [3 Connection](#)
- [4 Charging Guide](#)
- [5 Multimedia Function Button](#)
- [6 Product Parameter](#)
- [7 Package Contents](#)
- [8 Product Warranty](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)


SEENDA


SEENDA COE311 Multi Device Ergonomic Keyboard Mouse Combo



Product Features

Multimedia Function Keys






- A Left Button
- B Right Button
- C Scroll Wheel
- D Forward Button
- E Backward Button
- F DPI/Charging/Low Battery Indicator
 - **Charging:** Red Light On
 - **Fully Charged:** Green Light On
 - **Low Battery:** Flashing Red Light
- G DPI Button
- I Bluetooth Channel Indicator

- J 2.4G USB Channel Indicator
- M Type-C Receiver
- O Channel Switch Button
- H Type-C Charging Port
- J 2.40 Type-C Channel Indicator
- L Power Switch
- N USB Receiver

DPI Indicator


Press the DPI button to adjust the cursor sensitivity. A single flash of indicator light corresponds to DPI level 1000, two to 1600, three to 2400.



Connection

2.4C USB Connection

1. Turn the power switch to ON.




2. Press the  button until the  indicator lights up, and the keyboard enters 2.40

USB channel. (If indicator does not light up, try to press “ + ”)



Press the channel switch button on the bottom of the mouse, the indicator lights up,

and the mouse enters 2.40 USB channel.




3. Take out the USB receiver from the bottom of the mouse.

4. Plug the USB receiver into the USE port of the computer, then the keyboard and mouse can work normally.




Type-C Connection

1. Turn the power switch to ON.



2. Press  the button until the  indicator lights up, and the keyboard enters 2.4G Type-C channel. (If indicator does not light up, try to press  + ) Press the channel switch button on the bottom of the mouse, until  indicator lights up, and the mouse enters 2.40 Type-C channel.

2




Take out the Type-C receiver from the bottom of the mouse.

3. Plug the Type—C receiver into the Type-C port of the computer, then the keyboard and mouse can work normally.



Keyboard Bluetooth Connection


1. Turn the power switch to ON.



Press F3 the button until the  indicator lights up, and the keyboard enters Bluetooth

channel. (If indicator does not light up, try to press F1+ F3")


Long press F3 button for 5 seconds until the corresponding channel indicator flashes quickly, the keyboard enters Bluetooth pairing mode.



2. Turn on the Bluetooth settings on your device, search or select “SEENDA COE310” and start Bluetooth pairing until the connection is completed.

Keyboard Channel Switching


After channels 🖨️ / 🖱️ / 🎧 are all connected, press the corresponding channel button to switch between multiple devices.



NOTE: If FN lock is enabled, please press **FN** + **F1** / **F2** / **F3** to switch between con dcviCC5.


Mouse Channel Switching

After channels 🖨️ / 🖱️ / 🎧 are all connected, press the channel switch button on the bottom of the mouse to switch between multiple devices.



Charging Guide

1. When the battery is low, the indicator light will turn red and begin to flash until the keyboard or mouse is powered off.
2. To charge the device, insert the Type-C port into the keyboard or mouse and the USB-A port into the computer. The red indicator light stays on while charging.
3. A full charge typically requires 2 to 3 hours per cycle, and the indicator light will turn green when fully charged.



Multimedia Function Button

Button	Windows	Android	iPadOS	macOS
	2.4G USB Channel	2.4G USB Channel	2.4G USB Channel	2.4G USB Channel
	2.4G Type-C Channel	2.4G Type-C Channel	2.4G Type-C Channel	2.4G Type-C Channel
	Bluetooth Channel	Bluetooth Channel	Bluetooth Channel	Bluetooth Channel
	Window Switch	Window Switch	Multi-Window Preview	Multi-Window Preview
	Multi-Window Preview	Multi-Window Preview	Application Switch	Application Switch
	Show Desktop	Show Homepage	Show Homepage	Show Desktop
	Search	Search	Search	Search
	Screenshot	Screenshot	Screenshot	Screenshot
	Play & Pause	Play & Pause	Play & Pause	Play & Pause
	Mute	Mute	Mute	Mute
	Volume -	Volume -	Volume -	Volume -
	Volume +	Volume +	Volume +	Volume +
	FN+ESC (FN lock) button to turn on or turn off the FN function			

Product Parameter

Keyboard

DPI	1000-1600-2400
Battery capacity	300mAh
Working voltage	3.7V
Working current	≤3mA
Standby current	≤0.4mA
Sleeping current	≤0.03mA
Standby time	300 Days
Working time	100 Hours
Charging time	2-3 Hours
Wake up way	Press any key
Input Parameters	DC 5V 250mA
Dimensions	125*65*39mm/4.9*2.6*1.5in

Mouse

Battery capacity	500mAh
Working voltage	3.7V
Working current	≤5mA
Standby current	≤0.1mA
Sleeping current	≤0.03mA
Standby time	300 Days
Working time	100 Hours
Charging time	2-3 Hours
Wake up way	Press any key
Dimensions	397*227*34mm/15.6*5.9*1.3in

2.4G USB Channel	Windows XP, 7 to 11 or above.
2.4G Type-C Channel	Windows 7 to 11 or above, macOS 10.12 or above.
Bluetooth Channel	Windows 8/10 or above, macOS 10.12 or above, iPadOS 7.0 or above, Android 4.4 or above.

Sleep Mode

1. When the keyboard/mouse stops working for 60 minutes, it will automatically enter the sleep mode for energy saving.
2. When use the keyboard/mouse again, you only need to press any key, and the keyboard/mouse will wake up within 3-5 seconds.
3. The channel indicator lights up and start working.

Package Contents

- 1 Wireless Keyboard
- 1 Wireless Mouse (The receiver is on the bottom of the mouse)
- 1 Type-C Charging Cable
- 1 User Manual

Safety Warning

IMPORTANT: TO reduce risk Of fire, electric shock, or injury, follow these safety instructions.

- **Charging Safely:** use only the provided cable. Charge in a well-ventilated, dry area away from inflammable materials.
- **Battery Handling:** Do not attempt to replace the item's lithium battery. Battery

replacement should be conducted by qualified personnel to prevent hazards.

- **Heat Exposure:** Avoid leaving the item in high-temperature environments or in direct sunlight, which could result in a fire hazard.
- **Liquid Exposure:** Keep the item away from water and liquids. Do not use if wet until thoroughly dried.
- **Damage and Leakage:** Cease usage and consult customer service if the item is damaged or the battery leaks.
- **Correct Disposal:** Follow local regulations for disposing of electronic devices and batteries. Do not dispose of with household waste.
- **Radio Frequency Interference:** This device may cause interference with other electronics. Keep a safe distance from sensitive devices.
- **A Child Safety:** Keep the item and its components out of reach of children to avoid choking or battery ingestion hazards. Never allow children to handle the item unsupervised.

CAUTION: Non-compliance with the above warnings can lead to serious injury or property damage.

EU Declaration of Conformity

- **Declared Object:** Multi-Device Ergonomic Keyboard Mouse Combo
- **Model:** COE310
- **Rating:** 3.7v=10mA
- **Input:** 5V=250mA
- **Place of Production:** Made in China
- **Manufacturer:** Dongguan Togran Electronics Technology Co.,Ltd.
- **Email:** sales08@togran.com
- **Address:** No.110, Shidan Middle Road, Shijie Town, Dongguan City, Guangdong Province, China, 523290
- **European Representative:**
- **EC REP**
- **Business name:** g.L.L CmbH
- **Business address:** Bauernvogtkoppel, 55c, 22393, Hamburg, Germany
- **Email:** g.L.LDE@outlook.com

- **Tel:** +49162 3305764
- **UK REP**
- **Business name:** AMANTO INTERNATIONAL TRADE LIMITED
- **Business address:** The Imperial, 31-33 St Stephens Gardens, Notting Hill, London, United Kingdom, W2 SNA
- **Email:** AmantoUK@outlook.com
- +44 7921 801942
- It is our sole responsibility to declare that the above products are in full compliance with Directive Position:
- **Signature:**



- **Date of Sign:** 20221.5
- **EU agent name:**



- 2014/S3/EU.2011/6S/EU (as amended)
- **Managing Director** 20221.5

Product Warranty

All Seenda products come with a 24-month warranty policy, please do not hesitate to contact us if you have any questions. Our support team will try our best to provide you with a pleasant shopping experience.

- **Our email:** support@seenda.com
- **Our website:** www.seenda.com
- **Phone:** +1844-968-2543
- **Mon-Fri:** 10AM – 2PM; 3PM – 7PM ET
- Closed during Holidays

Documents / Resources

	SEENDA COE311 Multi Device Ergonomic Keyboard Mouse Combo [pdf] User Manual COE311, COE311 Multi Device Ergonomic Keyboard Mouse Combo, Multi Device Ergonomic Keyboard Mouse Combo, Device Ergonomic Keyboard Mouse Combo, Ergonomic Keyboard Mouse Combo, Keyboard Mouse Combo
---	---

References

- [User Manual](#)

SeenDa

COE311, COE311 Multi Device Ergonomic Keyboard Mouse Combo, Device Ergonomic Keyboard Mouse Combo, Ergonomic Keyboard Mouse Combo, Keyboard Mouse Combo, Multi Device Ergonomic Keyboard Mouse Combo, SeenDa

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

Post Comment

Search:

e.g. whirlpool wrf535swhz

Search

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.