



SEGA 1650 Genesis Game Controller Instructions

[Home](#) » [Sega](#) » SEGA 1650 Genesis Game Controller Instructions 



SEGA Genesis' Control Pad


SEGA Genesis Control Pad for the Nintendo Switch system. Before using the controller for the first time, charge and pair it with a Nintendo Switch system.

Contents


- [1 Pairing Instructions](#)
- [2 Documents / Resources](#)
- [3 Related Posts](#)

Pairing Instructions

- From the HOME Menu, select Controllers
- Select Change Grip/Order
- Press and hold down the SYNC Button
- Release the button when the LED(s) stop flashing and remains lit



SYNC Button



IMPORTANT! Read the Health and Safety information before setup or using up your system. This information is included with the Nintendo Switch system or in the system menu at HOME Menu>System Settings>Support/Health & Safety

Trademarks are the property of their respective owners. Nintendo Switch and Joy-Con are trademarks of Nintendo. © Nintendo. © SEGA. SEGA, the SEGA logo, Genesis are either registered trademarks or trademarks of SEGA Holdings Co., Ltd. or its affiliates. All rights reserved. SEGA is registered in the U.S. Patent and Trademark Office.

This device complies with Part 15 of FCC Rules and ISSED's license-exempt RSS. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept t an interference received, including interference that may cause undesired operation.

For FCC and ISSED information, visit / Pour plus d 'informations sur la FCC et l'ISDE, visitez


support.nintendo.com/switch/setup





This product is covered by Nintendo's Limited Warranty.
To request a printed copy, contact Consumer
Service. support.nintendo.com/switch/warranty
WARNING: Cancer and reproductive harm – p65warnings.ca.gov
CUSTOMER SERVICE: [/SUPPORT.NINTENDO.COM](https://SUPPORT.NINTENDO.COM) | 1-800-255-3700
Made in China.

Documents / Resources

	<p>SEGA 1650 Genesis Game Controller [pdf] Instructions HAC045, BKEHAC045, 1650 Genesis Game Controller, Genesis Game Controller</p>
---	--

[Manuals+.](#)