



Home » Sega » SEGA SJ-300 Joystick Controller Instruction Manual 📆

Contents [hide]

- 1 SEGA SJ-300 Joystick Controller
- **2 OPERATION MANUAL**
- 3 PRECAUTIONS FOR THE USE OF JOYSTICK SJ-300
- 4 Documents / Resources
 - 4.1 References



SEGA SJ-300 Joystick Controller



SG-1000 FOR THE SERIES SC-3000

OPERATION MANUAL


(Be sure to read this manual before using the JOYSTICK)


This is an authentic JOYSTICK and is of the same type as that used in the game center video games.

The JOYSTICK SJ-300 was developed for the SEGA SC-3000 series and the SG-1000 series.

It is also compatible with the following:

- NEC-PC-6000 series
- COMMODORE MAX-VIC-C64
- ATARI 400-800-2800





PRECAUTIONS FOR THE USE OF JOYSTICK SJ-300

- 1. This JOYSTICK is intended for ordinary use. Exerting unnecessary force, or using in any unnatural way, may cause damage.
- 2. The disassembly or alteration of the JOYSTICK may create problems in the mechanism.
- 3. When disconnecting the JOYSTICK from the computer, pull out by grasping the connector so as not to stretch the cord.
- 4. Keep the JOYSTICK from coming into contact with water and avoid using it in places where the temperature is high.
- 5. Wipe off stains by using water or chemical detergent. Do not use solvents such as thinner, etc.

Documents / Resources



SEGA SJ-300 Joystick Controller [pdf] Instruction Manual SJ-300 Joystick Controller, SJ-300, Joystick Controller, Controller

References

User Manual

Leave a comment

Your email address will not be published. Required fields are marked*

Comment *	
Name	
Email	
Website	
☐ Save my name, email, and website in this browser for the next time I comment.	
Post Comment	
Search:	
e.g. whirlpool wrf535swhz	h

Manuals+ | Upload | Deep Search | Privacy Policy | @manuals.plus | YouTube

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.