


SEIWA EXPLORER 23 Chartplotter Plus Multifunction Controller Instruction Manual

Home » SEIWA » SEIWA EXPLORER 23 Chartplotter Plus Multifunction Controller Instruction Manual



EXPLORER 23 Chartplotter Plus Multifunction Controller Instruction Manual



Contents

- 1 Warranty and warnings
- 2 Installation
- 3 Keyboard
- **4 Connections Scheme**
- **5 Product conformity**

information

- 6 Documents / Resources
- 7 Related Posts

Warranty and warnings

AvMap SrI warrants every unit to be free from defects in material and workmanship under normal use and service for a period of 24 months from the original retail purchase. During the warranty period,

AvMap Srl will repair or replace any component which fails in normal use without charges for parts or labor. Technological developments, modifications, and upgrades of the software are not covered by warranty. To receive warranty service, contact your local authorized dealer for shipping instructions. The device should be securely packed with its tracking code clearly written on the outside of the package, shipping to be paid by the customer. Include a copy of the original sales receipt as proof of purchase. This limited warranty does not extend to any device which has been subjected to misuse, neglect, accident, incorrect wiring or improper installation. **AvMap Srl** reserves the right to repair or replace the device at its sole discretion.

For more warranty information please see the web site: www.seiwadirect.com For technical advice or assistance in Europe contact:

AvMap Srl

Viale Zaccagna 6, 54033 Carrara (MS), Italy Customer support: +39-0585-784044 support@seiwadirect.com

-	Ÿ	•
/	1	1
L	:	_

Electronic charts displayed by the device are believed to be accurate and reliable, but they are not inten ded to replace official charts which should remain your main reference for all the matters related to the e xecution of safe navigation. For this reason, we would like to remind you that you are required to carry on board and use the officially published and approved nautical charts.



Please be aware that the serial ports are not optoisolated and therefore the peripherals are electrically c onnected to the device. This allows the connection of high-speed peripherals, like Fish Finder. If you are connecting an NMEA0183 peripheral and you would like to isolate it from the device, you have to add the optoisolator externally.



If water leaks into the equipment, immediately turn off the power at the switchboard. Fire or electrical shock can result.



If the equipment is giving off smoke or fire, immediately turn off the power at the switchboard. Fire or ele ctrical shock can result.



Do not open the equipment. The equipment uses high voltage that can cause electrical shock.



Keep the SD card slot's door closed to avoid water intrusion into the device



Extensive exposure to heat may result in damage to the device.




Please read through the device manual before the first operation. If you have any questions, please contact the Company's customer service or your local dealer.




Chart media are available from C-Map and Navionics authorized resellers.

Installation


2.1 Bracket Mount.




2.2 Panel Mount




2.3 How to insert the MicroSD





Keyboard



1. The joystick can move the cursor around the map or through menu items. Press [UP], [DOWN], [LEFT] or [RIGHT].

2. [ZOOM OUT]

Change the scale of the map by zooming out.

3. [ZOOM IN]

Change the scale of the map by zooming in.

4. [ENTER]

Push it to confirm your choice. When on the map page, it opens the contextual menu of a map object.

5. [CLEAR]

Short press' exits from the current menu (back).

Long press• allows you to come to the main page or if you are on the map page and the cursor is away from the boat position, centers the map on the boat position (home mode).

6. [MENU] — [PAGE]

Short press: Menu — opens the main menu if pressed on one of the main pages (Map, Fish Finder, GPS status, Engine monitor). It selects the top bar control buttons if pressed on full menu pages such as Marks, Routes, Tracks, and others.

Long press. Page — shows the main pages, it is the quickest way to switch between pages.

7. [MOB]

Is a special key dedicated to man-over-board situations Pressing MOB places a MOB mark on the current boat position and starts navigation to that place.

8. [POWER] — [DAY / NIGHT]

Short press. allows switching Day/Night modes.

Long press tums the device on/off when pressed and held in.

[F1 — F4] are special keys. Each key can perform two functions: a short press performs the fixed function labeled on the unit face. A long press (hold) executes the second function which can be customized. Read the software manual to learn how to customize the function keys.

9. [FI] — [WP]

Short press: WP — insert a new waypoint on the cursor position.

10. [F2] — [MARK]

Short press: Mark — allows adding a new mark.


11. [F3] — [TRACK]

Short press: Track — start and stop the track.

12. [F4] — [GOTO]

Short press: Go To — to navigate to a destination (desired position on the map).


Connections Scheme




Power & I/O Connector (Port A and C)			
PIN	FUNCTION		
1	PWR-/GND		
2	POWER INPUT + (10-35 Vdc)		
3	INPUT A	1/20 0 9M	
4	COMMON]((3° 8°′))]	
5	OUTPUT C	\\\\4° 0= °6//	
6	OUTPUT A		
7	INPUT C		
8	EXTERNAL ALARM OUTPUT +		

NMEA 2000 Connector				
PIN	FUNCTION			
1	NOT CONNECT			
2	POWER +	<i> </i> /2°o1\\\		
3	POWER -](\begin{align*} 3. \display* 3		
4	SIGNAL H			
5	SIGNAL L			

4.1 Power Supply connection only




4.2 Autopilot Connections Autopilot on Port A




WARNING

Do not connect the COMMON connections (green wires) of the I/O ports to the power cables of external devices. This connection could damage the hardware of the device.

Autopilot on Port C




4.3 External alarm connection




Note: Current MAX 300 mA

4.4 NMEA0183 Connection

External NAME on Port A



External NAME on Port C



- Dimensions: 172.5 x 106.5 x 84.4 mm (6.8" x 4.2" x 3.3") with holder
- Weight: 350 g (12.3 oz)
- · Back-lit keyboard
- Integrated remote control receiver (radio IF 2.4 Ghz)
- · External GPS connector
- NMEA 2000 NMEA 0183: 2x Rx/Tx on the power cable
- · External alarm
- Built-in HDMI video input cable (compatible with any HDMI display)
- Memory slot: MicroSD
- · Wireless LAN connection compatibility*
- · Mounting options: Bracket and flush mount

Waterproof IPX6

• Supply Voltage: 10-35 Vdc

• Operating temperature: -10°C / +60°C

• Storage temperature: -20°C / +80°C

• Transmitting frequency range: 2400 – 2483 MHz

Maximum transmitting power 1 mW (or 100mVV*)

Maximum power consumption: 4W (or 6.5W*)

Product conformity information

6.1 FCC compliant

This equipment has been tested and found to comply with the limits for a class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the AvMap Satellite Navigation could void the user's authority to operate the equipment.

Compliance information statement

	Name	P/N	
Identification of the product	Explorer 23 Explorer 23 Wireless LAN version	P3MC1000SE P3MC100WSE	
Certified components	Remote control receiver: FCC ID: CU9- P3MC1000 WiFi and BT module (Wirele ss LAN version only): FCC ID: Z64-WL18SBMOD		
Applicable compliance state ments	This device complies with part 15 of the FCC Rules. Operation is subject to the f ollowing two conditions: (1) This device may not cause harmful interference, and (2) This device must accept any interference received, including interference that may cause undesired operation.		
Responsible party	Name	AvMap Satellite Navigation Inc.	
	Address	25 Enterprise Zone Drive, Riverhead, NY 1 1901, USA	
	Phone	+1-800-363-2627	
	Website	www.avmap.us	

^{*}Wireless LAN version

6.2 Simplified EU declaration of conformity

Hereby,

AvMap Srl, Viale Zaccagna 6, 54033 Carrara (MS), Italy declares that the radio equipment in the following table are in compliance with Directive 2014/53/EU.

Explorer 23	P3MC1000SE
Explorer 23 Wireless LAN version	P3MC100WSE

The full text of the EU declaration of conformity for every single product is available at the following internet address: **eudeclaration.avmap.it**



Documents / Resources



<u>SEIWA EXPLORER 23 Chartplotter Plus Multifunction Controller</u> [pdf] Instruction Manual EXPLORER 23, Chartplotter Plus Multifunction Controller, EXPLORER 23 Chartplotter Plus Multifunction Controller, Multifunction Controller, Controller

Manuals+,