

SENA 10R Utility App Device Manager User Guide

Home » Sena » SENA 10R Utility App Device Manager User Guide 🖫

SENA 10R Utility App Device

Manager User Guide


Sena Utility App

- Download
 - Android: Google Play Store > Sena Utility
 - iOS: App Store > Sena Utility


Sena Device Manager

The **Sena Device Manager** allows you to upgrade the firmware and configure its settings directly from your PC or Apple computer. Download the **Sena Device Manager** from <u>sena.com</u>.


Charging




Button Operation




Power On/Off




Volume Adjustment




Battery Check




Phone, Music Pairing




Music Operation




Mobile Phone Call Making and Answering



Intercom Pairing



Intercom Start/End



Setting

Configuration Menu



Troubleshooting

Factory Reset

If you want to restore the 10R to factory default settings, use the Factory Reset in the configuration menu. The headset automatically restores the default settings and turns off.

Fault Reset



If the 10R is not working properly for any reason, reset by gently pushing the pin-hole reset button located below the (+) button.

You can download the full version of the manual and view other Sena products at the Sena website: www.sena.com.

10R Quick Reference

Туре	Operation	Button Command	LED
Basic Function	Power on	Press the Center Button and the (+) Button for 1 second	Solid blue
	Power off	Tap the Center Button and the (+) Button	Solid red
	Volume adjustment	Tap the (+) Button or the (-) Button	-
Mobile Phone	Answer mobile phone call	Tap the Center Button	-
	End mobile phone call	Press the Center Button for 2 seconds	-
	Voice dial	Press the Center Button for 3 seconds	-
	Speed dial	Press the (+) Button for 3 seconds	-
	Reject incoming call	Press the Center Button for 2 seconds	-
Intercom	Intercom pairing	Press the Center Button for 5 seconds	Red flashing
		Tap the Center Button of any one of the two headsets	
	Start/End each intercom	Tap the Center Button	-
	End all intercoms	Press the Center Button for 3 seconds	-
	Start Group Intercom	Tap the (+) Button and the (-) Button at the same time	Blue and red flashing
	End Group Intercom	Press the Center Button for 3 seconds	-
Music	Play/Pause Bluetooth music	Press the Center Button for 1 second	-
	Track forward/back	Press the (+) Button or the (-) Button for 1 second	-





www.sena.com

Contents

- 1 Documents / Resources
 - 1.1 References

Documents / Resources





References

- E The Best Motorcycle & Action Sport Bluetooth Devices | Sena
- E The Best Motorcycle & Action Sport Bluetooth Devices | Sena

Manuals+,