



SENA 50C Motorcycle Camera and Communication System With Mesh Intercom User Guide

[Home](#) » [Sena](#) » SENA 50C Motorcycle Camera and Communication System With Mesh Intercom User Guide 

SENA 50C Motorcycle Camera and Communication System With Mesh Intercom



Contents

- 1 Downloadable Sena Software
- 2 Product Details
- 3 Installation
- 4 Mesh Intercom Antenna
- 5 Icon Legend
- 6 Basic Operations
- 7 Checking the Battery Level
- 8 Phone Pairing
- 9 Using the Phone
- 10 Siri and Google Assistant
- 11 Music Control
- 12 Camera Controls
- 13 Mesh Intercom™
- 14 Open Mesh
- 15 Group Mesh
 - 15.1 Creating a Group Mesh
 - 15.2 Joining an Existing Group Mesh
- 16 Enable/Disable Mic (Default: Enable)
- 17 Reset Mesh
- 18 Bluetooth Intercom
 - 18.1 Using the Button
- 19 Last-Come, First-Served
- 20 Two-way Intercom
- 21 FM Radio
- 22 Headset Configuration Menu
- 23 Troubleshooting
- 24 Quick Reference
- 25 Documents / Resources
 - 25.1 References
- 26 Related Posts

Downloadable Sena Software

Download the **SENA MOTORCYCLES App** at **Google Play Store** or **App Store**.



SENA MOTORCYCLES

- Device configuration setting

Download the **Sena Camera App** at **Google Play Store** or **App Store**.



Sena Camera

- Live preview, video setting

Download the following items at sena.com.



Firmware



Sena Device Manager

- Firmware upgrade
- Device configuration setting



Quick Start Guide, User's Guide

Follow us on Facebook, YouTube, Twitter and Instagram to check the latest information and helpful tips.



SENA

SENA Technologies, Inc.



Customer Support: sena.com


Product Details




Installation

- For more information about installation, refer to the User's Guide.


1




2





3




4





Mesh Intercom Antenna

Pull the Mesh Intercom Antenna inwards slightly to unfold it.



Icon Legend



Tap button/Jog Dial the specified number of times



Press and Hold button/Jog Dial for the specified amount of time



Rotate Jog Dial clockwise (right) or counterclockwise (left).




Rotate while Pressing Jog Dial clockwise (right) or counterclockwise (left).




“Hello” Audible prompt

Basic Operations


- Powering On




- Powering Off



- Volume Up



- Volume Down



Checking the Battery Level

Powering On



=



=




=



Phone Pairing

①




Blinking  



"Phone pairing"


- ② Select **50C** in the list of Bluetooth devices detected.




- For more information on phone pairing, refer to the User's Guide.

Using the Phone

- **Answer a Call**



- **End a Call**




- **Reject a Call**




Siri and Google Assistant

Activate the Siri or Google Assistant Installed on Your Phone




"Hey or "Hey Siri" Google"

OR




Music Control



- Play/Pause



- Track Forward




- Track Backward




Camera Controls

- Camera On




"Camera on"

- Camera Off



"Camera off"

- Start Recording




Blinking twice 



"[Shutter sound]"

- Stop Recording




Blinking twice 



"Recording"


- Take Photos



Note:


- If the **video resolution** is **2160p/30fps**, you cannot **take a photo** during video recording.
- You cannot record videos without a microSD card.
- Your **microSD card** needs to be formatted before using the camera.
- **MicroSD** cards up to **128 GB** and **U3** or higher cards are compatible.

Change Wi-Fi Channel (Default: 5 GHz)




② Select 5 GHz or 2.4 GHz.

- 5 GHz:



Blinking twice 

- 2.4 GHz:



Blinking twice 

Note: IF YOUR SMARTPHONE OR REGION DOES NOT SUPPORT 5 GHZ, YOU MUST CHANGE THE WI-FI CHANNEL TO 2.4 GHZ.


Mesh Intercom™



Open Mesh™: communication within the same channel.

Group Mesh™: communication within the same private group.


- For more information on **Mesh Intercom**, refer to the User's Guide.


Mesh Intercom On



Blinking 
 "Mesh intercom on,
 Open Mesh, channel 1"

Mesh Intercom Off



 "Mesh intercom off"

Note: When **Mesh Intercom** is on, the **50C** will automatically connect to nearby **50C** users and the headset will be in **Open Mesh (default: channel 1)** initially


Open Mesh

Channel Setting (Default: channel 1) in Open Mesh


① Enter into the **Channel Setting**.



② Navigate between channels. (1 → 2 → ... → 8 → 9 → Exit → 1 → ...)



③ Save the channel.




Note: You can use the **SENA MOTORCYCLES** App to change the channel.

Group Mesh


Group Mesh is a closed group intercom function that allows users to join, leave, or rejoin a group intercom conversation without pairing each headset.

Creating a Group Mesh


Creating a **Group Mesh** requires **two or more Open Mesh** users.



① **Users (You, B, and C)** enter into **Mesh Grouping** to create a **Group Mesh**.




② When **Mesh Grouping** is completed, the **users (You, B and C)** will hear a voice prompt on their headset as **Open Mesh** switches to **Group Mesh**.




Joining an Existing Group Mesh

One of the current users in an **Existing Group Mesh** can allow **new users (one or more)** in **Open Mesh** to join the **Existing Group Mesh**.

Existing



① **One (You) of the current users** in the **Existing Group Mesh** and **new users (D and F) in Open Mesh** enter into Mesh Grouping to join the **Existing Group Mesh**.



② When **Mesh Grouping** is completed, the **new users (D and F)** will hear a voice prompt on their headset as **Open Mesh** switches to **Group Mesh**.




Enable/Disable Mic (Default: Enable)

Users can enable/disable the microphone when communicating in a



Reset Mesh


If a headset in an **Open Mesh** or **Group Mesh** resets the **Mesh**, it will automatically return to **Open Mesh** (default: channel 1).



"Reset Mesh"

Bluetooth Intercom

Up to three other people can be paired with the headset for Bluetooth intercom conversations.




Intercom Pairing

There are two ways to pair the headset.


Using the Smart Intercom Pairing (SIP)

SIP allows you to quickly pair with your friends for intercom communication by scanning the QR code on the **SENA MOTORCYCLES App** without remembering the button operation.

① Pair the mobile phone with the headset.


② Open the **SENA MOTORCYCLES App** and tap  (Smart Intercom Pairing Menu).

③ Scan the QR code displayed on your friend (B)'s mobile phone.

- Your friend (B) can display the QR code on the mobile phone by tapping > **QR code** () on the **SENA MOTORCYCLES App**.



④ Tap Save and check that your friend **(B)** is paired with **you (A)** correctly.


⑤ Tap **Scan** () and repeat steps 3-4 to pair with **Intercom Friends (C)** and **(D)**.

Note: The **Smart Intercom Pairing (SIP)** is not compatible with Sena products that use **Bluetooth 3.0** or **below**.

Using the Button




① The **users (You, B)** enter into **Intercom Pairing**.



② The **users’ headsets** will be automatically paired.

Turns blue ●




③ Repeat the steps above to pair with **other headsets (C and D)**.

Last-Come, First-Served

If a headset has multiple paired headsets for intercom conversations, the last paired headset is set as the first intercom friend.


Intercom Pairing Order

Last-Come, First-Served




Two-way Intercom


Start/End Conversation with the First Intercom Friend D



Start/End Conversation with the Second Intercom Friend C




Start/End Conversation with the Third Intercom Friend B




FM Radio


FM Radio On/Off




Start/Stop Scanning




Seek Forward



Seek Backward




Navigating Preset Stations



Note: You can save current station from the **Sena Device Manager** or the **SENA MOTORCYCLES App**.


Headset Configuration Menu

Accessing the Configuration Menu





"Configuration menu"

Navigating Between Menu Options



or




Execute Menu Options




Troubleshooting

Fault Reset















Note: Fault Reset will not restore the headset to the factory default settings.








Factory Reset
























Quick Reference





TYPE	OPERATION	BUTTON COMMANDS
<div><p>Basic Operations</p></div>	Power on / Power off	<div> </div> <div> </div>
	Volume up / Volume down	<div> or </div>
<div><p>Camera</p></div>	Camera On	<div> </div>
	Camera Off	<div> </div>
	Start/Stop recording	<div> </div>
	Taking Photos	<div> </div>

 <p>Mobile Phone</p>	Answer phone call	 
	End phone call	 
	Reject phone call	 
 <p>Siri and Google Assistant</p>	Activate the Siri or Google Assistant	 


 <p>Music</p>	Play/Pause music	 
	Track forward	 
	Track backward	 

 <p>FM Radio</p>	FM radio on/off	 
	Select preset	 
	Seek forward/backward	  or 
	Scan up FM band/stop scanning	 

 <p>Mesh Intercom™</p>	Mesh Intercom on/off	 
	Channel setting	 
	Mesh Grouping	 
	Reset Mesh	 
	Enable/Disable Mic	 

 <p>Intercom</p>	Intercom pairing	 
	Start/End intercom	 

www.sena.com

 <p>SENA</p> <p>50C MOTORCYCLE CAMERA & COMMUNICATION SYSTEM WITH MESH INTERCOM</p> <p>harman cardon</p> <p>QUICK START GUIDE</p>	<p>SENA 50C Motorcycle Camera and Communication System With Mesh Intercom [pdf] User Guide</p> <p>50C Motorcycle Camera and Communication System With Mesh Intercom, 50C, Motorcycle Camera and Communication System With Mesh Intercom, System With Mesh Intercom</p>
------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

References

-  [The Best Motorcycle & Action Sport Bluetooth Devices | Sena](#)