

**SENA**

**SP165 Single  
Compact Intercom**



# SENA SP165 Single Compact Intercom Instruction Manual

[Home](#) » [Sena](#) » SENA SP165 Single Compact Intercom Instruction Manual 

## Contents

- [1 SENA SP165 Single Compact Intercom](#)
- [2 Specifications](#)
- [3 Product Usage Instructions](#)
- [4 Music Operations](#)
- [5 Mesh Intercom](#)
- [6 Troubleshooting](#)
- [7 Phone Pairing](#)
- [8 FCC Statement](#)
- [9 FAQs](#)
- [10 Documents / Resources](#)
  - [10.1 References](#)

**SENA**


**SENA SP165 Single Compact Intercom**




## Specifications

- Model: 60S
- LED Indicators: Red for charging, Blue for fully charged
- Power On/Off: Press and hold Jog Dial and Phone Button
- Volume Adjustment: Rotate Jog Dial clockwise or counterclockwise
- Bluetooth Intercom Pairing: Press Jog Dial of two headsets for 5 seconds
- FM Radio On/Off: Press Phone Button for 1 second

## Product Usage Instructions



- Mesh Intercom antenna
- Headlight
- Headlight button
- Mesh Intercom button
- Status LED
- Dynamic motion LED
- Jog dial
- Speaker and microphone port
- Charging port
- Charging LED
- Phone button



## Charging

- Red LED: Charging
- Blue LED: Fully charged
- Power On/Off
- On: Press and hold the Jog Dial and Phone Button for 1 sec.
- Off: Tap the Jog Dial and Phone Button.
- Volume Adjustment
- Rotate the Jog Dial clockwise or counterclockwise

## Music Operations

- **Play or pause music:** Press and hold the Jog Dial for 1 second.
- **Track back/forward:** Rotate while pressing the Jog Dial clockwise or counterclockwise.

## Mobile Phone Call Making and Answering

- Answering a call: Tap the Phone Button.
- Ending a call: Press and hold the Phone for 2 seconds.
- Call a Voice Assistant: Tap the Phone Button.
- Rejecting a call: Press the Phone Button for 2 seconds.
- Speed dial:
  1. Enter into the Speed Dial: Double tap the Phone Button
  2. Navigate: Rotate the Jog Dial clockwise or counterclockwise.

3. Proceed: Tap the Phone Button.

## **Mesh Intercom**

- Mesh Intercom On: Tap the Mesh Intercom Button. Mesh Intercom Off: Tap the Mesh Intercom Button.
- Mute/Unmute the Mic: Press the Mesh Intercom Button for 1 second.

## **Channel Setting**

1. Enter the Channel Setting: Double tap the Mesh Intercom Button.
2. Navigate: Rotate the Jog Dial clockwise or counterclockwise.
3. Save the channel: Tap the Jog Dial Button.

## **Bluetooth Intercom**

- Intercom Pairing: Press the Jog Dial of both headsets for 5 seconds until red LEDs of both units start to flash rapidly.
- Intercom Start/End: Tap the Jog Dial.
- FM Radio On/Off: Press the Phone Button for 1 second.

## **Troubleshooting**

### **• Factory Reset**

1. Press the Jog Dial for 10 seconds.
2. Rotate the Jog Dial clockwise or counterclockwise until you hear the voice prompt, "Factory reset".
3. Tap the Phone Button.
4. Press the Jog Dial and Phone Button for 10 seconds.

## **Power On/Off**

To power on, press and hold the Jog Dial and Phone Button for 1 second. To power off, tap the Jog Dial and Phone Button.

## **Volume Adjustment**

Rotate the Jog Dial clockwise to increase volume or counterclockwise to decrease volume.

## **Phone Pairing**

1. To enter phone pairing mode:
  - First time turning on: Press and hold Jog Dial and Phone Button for 1 second.
  - When powered off: Press and hold Jog Dial and Phone Button for 5 seconds.
  - When powered on: Press and hold the Phone Button for 5 seconds.
2. Select the 60S in the list of detected devices on your phone.

## **FCC Statement**

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device under part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy, and, if not installed and used by the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment on and off, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and the receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

### **FCC RF Exposure Statement**

This equipment complies with FCC/IC radiation exposure limits set forth for an uncontrolled environment. End users must follow the specific operating instructions for satisfying RF exposure compliance. When equipped, the distance between the antenna and one's head surface is 47.4mm.

### **FCC Caution**

Any changes or modifications to the equipment not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

### **Industry Canada(IC) Statement**

This device complies with Industry Canada license-exempt RSS standard(s). Operation is subject to the following two conditions:

1. This device may not cause interference, and
2. This device must accept any interference, including interference that may cause undesired operation of

### **FAQs**

#### **How do I perform a factory reset?**

To perform a factory reset on the 60S ME:

1. Press the Jog Dial for 10 seconds.
2. Rotate the Jog Dial until you hear the voice prompt "Factory reset."
3. Tap the Phone Button to confirm.

#### **How do I pair Bluetooth Intercom with another headset?**

To pair Bluetooth Intercom with another headset:

1. Press the Jog Dial of both headsets for 5 seconds until red LEDs flash rapidly.
2. To start or end the intercom
3. Press the Jog Dial.

### **Documents / Resources**



[SENA SP165 Single Compact Intercom](#) [pdf] Instruction Manual  
S7A-SP165, S7ASP165, sp165, SP165 Single Compact Intercom, SP165, Single Compact Intercom, Compact Intercom

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.