



SENCOR SWS THS Remote Sensor User Manual

[Home](#) » [SENCOR](#) » SENCOR SWS THS Remote Sensor User Manual 

Contents

- 1 SENCOR SWS THS Remote Sensor
- 2 SWS TS , SWS THS
 - 2.1 REMOTE SENSOR for SWS WEATHER STATION
- 3 Documents / Resources
 - 3.1 References
- 4 Related Posts

SENCOR

SENCOR SWS THS Remote Sensor



SWS TS , SWS THS

REMOTE SENSOR for SWS WEATHER STATION

- When power is on, first signal of temperature and humidity (SWS THS only) will send out after 15 second. Then

automatic send signal of outdoor temperature and humidity (SWS THS only) every 58 second.

- Use “CH” to switch channel 1/2/3
- Press “TEST” to into test mode, this function for production only.
- Press “C/F” to switch Celsius temperature or Fahrenheit temperature.

Power supply : 2 x AAA alkaline battery (not included)

Radio frequency : 433 Mhz

Desktop or wall mountable

For details refer to main unit instruction manual.

The product has been designed and manufactured in accordance with the governmental regulation and relating standards

EN 55022:1998 + A1:2000 + A2 2003, EN 55024 : 1998 + A1:2001 + A2 2003.


The Conformity Declaration is available at : www.sencor.eu .

Disposal of Used Electrical & Electronic Equipment

The meaning of the symbol on the product, its accessory or packaging indicates that this product shall not be treated as household waste. Please, dispose of this equipment at your applicable collection point for the recycling of electrical & electronic equipment's waste. In the European Union and Other European countries which there are separate collection systems for used electrical and electronic product. By ensuring the correct disposal of this product, you will help prevent potentially hazardous to the environment and to human health, which could otherwise be caused by unsuitable waste handling of this product. The recycling of materials will help conserve natural resources. Please do not therefore dispose of your old electrical and electronic equipment with your household waste. For more detailed information about recycling of this product, please contact your local city office, your household waste disposal service or the shop where you purchased the product.

Changes in construction, design and specification are subject to change without notice.

Documents / Resources

	<p>SENCOR SWS THS Remote Sensor [pdf] User Manual SWS TS, SWS THS, SWS THS Remote Sensor, SWS THS, Remote Sensor, Sensor</p>
---	---

References

- [S Design and quality for you | Sencor](#)
- [S Design and quality for you | Sencor](#)