



SENSIRION SDP8xx Digital and Analog Pressure Sensor User Guide

[Home](#) » [SENSIRION](#) » SENSIRION SDP8xx Digital and Analog Pressure Sensor User Guide 

Contents

- [1 SENSIRION SDP8xx Digital and Analog Pressure Sensor](#)
- [2 Set-up](#)
- [3 Getting started with the Sensirion ControlCenter Software](#)
- [4 Documents / Resources](#)
 - [4.1 References](#)
- [5 Related Posts](#)

SENSIRION

SENSIRION SDP8xx Digital and Analog Pressure Sensor




Set-up

- Install the last version of the Sensirion ControlCenter Software from the website.
- Connect the sensor to a PC via the SEK-SensorBridge. The cable to connect the sensor with the SEK-SensorBridge is included in the evaluation kit.

Getting started with the Sensirion ControlCenter Software

- Start the ControlCenter Software.
- The sensor will be identified by the software automatically.
- 1 Select Config to adjust sampling rates, temperature compensation mode and displayed units.
- 2 Select Plot Settings to adjust the graph configurations.
- Press Start to run a measurement.



Please find all information about our differential pressure evaluation kits, including the required software, on our website: www.sensirion.com/ekdp

Thank you for your interest in our differential pressure sensors.

Sensirion AG

Laubisrütistrasse 50 · 8712 Stäfa · Switzerland · phone +41 44 306 40 00 · info@sensirion.com
www.sensirion.com

Documents / Resources



[SENSIRION SDP8xx Digital and Analog Pressure Sensor](#) [pdf] User Guide
SDP8xx, Digital and Analog Pressure Sensor, SDP8xx Digital and Analog Pressure Sensor

References

- [S Smart sensor solutions](#)
- [S Differential pressure evaluation](#)

Manuals+.