

SereneLife SLBSP10 Multi-Function Sound System User Manual

Home » serenelife » SereneLife SLBSP10 Multi-Function Sound System User Manual



Contents

- 1 SereneLife SLBSP10 Multi-Function Sound **System**
- **2 Product Information**
- 3 Packing list
- **4 Product Overview**
- 5 Charging
- **6 Connecting**
- 7 FAQ
- 8 Specification
- 9 Documents / Resources



SereneLife SLBSP10 Multi-Function Sound System



DEAR CUSTOMER

In order to achieve the best performance of your product, please read this instruction manual carefully before using, and keep it for future reference.

Product Information

• Product Name: MULTI-FUNCTION SOUND SYSTEM

• Model No.: SLBSP10

• Features: USB, TF, AUX-IN, Blue-connect, rechargeable battery, Volume+/-, Play/Pause, Previous/Next track

· Specification:

• Power output: 5W

• Input: DC 5V

Drivers: 3 Full Range +1 inch
Battery Capacity: 1000mAh
Transmission Distance: 10m

• **Dimension (WxHxD):** 136 x 136 x 250 mm

Note


This unit may be submitted to changes in specifications, characteristics and/or operation without prior notice to the user, in order to continue improving and developing its technology.

Packing list

Upon opening the package, please check for the following items:

- 1 x Speaker
- 1 x USB charging cable
- 1 x Audio cable
- 1 x Instruction manual
- 1 x strap

Product Overview



- 1. DC input
- 2. USB Slot
- 3. AUX-IN Slot
- 4. TF/MicroSD Card Slott
- 5. BT Indicator/Aux-in Indicator/Battery Indicator
- 6. Power ON/OFF Switch
- 7. Mode Button (Switch BT, USB disk, Micro TF, FM and Aux-in state)
- 8. Pevious track/ Volume Down Button
- 9. Play/Pause
- 10. Next track/Volume Up Button

Charging

There are two ways to charge the speaker

- 1. Plug the charging cable into speaker and connect to another USBC power source like PC/MAC, etc.
- 2. Use the AC adapter to charge. Please turn off the speaker when charging.

Indicator Status

Type	Indicator	State
BT indicator	Rapid flashing blue	Ready to link
	Steady-on blue	Linked
	Red	AUX-in mode
Battery indicator	Red light normally on	Charging
	Red light off	Fully charged

Features

USB, TF, AUX-IN, Blue-connect, rechargeable battery, Volume+/-, Play/Pause, Previous/Next track

Connecting

BT connection

Slide power key to ON position The speaker BT-connect indicator will flash in blue Search the BT device on your cellphone, select "SERENE LIFE" in the list BT indicator will stop flashing after the speaker is linked to the cellphone.

Connect to audio from the cellphone/Pad/Computer/Notebook/DVD/CD etc.

Plug one end of the audio cable into the speaker and the other end into a cellphone or other audio device.

FM Radio

- Press the "M" button to enter FM, the BT indicator will flash blue slowly.
- Press Play/Pause button to start channel auto-searching, the
- BT indicator will flash blue rapidly. Press Play/Pause button again to pause searching, the BT indicator will flash blue slowly.
- Press "M" button again to exit FM radio, the BT indicator will flash blue rapidly and BT is ready to pair.
- Under playing mode, short press: "Play/pause" button to auto search the FM Channel and store it automatically.
- Press Previous or Next button to change the stored FM channel.

FAQ

- Make sure the battery is full and the battery indicator light is on.
- Unable to connect to BT-enabled device

Make sure that the device is in BT mode, and is within 10 meters from the speaker. Ensure that neither the speaker nor the device is blue-connected to any other devices.

No sound heard

The volume is at its lowers, please turn up the volume.

Button doesn't work

Please press button longer

• The speaker has no response

Please power off and try again.

Specification

• Power output: 5W

• Input: DC 5V

Drivers: 3"Full Range +1 inch
Battery Capacity: 1000mAh
Transmission Distance: 10m

• **Dimension:** (WxHxD):136 x 136 x 250 mm

Documents / Resources



<u>SereneLife SLBSP10 Multi-Function Sound System</u> [pdf] User Manual SLBSP10 Multi-Function Sound System, SLBSP10, Multi-Function Sound System, Sound System

Manuals+,