



[Home](#) » [Setti plus](#) » **Setti Plus SC822 Rotating Camera Instruction Manual** 

Contents [[hide](#)]

- [1 Setti Plus SC822 Rotating Camera](#)
- [2 Product Usage Instructions](#)
- [3 TECHNICAL DATA](#)
- [4 WALL / CEILING INSTALLATION](#)
- [5 INSTALLATION AND OPERATION OF THE APP](#)
- [6 INSTALLING MEMORY CARD](#)
- [7 TROUBLESHOOTING](#)
- [8 Frequently Asked Questions](#)
- [9 Documents / Resources](#)
 - [9.1 References](#)



Setti Plus SC822 Rotating Camera



Product Usage Instructions

1. **Setting Up:** Unpack the camera and accessories. Follow the provided instructions to mount the camera securely.
2. **Powering On:** Connect the camera to the power supply using the included adapter.
3. **Connecting to Devices:** Install the required app on your Android or IOS device. Follow the app instructions to connect to the camera.
4. **Adjusting Settings:** Use the app to adjust camera settings such as motion detection, video recording resolution, and angle adjustment.
5. **Monitoring:** Access the live feed from the camera on your mobile device to monitor the desired area.

SAFETY AND HAZARD CONDITIONS

1. Do not start the device if it is damaged, if it is so the device must be repaired by the service or a person authorized to do so.
2. Due to safety concerns, only the manufacturer, a service authorized by the manufacturer or a person with appropriate qualifications can perform any repairs of the device.
3. Do not attempt to repair or interfere with the inside of the device.
4. This product may only be operated by children 8 years old or more, mentally and/or

physically deficient persons and persons without knowledge of or experience in the operation of this device type if supervised or instructed in safe operation, with a clear understanding of all related risks. Children should not play with the equipment.

Unsupervised children should not carry out maintenance and cleaning of the device.

5. Do not immerse the device in water or other liquids.
6. The device is not designed to protect property. For this purpose, one should seek a professional alarm system.
7. Ensure that local laws do not prohibit recording, storing, and editing video without the consent of the people being recorded.
8. Do not use the power adapter if its cable or housing is damaged.

FOREWORD

Thank you for the trust you have placed in us when you purchased your Setti+ device.

- We are convinced that a high-quality device will provide you with a lot of joy and satisfaction during its use.
- PLEASE CAREFULLY READ AND FOLLOW THE OPERATING MANUAL!
- This device is intended for domestic or similar, non-commercial use. The manufacturer will not be held liable for damages resulting from improper or non-compliant use.


TECHNICAL DATA

Camera model	SC822
Power supply	5.0V 2.0A
Angle adjustment range	355° horizontal, 160° vertical
Protection rating	IP20
Video recording resolution	1920 x 1080
Operating temperature range	-10to0 +50°C
Power input	USB-C

Accessories	Camera, power adapter, installation accessories
Motion detection range	5 m
System requirements	Android, IOS
Supported memory cards	Micro SD, up to 128 GB
Frequency of transmission Frequency range	5 GHz 5745 – 5825 MHz
Maximum transmission power	<10 dBm


Power supply model	SC822
Input voltage	100-240V~
Input current	0.3A
Input AC frequency	50/60Hz
Output voltage and current	5V 2A, 10W
Average operating efficiency	79.59%
Low load efficiency (10%)	–
No-load power consumption	0,069W

DEVICE DESCRIPTION



WALL / CEILING INSTALLATION

1. Place the bracket against the wall and mark the locations of the holes to be drilled.
You can also use the auxiliary template from the set.
2. Drill holes matching the diameter of the mounting plug, and put the plugs in the holes.
3. Place the mounting bracket against the wall, insert the screws into the bracket holes and screw into the plugs, securing the bracket to the wall.



- PLEASE NOTE! IF THE BRACKET IS NOT SECURELY FIXED, REMOVE IT AND RE-INSTALL IT BY THE INSTALLATION INSTRUCTIONS.
- PLEASE NOTE! INSTALL THE CAMERA IN A ROOFED SPACE AND AVOID

HEAVILY SUNLIT AREAS.

START-UP

1. Connect the USB-C cable plug to the power socket, and the USB-A plug to the power adapter socket, then connect the power adapter plug to the mains.
2. After a correct connection, the LED indicator will illuminate. After about a minute, the camera will perform test movements and emit a voice message that it is ready to set up with a Wi-Fi network, then the LED indicator will start flashing.

INSTALLATION AND OPERATION OF THE APP

1. Download the Setti+ app from the site by scanning the QR code:



w aplikacji Google Play
wyszukaj Setti+



w aplikacji App Store
wyszukaj Setti+.

2. Open the installed application.
3. As a new user, create a new account. If you have an account, log in using your own access data.
4. Start the device by connecting the power adapter to the electrical outlet, and the cable plug to the power input of the camera. The camera will perform a test move, then the LED will start flashing.
5. In the upper right corner of the application, press the „+” button and select the appropriate device: Security, SS822 Camera.
6. Make sure the LED flashes quickly to indicate the configuration mode.
7. Select the Wi-Fi network (2.4GHz), enter the password and confirm it with the „Next” button.
8. A QR code will be displayed on your phone screen. Point the camera lens towards the phone screen to scan the code. After hearing a beep, confirm with the button „I heard a sound.”
9. After successfully connecting the device, you can fully enjoy its remote operation.

A detailed operating manual for the control application is available at:
<https://setti.pl/wsparcie/aplikacja> or after scanning this QR code:

INSTALLING MEMORY CARD

To install a microSD memory card (128 GB max):

1. Set „Private Mode” in the app – the camera will rotate the lens down, exposing the memory card slot.
2. Slide the card into the slot as marked, press and lock.

CLEANING

- The device should be regularly inspected and cleaned. Use a softly damp cloth for cleaning.
- PLEASE NOTE! DO NOT USE CHEMICALS OR ABRASIVES FOR CLEANING.

STORAGE

1. If the device is not to be used, the power adapter must be unplugged from the power socket.
2. Store the appliance in a dry, safe place away from children.

TROUBLESHOOTING

PROBLEM	POSSIBLE CAUSE	SOLUTION
An acoustic signal was triggered.	The camera was not configured correctly with Wi-Fi, or was disconnected.	Configure the camera with the home network, according to the „Installation and operation of the app” section.

It is not possible to configure Wi-Fi network in the camera.	There was a problem with the Wi-Fi connection.	Check that the Wi-Fi signal of the router is of correct strength.
The camera does not respond to changes in the application.	There was a problem with the Wi-Fi connection.	Check that the Wi-Fi signal of the router is of correct strength.
	The camera is too far away from the Wi-Fi signal source.	Boost the Wi-Fi signal of the router or reduce the distance between the camera and the router.
	The router configuration has been changed.	Reconfigure the camera with the home network according to the section „Installation and operation of the app”.

DECLARATION

ART-DOM Sp. z o.o. Hereby declares that the SC822 camera complies with the relevant requirements of the Union harmonisation legislation: Directive 2014/53/EU and other Union harmonisation legislation. The full text of the EU declaration of conformity is available at the following address: www.artdom.net.pl/deklaracja/SC822/

ECO-FRIENDLY AND ENVIRONMENTALLY FRIENDLY DISPOSAL

This device is marked by Directive 2012/19/ EU of the European Parliament and of the Council of 4 July 2012 on waste electrical and electronic equipment (WEEE), with the symbol of a crossed-out waste container:

- Do not dispose of the device marked with this symbol together with household waste.
- For disposal, return the device to your local waste treatment and disposal facility or contact your local authorities. YOU CAN HELP PROTECT THE ENVIRONMENT!
- Proper handling of waste electrical and electronic equipment contributes to avoiding harmful consequences for human health and the environment, resulting from the presence of hazardous components and improper storage and processing of such

equipment.

WARRANTY CONDITIONS FOR THE INTERNAL CAMERA

1. ART-DOM Sp. z o.o. with its registered office in Łódź (92-402) at ul. Zakładowa 90/92 National Court Register Number 0000354059 (Guarantor) guarantees that the purchased device is free from physical defects. The warranty covers only defects resulting from the causes inherent in the item sold (manufacturing defects).
2. A disclosed defect will be removed at the Guarantor's expense within 14 days from the date of reporting the damage to the authorized service or point of sale.
3. In exceptional cases, e.g. the need to import spare parts from their manufacturer, the repair period may be extended up to 30 days.
4. The warranty period for the user is 24 months from the date of delivery of the goods.
5. The goods are intended for use only in the conditions of an individual household.
6. The present warranty does not cover:
 1. damage caused by using the device in a manner inconsistent with the user manual,
 2. mechanical, chemical or thermal damage,
 3. repairs and modifications made by companies or persons that were not authorised to do so by the manufacturer,
 4. parts that are easily worn or consumables such as: batteries, bulbs, fuses, filters, knobs, shelves, accessories,
 5. installation, maintenance, inspection, cleaning, unlocking, removal of contaminants and instruction.
7. The Guarantor will select the mode of defect removal at its discretion. Removal of a confirmed defect of the device will take place through warranty repair or replacement of the device. The Guarantor may perform repairs when the Buyer requests replacement or the Guarantor may perform replacements when the Buyer requests repair, if bringing the goods (device) into conformity with the granted warranty in the manner selected by the buyer proves impossible or would require excessive costs on the part of the Guarantor. In particular, justified cases, if both repair and replacement are impossible or would require excessive costs for the Guarantor, the Guarantor may refuse to bring the goods into compliance with the granted warranty and propose another way to settle the warranty claim.

8. The exchange of goods is made at the point of sale at which the goods were purchased (replacement or refund) or an authorized service point, if it offers such service (replacement). The returned device must be complete, without mechanical damage. Failure to comply with these conditions may fail to accept the warranty claim.
9. In the event of non-compliance of the goods with the sales contract, the buyer is entitled by law to legal protection measures on the part and at the expense of the seller, and the warranty does not affect these legal protection measures.
10. The warranty is valid in Poland.
11. The condition for the warranty repair or replacement of the device is the presentation of proof of purchase and the use of the goods by the information contained in the user manual.

CAUTION

Damage or removal of the rating plate from the device may result in the warranty being deemed void.

- We are constantly improving our products, so they may differ slightly from the images presented on the packaging and in the user manual. Please read the user manual before operating the appliance.

Frequently Asked Questions

Q: Can children use this camera?

A: The camera can be used by children aged 8 and above under supervision.


Q: What is the maximum supported memory card size?

A: The camera supports microSD cards up to 128 GB.

Q: Is the camera suitable for outdoor use?

A: The operating temperature range is not specified, so it is recommended to use it in indoor environments unless otherwise stated by the manufacturer.

Documents / Resources



KAMERA
OBROTOWA
SC822
Wideo 1080p
Wideo 720p
SC822
ROTATING
CAMERA
Wideo 1080p
& Wideo 720p

[Setti Plus SC822 Rotating Camera \[pdf\]](#) Instruction Manual
SC822 Rotating Camera, SC822, Rotating Camera, Camera

References

- [User Manual](#)

Setti
plus

camera, Rotating Camera, SC822, SC822 Rotating Camera, Setti
plus

Leave a comment

Your email address will not be published. Required fields are marked *

Comment *

Name

Email

Website

☐ Save my name, email, and website in this browser for the next time I comment.

[Post Comment](#)

Search:

[Search](#)

[Manuals+](#) | [Upload](#) | [Deep Search](#) | [Privacy Policy](#) | [@manuals.plus](#) | [YouTube](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.