


## SEVENFRIDAY P3C-04 Automatic Watch Instructions

[Home](#) » [SEVENFRIDAY](#) » SEVENFRIDAY P3C-04 Automatic Watch Instructions 

*SEVENFRIDAY P3C-04 Automatic  
Watch Instructions*

### INSTRUCTIONS - **DISPLAY**

P1C/04, P3C/02, P3C/03, P3C/04, P3C/07, P3C/08, P3C/09



**AUTOMATIC MOVEMENT . MIYOTA 82S7- MADE IN JAPAN 10ATM/100M WATER RESISTANT**

## Contents

[1 WINDING THE MAINSPRING](#)

[2 SETTING THE TIME](#)

[3 TIME READING](#)

[4 Documents / Resources](#)

[5 Related Posts](#)

## WINDING THE MAINSPRING

Unscrew the crown, until you hear a click (position 1 ). Automatic winding watch can also be hand winded by turning the crown clockwise in position 1. Wind 15-20 times and it will start to move, after slightly shaking.

## SETTING THE TIME

1. Unscrew the crown, until you hear a click.
2. After hearing the click, pull out the crown.
3. Adjust the time, by rotating the crown upwards or downwards.
4. After the time has been set, push the crown back and screw it into normal position.

## TIME READING

## DISPLAY

## EXAMPLE 1



10:31:20

HOURS: 10AM

MINUTES: 31MIN

SECONDS: 20s

## EXAMPLE 2




6:10:40

HOURS: 6PM

MINUTES: 10MIN

SECONDS: 40s

## Documents / Resources



[SEVENFRIDAY P3C-04 Automatic Watch](#) [pdf] Instructions  
P3C-04 Automatic Watch, P3C-04, Automatic Watch