



SG Lighting Zip 230V 1 Circuit Rail System Instruction Manual

[Home](#) » [SG Lighting](#) » SG Lighting Zip 230V 1 Circuit Rail System Instruction Manual 

Contents

- [1 SG Lighting Zip 230V 1 Circuit Rail System](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Mounting Instruction](#)
- [5 Documents / Resources](#)
- [6 Related Posts](#)



SG Lighting Zip 230V 1 Circuit Rail System



Product Information



- **Product Name:** Zip 230V
- **IP Rating:** IP20
- **Input Voltage:** 220-240V
- **Maximum Current:** 10A
- **Dimensions:** 1150mm x 2000mm
- **Number of Sheets:** 2
- **Revision:** 02.05.2022
- **Maximum Power:** 6.5W
- **Lamp Type:** GU10
- **Frequency:** 50-60Hz

Product Usage Instructions

1. Ensure that the input voltage is within the range of 220-240V.
2. Connect the Zip 230V to a suitable power source using the provided central connector.
3. Make sure the product is installed in a location with an IP20 rating to protect it from solid objects larger than 12mm.
4. Insert a GU10 lamp with a maximum power rating of 6.5W into the designated socket.
5. Turn on the power source to activate the Zip 230V.
6. Check that the product is functioning properly and emitting light.
7. If any issues arise, refer to the user manual for troubleshooting steps or contact the manufacturer's support for assistance.

Please note that these instructions are a general guideline, and it's important to refer to the specific user manual provided with the product for detailed instructions and safety precautions.

Mounting Instruction



NORWAY

SG Armaturen AS
 Skytterheia 25
 N-4790 Lillesand
 Tel: +47 37 50 03 00
www.sg-as.no

SWEDEN

SG Armaturen AB
 Tel: +46 31 81 71 10
info@sg-ab.se
www.sg-ab.se

FINLAND

SG Armaturen Oy

Tel: +358 02 07 30 39 60

www.sg-oy.fi

DENMARK

SG Armaturen A/S

Tel: +45 70 70 72 13

info@sg-as.dk

www.sg-as.dk

UNITED KINGDOM SG Lighting LTD

Tel: +47 37 50 03 00

info@sglighting.co.uk

www.sglighting.co.uk

FRANCE

SG Lighting SA/NV

Tel: +33(0) 4 94 93 00 00

info.france@sglighting.fr

www.sglighting.net

BENELUX

SG Lighting SA/NV

Tel: +32(0) 15 20 72 71

info.benelux@sglighting.net

www.sglighting.net

GERMANY

SG Leuchten GmbH

Tel: +49 40 23 99 44 59

info@sg-leuchten.de

www.sg-leuchten.de


INTERNATIONAL


SG Lighting Co Ltd.

Tel: +86 769 88 49 20 88


cindy@sgdgc.com

www.sg-as.com






Max. 6.5W
GU10
50-60Hz



- Only to be installed and maintained by an authorized electrician.
- Turn off power before installing.
- It is the user's responsibility to ensure electrical, mechanical and thermal compatibility between the track system and luminaires attached to it.

Documents / Resources



[SG Lighting Zip 230V 1 Circuit Rail System](#) [pdf] Instruction Manual
70 210, 3001, 3003, Zip 230V, Zip 230V 1 Circuit Rail System, 1 Circuit Rail System, Rail System, System