



## Shaanxi Depin Trading HW256 Wireless Keyboard and Mouse User Manual

[Home](#) » [Shaanxi Depin Trading](#) » Shaanxi Depin Trading HW256 Wireless Keyboard and Mouse User Manual 

### Superbcco HW256 Wireless Keyboard and Mouse



### User's Manual

Thank you for purchasing Superbcco 2.4Ghz Wireless Keyboard and Mouse. Each unit has been manufactured to ensure safety and reliability with life-time warranty. Before using for the first time. please read the instructions carefully and keep them for further reference.

## Contents

### 1 PACKAGE CONTENTS

### 2 HOW TO PAIR

### 3 SETTING UP YOUR WIRELESS KEYBOARD AND MOUSE

#### 3.1 INDICATOR LIGHTS

#### 3.2 KEYBOARD SPECIFICATION

#### 3.3 FUNCTION KEYS

#### 3.4 TROUBLESHOOTING

#### 3.5 LIFETIME WARRANTY

### 4 Documents / Resources

### 5 Related Posts

## PACKAGE CONTENTS

- 1\*Wireless Keyboard and Mouse
- 1\*USB Receiver (stored inside the keyboard; plug it into your computer)
- 2 \*AAA-Type Batteries for the Mouse (included)
- 2\*AAA-Type Batteries for the Keyboard (included)
- 1\*Environment-Friendly Transparent Silicone Keyboard Cover
- 1\* User Manual

**Note:** for Macbook, iPhone, iPad & Android phones, tablets, it can work via a USB dongle/OTG.

## HOW TO PAIR

Normally keyboard and mouse have already been paired before delivery. Please follow the below steps in case they are disconnected.

Keyboard Paring: Switch your keyboard off first. pluck the USB receiver out. and then turn your keyboard on and quickly press “Esc’ + “k” or “Esc” + “q”. Plug the USB receiver into your computer when the indicator starts flashing Reconnection is done when the indicator light turns off (Please place keyboard close to USB receiver when paring).

Mouse Paring: Switch your mouse off first. pluck the USB receiver out. and then replug it into your computer. Press and hold “Right Click” first and then keep pressing “Scroll Wheel”. and switch the mouse on. Reconnection is done after 3-5 seconds.

## SETTING UP YOUR WIRELESS KEYBOARD AND MOUSE

1. Install two AM batteries in your keyboard and two MA batteries in your mouse (**Note:** batteries+/-ends should follow those indicated on the battery compartment label).
2. Connect the 2.4 GHz USB receiver to the computer (Please note that this combo only needs one USB receiver for both keyboard and mouse, and the USB receiver is inserted inside the keyboard, not inside the mouse).  
Warning: plug the USB receiver into the USB 2.0 port (usually the black one) not the USB 3.0 the blue one; this is due to USB 3.0 radio frequency interfering with the 2.4GHz wireless device, and not properly plug-in may lead to mouse lagging or freezing problems. Sometimes the black one can also be USB 3.0
3. Flip the power switches on (Note: keyboard and mouse has their own independent POWER ON/OFF switch, located on their back. Flipping them off for energy saving when not in use. The keyboard and mouse have already been successfully paired before delivery and thus simply plug and play).

## INDICATOR LIGHTS



Low Power Alarm:



Flashing red 3 times per second.



Indicate Whether Caps Lock Is On or Off:

**CPS** Press Caps Lock once to type all letters as uppercase. Press Caps Lock again to turn it off.



Indicate Whether Num Lock Is On or Off:

















**NuM** To use the numeric keypad to enter numbers, press Num Lock. When Num Lock is off, the numeric functions as a second set of navigation keys.

## KEYBOARD SPECIFICATION

Transmission Distance	10mV3311	Keystroke Force	60±10g
Modulation Mode	GFSK	Keystroke bounce°	3 Won
Working Current	3M	Standby Current	0.3-1.5mA
Sleep Mode Current	<EVA	Battery	4 AAA (included)
Working Temperature	-10 – +55°C -14 – +122°F		

## FUNCTION KEYS

Key Icon	Windows System Function	Wins FN+Function Keys
	ESC	Fn•Key Lock
	F1	Mute
	F2	Volume Down
	F3	Volume Up
	F4	Previous Song

	F5	Play/Pause
	F6	Next Song
	F7	Brightness
	F8	Brightness •
	F9	Calculator
	F10	Search
	F11	Setup
	F12	Device Sharing
FN + 		Move to the <b>top of a webpage</b>
FN + 		Page <b>up</b> one screen
FN + 		Page down one screen
FN + 		Move to the <b>bottom</b> of a webpage

DELETE Key: please select the object first and then press delete to make the DELETE key work: Backspace key works as direct delete as well.

Screenshot for MAC: Command Key=Win on this keyboard Full-Screen Shot: Command+Shift+3 Area Screen Shot: Command+Shift+4

## TROUBLESHOOTING

Common Symptoms	What You Experience	Possible Solutions
Unable to use the keyboard	No response when typing on the keyboard or mouse	1. Check if the batteries are inserted correctly (Batteries + and – must follow the battery compartment label)
		2. Check if the keyboard or mouse power switch is set to ON
		3. Remove & reinsert batteries
		4. Remove and reconnect the USB receiver on your computer
		5. Restart your computer.
Mouse problems	Mouse lagging or no response	6. Battery is out of power and needs to be recharged
		7. Clean the surface of the mouse sensor.
		8. Try it on another computer.
		9. Contact us for a replacement if the mouse is defective.

## LIFETIME WARRANTY

Superbco warrants this product to be free from manufacturing defects for a lifetime warranty from the original date of consumer purchase.

This warranty is limited to the repair or replacement of this product only and does not extend to consequential or incidental damage to other products that may be used with this unit.

## TECHNICAL SPECIFICATIONS

Item Name	Wireless Keyboard and Mouse Combo HW2511	Battery	4 W Bader ieS included)
Material	<b>ABS</b>	Number of Keys	<b>96</b>
Interlace	US8 2.0	Hotkeys	12
Transmission Distance	IOrrV33/1	Features	%Viceless, Ultra-Slim, Plug, and Play
Operation Voltage	Sy	Optical Resolution	8001120011600 DPI
Service Time	<20mA	Mouse Size	10.1cm x 7.5cm x 2.3cm 2.4" x 4.2" x 0.9" (IS)
Operation Current	23 Million Strokes	Keyboard Size	30cm x 12.1cm x 2.1cm 4.7" x 4.6" x 0.8" (414,02.)
Colors	Avocado Green/Baby Pink/Pearl White/Midnight Black		
Supported operating Systems	Microsoft Windows 10/97/xP/Vista/Server 2003/Server 2008/ Server 2012, Ubuntu, Naokylin. Free DOS. Chrome and Android (for Mac, use a USB dongle to Make it work)		

#### COMPANY ADDRESS

#### SHAANXI DEPIN TRADING CO., LTD


Room 705, Building No. 2, Internet Industry Land, Weibing South Road  
No. 1, Garden Road Zone, Qiaonan Street Work Station, Weibing  
District, Baoji City, Shaanxi Province 721000

#### CONTACT US

Official Website: [www.de-pin.com](http://www.de-pin.com)

Email: [info@de-pin.com](mailto:info@de-pin.com)

#### Documents / Resources

	<a href="#">Shaanxi Depin Trading HW256 Wireless Keyboard and Mouse</a> [pdf] User Manual HW256, 2A4LM-HW256, 2A4LMHW256, HW256 Wireless Keyboard and Mouse, HW256, Wireless Keyboard and Mouse
---	--