



Shark ZS360 Series APEX Stick Vacuum User Manual

[Home](#) » [Shark](#) » Shark ZS360 Series APEX Stick Vacuum User Manual 

Contents

- 1 Shark ZS360 Series APEX Stick Vacuum User Manual
- 2 WHAT'S INSIDE:
 - 2.1 ASSEMBLY
- 3 DUOCLEAN® TECHNOLOGY
- 4 VERSATILE FLOOR-TO-CEILING CLEANING
- 5 STORAGE
- 6 MAINTENANCE
 - 6.1 Brushroll/Soft Roller Access
 - 6.2 Brushroll Maintenance
 - 6.3 Empty the dust cup every time debris reaches the MAX fill line.
 - 6.4 Cleaning the Soft Roller
 - 6.5 Checking the Nozzle for Blockages
- 7 HAVING TROUBLE?
- 8 DOWNLOAD
- 9 Related Posts

Shark ZS360 Series APEX Stick Vacuum User Manual



ZS360 Series QUICK START GUIDE

[Please be sure to read the enclosed Shark® Owner's Guide prior to using your unit.]


Use this Quick Start Guide to start using your new vacuum's great features.

Register your vacuum at [registeryourshark.com](https://www.registeryourshark.com)


For additional parts and accessories, visit [sharkaccessories.com](https://www.sharkaccessories.com)

WHAT'S INSIDE:

- A. Handheld Vacuum
- B. Motorized Floor Nozzle
- C. Wand
- D. 5" Crevice Tool
- E. Pet Multi-Tool



ASSEMBLY



DUOCLEAN® TECHNOLOGY


ON FLOORS

Direct engagement with the Soft Roller removes large particles, small particles, and stuck-on dust.

Setting I: Bare Floor/Small Area Rugs

Gentle on bare floors and small area rugs.

The brushrolls will spin slowly to help with debris pickup.




ON CARPETS*

The Soft Roller pulls in large particles, while the deep-cleaning brushroll removes embedded fine dirt.

Setting II: Carpet

Optimized brushroll speed for carpets.

The brushrolls will spin faster to help pick up debris below the surface.




* For deep cleaning per ASTM F 608 (embedded dirt in carpet) please use Setting II, Carpet.

VERSATILE FLOOR-TO-CEILING CLEANING

UPRIGHT MODE


To clean floors, place foot on floor nozzle and tilt handheld vacuum back.



NOTE: All accessories are compatible with both the wand and the handheld vacuum. Use Setting I, Bare Floor/Small Area Rugs, with all above-floor accessories.


ABOVE-FLOOR WITH WAND

Stand the vacuum upright. Step on the foot pedal on the bottom left side of the floor nozzle and pull the wand up to disconnect it. Great for cleaning baseboards, ceiling fans, window sills, etc.



ABOVE-FLOOR WITH HANDHELD


Press the Wand Release button and lift the handheld vacuum off the wand. Great for cleaning stairs and furniture.



STORAGE

ONBOARD HOOK

Hang the handheld vacuum on the hook on the bottom of the wand, and wrap the power cord around the cord hooks.



MAINTENANCE


Brushroll/Soft Roller Access

1. To open the brushroll garage, slide both release buttons on the floor nozzle away from you, towards the back of the nozzle, then lift off the lid.
2. To close the brushroll garage, insert the 3 tabs on top of lid into the 3 slots in the nozzle, then push down on both sides of lid until it clicks securely into place. If Brushroll Indicator Light isn't green and headlights are flashing, check again that both sides of lid are locked in place.




Brushroll Maintenance

With the garage lid removed, carefully clear away any debris that may be impeding the brushroll.




NOTE: If you see any hair wrapped around the brushroll, continue cleaning, using Setting II, Carpet, on bare floors. This will allow Zero-M™ technology to remove the hair wrap and send it to the dust cup.

Empty the dust cup every time debris reaches the MAX fill line.




Cleaning the Soft Roller

Lift out the Soft Roller by pulling the tab on the right side. Clear away any debris, then slide the Soft Roller back into place.



Checking the Nozzle for Blockages

Tilt neck of nozzle back to straighten the airway, then remove any blockages.



HAVING TROUBLE?

ISSUE: Vacuum lifts area rugs.

Solution: Turn off the unit to disengage the brushroll and restart with the Power button.

ISSUE: Vacuum is not picking up debris. No suction or light suction.

Solution: Empty dust cup, clean filters, check all openings for blockages.

For questions or to register your product, visit us online at sharkclean.com

Operating LLC. ZERO-M is a trademark of SharkNinja Operating LLC.

ZS360_QSG_MP_Mv6

DOWNLOAD

Shark ZS360 Series APEX Stick Vacuum:

Quick Start Guide – [[Download PDF](#)]

Owner's Guide – [[Download PDF](#)]
