

# **Shark SonicScrub Mop User Guide**

Home » Shark » Shark SonicScrub Mop User Guide The shark sonicScru





**STEAM** SonicScrub Mop™ **QUICK START GUIDE** 


## **Contents**

- 1 ASSEMBLY
- **2 WHAT'S INSIDE**
- **3 FILLING THE WATER**

#### **TANK**

- **4 ATTACHING THE PADS**
- **5 REMOVING THE PADS**
- **6 USING THE STEAM MOP**
- 7 Documents / Resources
  - 7.1 References
- **8 Related Posts**

#### **ASSEMBLY**



1. Insert the steam mop handle into the steam mop body until it clicks securely into place.


# WHAT'S INSIDE

A Steam Mop Handle


B Steam Mop Body

C Dirt GripTM Pads

D Filling Flask



## **FILLING THE WATER TANK**




- 1. To open the water tank, pull the lid down.
- 2. Use the filling flask to pour water into the tank. Make sure not to exceed the Max Fill Line on the flask. When finished, close the tank lid firmly.


Please be sure to read the enclosed Shark® Owner's Guide prior to using your unit.

### **DIRT GRIP PADS**

### ATTACHING THE PADS




- 1. Place the Dirt Grip pads flat on the floor with the plastic rings facing up.
- 2. Hold the nozzle over the pads. Align the indent on the nozzle's rotating discs with the plastic rings on the pads.



3. Gently lower the nozzle onto the pads, pressing until the pads are secured.


# **REMOVING THE PADS**


When the pads have cooled completely, remove them by gently pulling them off the discs.



#### **USING THE STEAM MOP**

- 1. Twist the quick-release cord holder to unwrap the power cord completely, and plug the cord into an electrical outlet. The steam mop power light will illuminate.
- 2. Press the mode button once for NORMAL or twice for DEEP.
- 3. Mop with a forward and backward motion.
- 4. When finished mopping, press the mode button and the blue indicator lights will blink, indicating that the unit is in Standby Mode, and the rotating discs will stop spinning. When the mop is in Standby mode, lift the handle to bring the Steam Mop back to the upright position and unplug the cord.





For questions or to register your product, contact us at 800-798-7398 or visit us online at <a href="mailto:sharkclean.com">sharkclean.com</a>



### **Documents / Resources**



<u>Shark SonicScrub Mop</u> [pdf] User Guide SonicScrub Mop, Shark

### References

• S Vacuum Cleaners, Steam Mops, Hair Care & Air Purifiers | Shark Home Cleaning

Manuals+,