

SHARP 4T-C65FV1X LED Backlight TV Installation Guide

Contents

- 1 4T-C65FV1X LED Backlight TV
- 2 A Q U O S
 - 2.1 Initial setup guide
 - 2.2 A. Supplied accessories
 - 2.3 B. Inserting the batteries
 - 2.4 CAUTION
 - 2.5 C. Attaching the stand
 - 2.6 C. Attaching the stand (Continued)
 - 2.7 C. Attaching the stand (Continued)
 - 2.8 6. Install the stand cover.
 - 2.9 C. Attaching the stand (Continued)
 - 2.10 When removing the stand
 - 2.11 Dear SHARP customer
 - 2.12 Important Safety Precautions
 - 2.13 Precautions when transporting the TV
 - 2.14 Initial installation
 - 2.15 Terminal Diagram
 - 2.16 Viewing E-Manual
 - 2.17 Appendix
 - 2.18 ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.
 - 2.19 CAUTION
 - 2.20 Dimensional Drawing
- 3 SHARP
- 4 SHARP
- 5 Documents / Resources
 - 5.1 References
- 6 Related Posts

4T-C65FV1X LED Backlight TV

SHARP

4T-C65FV1X



TINS-H724WJN1

<https://global.sharp/restricted/support/aquos/emanual/asia/pdf/fv/android11/index.html>

Please scan the code above to access PDF E-Manual. The networks of the internet charges will be applied.

AQUOS











LED BACKLIGHT TV

Initial setup guide

Please read Important safety precaution before setting up the TV.




A. Supplied accessories


<p>① Remote control unit (× 2)</p> <p>Type A</p>  <p>Type B</p> 	<p>② "AAA" size battery (× 4)</p> 	<p>③ Initial setup guide</p> 
<p>Stand unit</p> <p>④ Stand mounting bracket (× 1)</p>  <p>⑦ Stand cover (× 1)</p> 	<p>⑤ Stand base (× 1)</p>  <p>⑧ Swivel lock screw (× 1)</p> 	<p>⑥ Screws (× 8)</p>  <p>⑨ AC cord (× 1)</p> 

B. Inserting the batteries

Remote control unit (Type A)




Remote control unit (Type B)



CAUTION


Batteries (battery pack or batteries installed) shall not be exposed to excessive heat such as sunshine, fire or the like.

C. Attaching the stand




C. Attaching the stand (Continued)

1. To insert stand mounting bracket to stand base.




2. Fix the stand mounting bracket and the stand base with four screws for assembling the stand.




3. Take out the TV.

1) Peel off the tape on the TV screen side and slide the bag down.



2) Do not remove the screen protection pad until the TV installation is complete.



C. Attaching the stand (Continued)

4. Attach the display part to the stand mounting bracket in an upright position.


- Be careful not to get your fingers caught between the display part and the stand mounting bracket.

5. Fix the TV and stand base with four screws provided.

- When installing the TV and the stand mounting bracket, please tighten it.
- After fixing, please shake to confirm whether all the screws are tightened.
- After the installation is complete, if you find that the TV is tilted, please loosen the screws slightly to make the TV shift to the horizontal, and then tighten the screws again.

6. Install the stand cover.

- Align the 3 raised parts above the stand cover with the recessed parts of the TV to install.




Complete the above steps to end the “Attaching the stand”.

CAUTION Adjust the TV screen angle (Be careful not to caught your hands)

Be careful not to tip the TV over when turning the TV screen.

Also, be careful of caught your hands.

The adjustable range for left and right is about 15 degrees.



When turning the TV screen, be careful not to press the TV screen or the corners too hard. This may break the TV screen, resulting in injury.


C. Attaching the stand (Continued)

When you want to fixed the screen in front

Use the supplied swivel lock screws to fix it.

With the screen facing the front, align the screw holes with the stand holes and attach the screws

Secure it with flathead screwdriver.




When removing the stand

When moving the unit, remove the stand by following the steps in “Attaching the stand” in reverse order.

When removing the stand cover, lift the arrow part shown in the figure below and remove it.

If you are using the swivel lock screws, remove the screw before removing the stand cover.



Do not place the TV screen face down, as it may cause damage to the TV screen, etc., resulting in injury.

Dear SHARP customer

Thank you for your purchase of the SHARP LCD colour TV product. To ensure safety and many years of troublefree operation of your product, please read the Important Safety Precautions carefully before using this product.

Important Safety Precautions

- Stand base must be attached to prevent the TV set from falling down and cause injuries.
- Cleaning — Unplug the AC cord from the AC outlet before cleaning the product. Use a soft damp cloth to clean the product. Do not use liquid cleaners, aerosol cleaners or chemical cloth to clean it, as such materials may damage the product.
- Water and moisture — Do not use the product near water, such as bathtub, washbasin, kitchen sink, laundry tub, swimming pool and in a wet basement.
- Do not place vases or any other water-filled containers on this product. The water may spill onto the product causing fire or electric shock.
- Stand — Do not place the product on an unstable cart, stand, tripod or table. Doing so can cause the product to fall, resulting in serious personal injuries as well as damage to the product. Use only a cart, stand, tripod, bracket or table recommended by the manufacturer or sold with the product. When mounting the product on a wall, be sure to follow the manufacturer's instructions. Use only the mounting hardware recommended by the manufacturer.
- When relocating the product placed on a cart, it must be moved with utmost care. Sudden stops, excessive force and uneven floor surface can cause the product to fall from the cart.
- Ventilation — The vents and other openings in the cabinet are designed for ventilation. Do not cover or block these vents and openings since insufficient ventilation can cause overheating and/or shorten the life of the product. Do not place the product on a bed, sofa, rug or other similar surface, since they can block ventilation openings. This product is not designed for built-in installation; do not place the product in an enclosed place such as a bookcase or rack, unless

proper ventilation is provided or the manufacturer's instructions are followed.

- The LCD panel used in this product is made of glass. Therefore, it can break when the product is struck forcefully or with a sharp object. If the LCD panel is broken, be careful not to be injured by broken glass.
- Heat sources — Keep the product away from heat sources such as radiators, heaters, stoves and other heat-generating products (including amplifiers).
- To prevent fire, never place any type of candle or naked flames on the top or near the TV set.
- To prevent fire or shock hazard, do not place the AC power cord under the TV set or other heavy items.
- Do not place heavy objects on this product or stand on it. Doing so could cause injury if the product overturns. Take special care near children and pets.
- The LCD panel is made with extremely high precision technology, and has 99.99% or more effective pixels. The 0.01% or less missing pixels or those that are always lit is not a malfunction.

Precautions when transporting the TV

When transporting the TV, never carry it by holding or otherwise putting pressure onto the display. Be sure to always carry the TV by two people holding it with two hands — one hand on each side of the TV.

- Do not display a still picture for a long time, as this could cause an afterimage to remain.
- Install the product on the place where the AC cord can be unplugged easily from the AC outlet or from the AC INPUT terminal on the rear of the product.
- If a TV is not positioned in a sufficiently stable location, it can be potentially hazardous due to falling. Many injuries, particularly to children, can be avoided by taking simple precautions such as:
 - Using cabinets or stands recommended by the manufacturer of the TV.
 - Only using furniture that can safely support the TV.
 - Ensuring the TV is not overhanging the edge of the supporting furniture.
 - Not placing the television on tall furniture (for example, cupboards or bookcases) without anchoring both the furniture and the TV to a suitable support.
 - Not standing the TV on cloth or other materials placed between the TV and supporting furniture.
 - Educating children about the dangers of climbing on furniture to reach the TV or its controls.
 - Do not install the TV in a location in which it will be subject to water drops such as underneath an air conditioning unit or in the vicinity of a humidifier.
 - Water drops falling onto the TV and water entering inside it may result in fire, electric shock, or malfunctions.
 - We recommend that you install the TV at least 1m away from the outlet of an air conditioner.

Initial installation

Follow the steps below one by one when using the TV for the first time. Some steps may not be necessary depending

on your TV installation and connection.

- ❶ Connect an RF IN cable to the RF IN terminal.



- ❷ Plug the AC cord into the AC inlet of the main unit.
Plug the AC cord into the AC outlet.
• Place the TV close to the AC outlet, and keep the power plug within reach.
• Product shape varies in some countries.
- ❸ Press (JOG-KEY) on the TV.

- ❹ Run the initial installation.


- Follow the guide on the TV screen to set the settings.

Instruction for using AV IN.

Requires RCA jack conversion.


Buy the service parts (QCNWGA252WJPZ).

Side terminal



Terminal Diagram

TV (Rear)



Viewing E-Manual

Viewing the Built-in Operation Manual

Displays the built-in operation manual on the screen. You can read information about how to use this device.

The internet connection will be required.

1. Press (HOME) to display the HOME screen, press / to select "Manual", and then press ENTER/OK.

This displays the built-in operation manual screen.

2. When you select contents, its page will be displayed.



Appendix

Troubleshooting

The problems described below are not always caused by malfunctions. Check the TV again before having the TV serviced.

Problem	Possible Solution
<ul style="list-style-type: none"> • No power. 	<ul style="list-style-type: none"> • Check if you pressed POWER on the remote control unit. • Is the AC cord disconnected? • Has the power been turned on?
<ul style="list-style-type: none"> • Remote control unit does not operate. 	<ul style="list-style-type: none"> • Are batteries inserted with polarity (e, f) aligned?
<ul style="list-style-type: none"> • No picture. 	<ul style="list-style-type: none"> • Is connection to other components correct?
<ul style="list-style-type: none"> • No sound. 	<ul style="list-style-type: none"> • Is connection to other components correct?

Clearing the password

If you forget the password, clear the password using the following procedure.

1 From the Dashboard, select “Settings” > “System” > “About” > “Reset” > “Factory reset”, and then press ENTER/OK.

2 When you perform a reset, the TV will be returned to the factory preset values, and you need to set the password again.

NOTE

- The default PIN is “1234”.
- As a precautionary measure, make a note of your password, and keep it in a safe place.

DISCLAIMERS

- This SHARP device facilitates the access to content and services provided by third parties. The content and services accessible via this device belong to and may be proprietary to third parties. Therefore, any use of such third party content and services must be in accordance with any authorization or terms of use provided by such content or service provider. SHARP shall not be liable to you or any third party for your failure to abide by such authorization or terms of use. Unless otherwise specifically authorized by the applicable content or service provider, all third party content and services provided are for personal and non-commercial use; you may not modify, copy, distribute, transmit, display, perform, reproduce, upload, publish, license, create derivative works from, transfer or sell in any manner or medium any content or services available via this device.
- SHARP is not responsible, nor liable, for customer service-related issues related to the third party content or services. Any questions, comments or service-related inquiries relating to the third party content or service should be made directly to the applicable content or service provider.

You may not be able to access content or services from the device for a variety of reasons which may be unrelated to the device itself, including, but not limited to, power failure, other Internet connection, or failure to configure your device properly. SHARP, its directors, officers, employees, agents, contractors and affiliates shall not be liable to you or any third party with respect to such failures or maintenance outages, regardless of cause or whether or not it could have been avoided.

- ALL THIRD PARTY CONTENT OR SERVICES ACCESSIBLE VIA THIS DEVICE IS PROVIDED TO YOU ON AN “AS-IS” AND “AS AVAILABLE” BASIS AND SHARP AND ITS AFFILIATES MAKE NO WARRANTY OR REPRESENTATION OF ANY KIND TO YOU, EITHER EXPRESS OR IMPLIED, INCLUDING, WITHOUT LIMITATION, ANY WARRANTIES OF MERCHANTABILITY, NON-INFRINGEMENT, FITNESS FOR A PARTICULAR PURPOSE OR ANY WARRANTIES OF SUITABILITY, AVAILABILITY, ACCURACY, COMPLETENESS, SECURITY, TITLE, USEFULNESS, LACK OF NEGLIGENCE OR ERROR-FREE OR

Specifications

Model Item			4T-C65FV1X
lenapDCL			164 cm
Resolution			8,294,400 pixels (3840 g 2160)
metsysruolocoediV			06LAP/34.4CSTN/85.3CSTN/MACES/LAP
TV function	TV standard	Analogue	PAL: B/G, D/K, I SECAM: B/G, D/K, K/K1 NTSC: M
		Digital	DVB-T / DVB-T2
	Receivin g channel	VHF/UH F	44.25 – 863.25 MHz

	TV-tuning system	Auto Preset
	STEREO/BILINGUAL	NICAM: B/G, I, D/K A2 stereo: B/G MTS:M
Audio amplifier		Total 85W [(15W g 2) + (10W g 2) + (10W g 2) + 15W]
Termin als	RF IN	75 Ω DIN type
	HDMI 1	HDMI 4K, ALLM
	HDMI 2	HDMI 4K, ALLM
	HDMI 3	HDMI 4K, ALLM/VRR (120P)
	HDMI 4	HDMI 4K, ALLM/VRR (120), eARC/ARC
	AV IN	3.5 mm jack (AUDIO in, VIDEO in)
	USB	USB 2.0 (DC5V 500mA output)
	USB	USB 2.0 (DC5V 500mA output)
	LAN (10/100 BASE-T)	Network connector
	OPTICAL DIGITAL AUDIO OUT	Optical S/PDIF digital audio output
	EAR PHONE	3.5 mm stereo
	FOR SERVICE ONLY	2.5 mm jack
WIFI Protocol		IEEE 802.11 a/b/g/n/ac 2T/2R Dual Band

WIFI Security		WPA3-Personal, WPA2-Personal, WPA-Personal
Bluetooth		V2.1 + EDR / 4.2 / 5.1
Language		English/Simplified Chinese/Traditional Chinese(TW)/ Traditional Chinese(HK)/Arabic/French/Thai/Portuguese/Vietnamese/ Hindi/Russian/Bahasa Malaysia/ Bahasa Indonesia
Power		AC 110 – 240 V, 50/60 Hz
Power (Standby)		360W (0.5W)
Dimensions	without stand W x H x D (mm)	1442 g 845 g 73
	with stand W x H x D (mm)	1442 g 896 g 304
Weight without stand (with stand)		31.5 kg (37.0 kg)
Operating temperature		0°C to + 40°C

- UNINTERRUPTED OPERATION OR USE OF THE CONTENT OR SERVICES PROVIDED TO YOU OR THAT
- THE CONTENT OR SERVICES WILL MEET YOUR REQUIREMENTS OR EXPECTATIONS.
- SHARP IS NOT AN AGENT OF AND ASSUMES NO RESPONSIBILITY FOR THE ACTS OR OMISSIONS OF THIRD PARTY CONTENT OR SERVICE PROVIDERS, NOR ANY ASPECT OF THE CONTENT OR SERVICE
- RELATED TO SUCH THIRD PARTY PROVIDERS.
- IN NO EVENT WILL SHARP AND/OR ITS AFFILIATES BE LIABLE TO YOU OR ANY THIRD PARTY FOR ANY
- DIRECT, INDIRECT, SPECIAL, INCIDENTAL, PUNITIVE, CONSEQUENTIAL OR OTHER DAMAGES, WHETHER THE THEORY OF LIABILITY IS BASED ON CONTRACT, TORT, NEGLIGENCE, BREACH OF WARRANTY, STRICT LIABILITY OR OTHERWISE AND WHETHER OR NOT SHARP AND/OR ITS AFFILIATES HAVE BEEN •

ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.

- As a part of policy of continuous improvement, SHARP reserves the right to make design and specification changes for product improvement without prior notice. The performance specification figures indicated are nominal values of production units. There may be some deviations from these values in individual units.


CAUTION

Installing the Liquid Crystal Television requires special skill that should only be performed by qualified service personnel. Customers should not attempt to do the work themselves. SHARP bears no responsibility for improper mounting or mounting that results in accident or injury.

Carefully read the instructions that come with the bracket before beginning work.

Do not install / mount the TV with tilting condition.

Dimensional Drawing



SHARP

SHARP CORPORATION


For Indonesia
NO. REG I.32.STID4.03901.0516

SHARP

PT. SHARP TRADING INDONESIA

Kawasan Industri KIIC, Jl. Harapan Raya Lot LL 1 & 2
Gedung No. 01, Desa Sirnabaya, Kec. Teluk Jambe Timur
Kabupaten Karawang 41361

Documents / Resources



[SHARP 4T-C65FV1X LED Backlight TV](#) [pdf] Installation Guide
4T-C65FV1X, 4T-C65FV1X LED Backlight TV, LED Backlight TV, Backlight TV, TV

References

- [🌐 Patent Lists - Access Advance](#)
- [🇸🇬lobal.sharp/restricted/support/aquos/emanual/asia/pdf/fv/android11/index.html](#)
- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)