



SHARP PN-HS501 LCD Monitor Instructions

[Home](#) » [Sharp](#) » SHARP PN-HS501 LCD Monitor Instructions 

Contents

- 1 SHARP PN-HS501 LCD Monitor Instructions
- 2 1. Scope
- 3 2. Tools for dismantling
- 4 3. Dismantle Procedure
- 5 4. Back covers
- 6 5. Printed circuit boards
- 7 6. Battery
- 8 7. LCD Module
- 9 8. Capacitors
- 10 9. Parts List
- 11 Read More About This Manual & Download PDF:
- 12 Documents / Resources
- 13 Related Posts

SHARP PN-HS501 LCD Monitor Instructions



1. Scope

This document describes dismantling instruction according to Annex VII of Directive 2012/19/EU.

2. Tools for dismantling

Below tools are required to dismantle this product.

- Screw Driver
- Nipper

3. Dismantle Procedure

This product can be dismantled by below steps.

1. Remove Back covers (section 4)
2. Remove Printed circuit boards (section 5)
3. Remove Battery (section 6)
4. Dismantle LCD (section 7)
5. Remove Electrolyte Capacitors (section 8)

4. Back covers

Back cover can be removed by screw driver.



5. Printed circuit boards

All PWBs can be removed by screw driver.




Main I/F PWB (1pcs)



Power PWB (1pcs)

6. Battery


This model uses only AAA battery for remote control. Battery can easily be removed.



7. LCD Module


LCD Dismantle procedure

1. Remove Rear cover
2. Remove PWBs
3. Remove the Cables



8. Capacitors

Electrolyte Capacitors which diameter/height is larger than 25mm is installed on Power PWB. These capacitors can be removed by using nipper to cut the leads.




9. Parts List

Parts described in Annex VII of directive 2012/19/EU are as below.

Parts	Note
LCD	50inch LCD module
Printed Circuit Boards	Main I/F PWB Power PWB T-CON PWB
Battery	AAA battery
Electrolyte capacitors (height >25mm, diameter >25mm)	On Power PWB
External electric cables	2 kinds of Power Cord – for EU – for UK

Read More About This Manual & Download PDF:

Documents / Resources

 <p>SHARP</p> <p>LCD MONITOR</p> <p>Model: PN-HS501</p> <p>Disassembly Instruction</p>	<p>SHARP PN-HS501 LCD Monitor [pdf] Instructions PN-HS501, LCD Monitor, PN-HS501 LCD Monitor</p>
---	--