



Sharpal 129N METALKUTTER Multipurpose Sharpening Tool User Manual

[Home](#) » [SHARPAL](#) » Sharpal 129N METALKUTTER Multipurpose Sharpening Tool User Manual 

Contents

- [1 Sharpal 129N METALKUTTER Multipurpose Sharpening Tool](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 FAQ](#)
- [5 Sharpening and Honing Instruction](#)
- [6 Documents / Resources](#)
 - [6.1 References](#)



Sharpal 129N METALKUTTER Multipurpose Sharpening Tool



Product Information

Specifications:

- **Item No.:** 129N
- **Material:** Tungsten carbide for sharpening, Ceramic blade for honing

- **Warranty:** 3 years from the date of purchase for normal wear and tear

Product Usage Instructions

Sharpening and Honing Instructions:

1. Align the cutting edge being sharpened and the sharpening tool at an angle of approximately 20 degrees.
2. Maintain the angle and repeatedly slide the tungsten carbide along the cutting edge from the heel of the blade toward the tip. Continue until desired sharpness is achieved.
3. Switch to the ceramic blade for honing the cutting edge, following the same process as sharpening.

Note: Most pruning shears, loppers, and mowers have blades that are only beveled on one side. Only sharpen the beveled side of each blade. For double-beveled edges, repeat the process for the underside of the blade. Give each side of the blade the same number of strokes for an even cutting edge.

Tungsten Carbide: Use for dull or damaged edges that require a new edge setting.

Ceramic Blade: Suitable for honing a blade.

For warranty claims, contact us through the SHARPAL website or send an email directly to warranty@sharpal.com.

FAQ

- **How long is the warranty period?**


The warranty period is 3 years from the date of purchase for normal wear and tear, excluding damage caused by misuse or alteration.

- **Can I sharpen both sides of a blade?**

For blades with a single beveled edge, only sharpen the beveled side. For double-beveled edges, repeat the process on both sides to maintain even sharpness.

Sharpening and Honing Instruction

1. Align the cutting edge being sharpened and the sharpening tool at an angle of approximately 20 degrees (see Fig.1).
2. Maintain the angle and repeatedly slide the tungsten carbide along the cutting edge from the heel of the blade toward the tip (see Fig.2). Continue this motion until the desired sharpness is achieved.
3. Switch to the ceramic blade for honing the cutting edge, following the same process as sharpening.



Note:

- Most pruning shears, loppers and mower have blades that are only beveled on one side of the blade. Only sharpen the side of each blade that has a bevel. If you are sharpening a double-beveled edge, such as most knife edges, repeat the above process for the underside of the knife blade. Give each side of the blade the same number of strokes to maintain an even cutting edge.
- The tungsten carbide is for the dull or damaged edge that requires a new edge setting
- The ceramic blade is suitable for honing a blade.

Demo Video

- Watch its demo video on YouTube: bit.ly/129video
- Or scan QR code



- Each SHARPAL product is warranted to be free from defects in material and workmanship for 3 years from the date of purchase under normal wear and tear, except for damage caused by misuse or alteration. THIS WARRANTY APPLIES ONLY TO NON-INDUSTRIAL OR NON-COMMERCIAL USE. If you want to make a warranty claim, please contact us through SHARPAL website or send an email directly to warranty@sharpal.com.

Documents / Resources

A small thumbnail image showing the cover of the Sharpal 129N METALKUTTER User Manual, which includes a diagram of the tool and some text.	<p>Sharpal 129N METALKUTTER Multipurpose Sharpening Tool [pdf] User Manual 129N METALKUTTER Multipurpose Sharpening Tool, 129N, METALKUTTER Multipurpose Sharpening Tool, Multipurpose Sharpening Tool, Sharpening Tool, Tool</p>
--	---

References

- [YouTube](#)
- [User Manual](#)

