



## DigiPower 3-in-1 Wireless Power Bank DP-PBA6L

[Home](#) » [Sharper Image](#) » DigiPower 3-in-1 Wireless Power Bank DP-PBA6L 

## Contents

- 1 DigiPower 3-in-1 Wireless Power Bank DP-PBA6L
- 2 Product diagram
- 3 Specifications
- 4 Accessories list
- 5 Charge Up to devices at the same time
- 6 OPERATION OF THE POWERBANK
  - 6.1 CHECKING THE POWER LEVEL
- 7 TURNING THE POWER BANK OFF
  - 7.1 (Turning the LEDs off)
  - 7.2 CHARGING THE APPLE WATCH
  - 7.3 CHARGING THE AIRPODS
  - 7.4 CHARGING A SMARTPHONE OR OTHER USB DEVICE
  - 7.5 RECHARGING THE POWERBANK
- 8 Experiencing problems?
- 9 WARNING! IMPORTANT SAFETY INSTRUCTIONS!
- 10 Questions about your Manual? Post in the comments!
  - 10.1 Related Posts

## DigiPower 3-in-1 Wireless Power Bank DP-PBA6L



## Product diagram



## Specifications

- **Capacity:** 5200mAh (19.24Wh)
- **USB Input:** 5V/2A (106)
- **USB Output:** 5V/2A (10W)
- **Watch Output:** 5V/0.4A (2W)
- **Airpods Output:** 5V/0.2A (1W)

## Accessories list

- 1m (3.3ft) charge cable
- User guide

## Charge Up to devices at the same time



## OPERATION OF THE POWERBANK

### CHECKING THE POWER LEVEL

- To check the power level press the function button one time

- There are 4 blue LEDs in total: 4 blue LEDs > 75% charge, 3 blue LEDs 50% to 75% charge, 2 blue LEDs 25% to 50% charge, 1 blue LED < 25% charge

## **TURNING THE POWER BANK OFF**

### **(Turning the LEDs off)**

- Press and hold the function button for 5 seconds to turn the powerbank and the LEDs off

## **CHARGING THE APPLE WATCH**

- Place the watch on the charge area and press the function button to start charging
- The LEDs will remain on if the watch is charging

## **CHARGING THE AIRPODS**

- Insert the AirPods into the compartment on the top of the powerbank
- The blue power level LEDs and the green watch charging LED will light up to indicate the AirPods are charging
- When the AirPods are fully charged all the LEDs will turn off

## **CHARGING A SMARTPHONE OR OTHER USB DEVICE**

- Connect a USB cable to the powerbank and the other end to your device
- Press the function button one time to turn the powerbank on
- The blue power level LEDs will remain on while your device is charging

## **RECHARGING THE POWERBANK**

- Connect the powerbank to a USB power source, the blue LEDs will light up in sequence
- When all 4 blue LEDs remain lit the powerbank is fully charged

## **Experiencing problems?**

Before returning this product please call our toll free customer support line for assistance: 1-800-838-3200 or email us at [TechSupport@Mizco.com](mailto:TechSupport@Mizco.com)

## **WARNING! IMPORTANT SAFETY INSTRUCTIONS!**

Failure to read and follow these safety instructions could result in fire, explosion, electrical shock or other hazard, causing serious and/or fatal injury and/or property damage.

- Do not modify, disassemble, open, drop, crush, puncture or shred the product.
- Do not expose the product to rain or water

- Keep the product away from open flame or sunlight to prevent heat build-up
- Keep the product away from children. This product is not a toy.
- Ensure that all persons who use the product read and follow these warnings and instructions.

**Read More About This User Manuals...**

[DigiPower-3-in-1-Wireless-Power-Bank-DP-PBA6L-Optimized.pdf](#)

[DigiPower-3-in-1-Wireless-Power-Bank-DP-PBA6L-Original.pdf](#)

---

**Questions about your Manual? Post in the comments!**

Manuals+.