



SHARPER IMAGE Expansion Trays for Dinner Table Lazy Susan Instructions


[Home](#) » [Sharper Image](#) » SHARPER IMAGE Expansion Trays for Dinner Table Lazy Susan Instructions 

Contents


- [1 SHARPER IMAGE Expansion Trays for Dinner Table Lazy Susan](#)
- [2 Package Contents](#)
- [3 Storing the Expansion Pack](#)
- [4 Documents / Resources](#)

SHARPER IMAGE®

SHARPER IMAGE Expansion Trays for Dinner Table Lazy Susan




Package Contents




To take apart, DO NOT PULL APART WITH FORCE. Gently lift the Lazy Susan a few inches and press/unclick tab under the track. Pull both sides apart carefully.

Storing the Expansion Pack

1. Place the 2 tracks upside down inside the box. The circular black feet facing up.
2. Place the first tray on top of the tracks so that the black silicone is facing up.
3. Place the second tray upside down on top of the first tray. The wheels facing up.



Documents / Resources

	<p>SHARPER IMAGE Expansion Trays for Dinner Table Lazy Susan [pdf] Instructions Expansion Trays for Dinner Table Lazy Susan, Expansion, Trays for Dinner Table Lazy Susan, T able Lazy Susan, Lazy Susan, Susan</p>
-------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------