

Sharper Image EC-B150 Sound Soother White Noise Machine User Manual

Home » Sharper Image » Sharper Image EC-B150 Sound Soother White Noise Machine User Manual



Contents

- 1 Sharper Image EC-B150 Sound Soother White Noise **Machine**
- 2 Introduction
- 3 Specifications
- 4 Package Includes
- **5 Features**
- **6 Dimension**
- 7 Usage
- 8 Care and Maintenance
- 9 Troubleshooting
- 10 Pros and Cons
- 11 Contact Information
- 12 Warranty
- 13 FAQs
- 14 References
- 15 Related Posts



Sharper Image EC-B150 Sound Soother White Noise Machine



Launch Date: August 1, 2012 **Price:** \$54.00 and \$147.02

Introduction

We will learn about the Sharper Image EC-B150 Sound Soother White Noise Machine in this guide. This machine has advanced features that are meant to help you sleep well and relax. The gadget has 20 digitally mastered sounds, such as relaxing nature sounds and background noises like rain, ocean waves, and clouds, to make a calm space for working or relaxing. Because it's small and portable, and the level can be changed, it's easy to use anywhere, from the bedroom to the office. It has two alarms, a digital FM clock, and a snooze button, so you can set a gentle and flexible way to wake up. The extra-large screen makes it easy to choose sound titles, and the auto-off timer is handy. This machine also has a battery backup option that will keep your settings even if the power goes out. The EC-B150 Sound Soother is a great addition to your routine whether you want to sleep better or just enjoy relaxing background noise.

Specifications

• Brand: Sharper Image

· Color: White

• Display Type: Digital

• Style: Compact

• Special Features: Snooze, Adjustable Volume, Dual alarm clock

• Power Source: Corded Electric

Room Type: BedroomShape: RectangularMaterial: Plastic

• Theme: Sleep

• Frame Material: Plastic

• Are Batteries Included: No

• Item Weight: 16 ounces (1 pound)

· Alarm Clock: Yes

• Watch Movement: Quartz

• Number of Items: 1

• Operation Mode: Electrical

Dial Color: WhiteClock Form: Mantel

• Global Trade Identification Number: 00845516003370

Manufacturer: Sharper Image-CEUPC: 845516000126 / 845516003370

• Product Dimensions: 8.1 x 2.5 x 4.6 inches

Country of Origin: China
Item Model Number: EC-B150

Package Includes

• 1 x Sharper Image EC-B150 Sound Soother White Noise Machine

1 x AC Adapter

• 1 x User Manual

Features

1. 12 Calming Sound Options

The device comes equipped with a selection of 12 calming soundscapes designed to help users relax, sleep, or focus. These sounds include white noise, rain, ocean, thunder, and more, each of which can help mask environmental noises or create a peaceful ambiance.

2. Adjustable Volume

The machine offers a fully adjustable volume control, allowing users to tailor the sound output according to their specific needs. Whether you need a subtle background sound to relax or louder noise to block out disturbances, the volume dial ensures flexibility for any environment.

3. Compact and Portable

With its small, sleek design, the Sound Soother is easy to transport, making it ideal for both home use and travel. Its lightweight structure means it fits effortlessly into luggage, so you can take your preferred soundscapes on the go to ensure restful sleep wherever you are.

4. Auto-Off Timer

For added convenience, the device includes an auto-off timer, which allows users to set the machine to automatically shut off after 30, 60, or 90 minutes. This feature conserves energy while ensuring you fall asleep with the sound but don't wake up to it in the middle of the night.

5. Battery Backup

The Sound Soother includes a battery backup option, allowing it to maintain functionality even during power outages. This means that the machine can continue running and retain your chosen settings, so your sleep or relaxation won't be interrupted.

6. Improves Sleep and Focus

By offering continuous soothing sounds that block out disruptive background noise, this white noise machine creates an optimal environment for sleep and focus. It is ideal for those who live in noisy environments, suffer from insomnia, or need help concentrating during work or study sessions.

7. Digital FM Clock Radio with Gradual Wake and Snooze

The device also functions as a digital FM clock radio, complete with gradual wake-up features. The gradual wake and snooze functionality allows users to wake up gently with increasing sound or to hit the snooze button for a few extra minutes of rest.

8. 20-Digitally Mastered Relaxing Sounds

In addition to its 12 sound options, the machine features 20 digitally mastered sounds that create an immersive audio environment for relaxation. These sounds include:

- Aviary (birds singing)
- Brook (flowing water)
- City (urban ambiance)
- Dockside (sounds of a harbor)
- Ebb Tide (gentle waves)
- Everglades (nature sounds from the wetlands)
- Fireside (crackling fire)
- Foghorns
- **Heartbeat** (rhythmic heartbeats)
- North Woods (forest sounds)
- Oceanside (waves crashing)
- Rain
- Rainforest (tropical rain sounds)
- Roadside (highway sounds)
- Steam Train (train sounds)
- Summer Night (evening nature sounds)
- Surf's Up (energetic waves)
- Thunderstorms
- · White Noise
- Wind Chimes

9. Extra Large Display with Full Sound Titles

The device includes an extra-large, easy-to-read display that shows the full titles of the sounds, allowing users to quickly select and identify their preferred sound settings. This feature makes operation straightforward, especially in low-light conditions or for users who prefer larger text.

10. Dual Alarm with Dual Readouts

Setting alarms is easy with the dual alarm system and dual readouts, allowing users to set two alarms with different wake-up options. You can choose to wake up to soothing sounds, a beep, or the FM radio, making the alarm adaptable to your preferences.

11. Snooze Function

The built-in snooze function allows users to extend their sleep by a few minutes when the alarm goes off, with easy-to-access buttons for quick operation.

Dimension



Usage

- 1. Power On: Plug the AC adapter into a wall socket and connect it to the device.
- 2. Select Sound: Use the sound selection button to choose from 12 options.
- 3. Adjust Volume: Set the volume level to your preference using the volume dial.
- 4. Timer Setting: If needed, select the timer function for 30, 60, or 90 minutes, or let it run continuously.
- 5. Battery Backup: Insert optional batteries for backup power during power interruptions.

Care and Maintenance

- Cleaning: Wipe the exterior with a soft, dry cloth. Avoid using water or harsh chemicals.
- Power Cord: Ensure the power cord is free from kinks and store it properly to prevent damage.
- Storage: Store the device in a cool, dry place when not in use.
- Battery Replacement: If using battery backup, replace the batteries every 6 months or when drained.

Troubleshooting

Issue	Possible Cause	Solution
Device not powering on	No power or improper connection	Ensure the AC adapter is properly plugged in.
No sound output	Volume set too low or muted	Increase the volume using the volume dial.
Sound is distorted	External interference or faulty s peaker	Move the device away from electronics or rest art.
Timer function not working	Incorrect timer settings	Reset and verify the correct timer option is set .
Battery backup not functio ning	Batteries are drained	Replace batteries and ensure proper placeme nt.
Alarm not going off	Alarm not set properly	Double-check alarm settings and ensure AM/PM mode.
The display not working pr operly	Faulty connection or power out age	Reset the device or check power supply.

Pros and Cons

Pros	Cons
Wide variety of soothing sounds	Some users report sound clarity issues
Dual alarm feature	Requires batteries for backup
Compact design	Limited portability without power

Contact Information

• Customer Service Phone Numbers:

Toll-Free Number: <u>877-714-7444</u>
 Customer Service: <u>877-202-9337</u>

• Alternative Customer Service: 877-206-7862

• Email:

• Customer Service: <u>customerservice@sharperimageonline.com</u>

• Mailing Address: Sharper Image 27725 Stansbury Boulevard, Suite #175 Farmington Hills, MI 48334, USA

Warranty

The Sharper Image EC-B150 comes with a **1-year limited warranty**, ensuring peace of mind with your purchase.

FAQs

What sounds are available on the Sharper Image EC-B150 Sound Soother White Noise Machine?

The Sharper Image EC-B150 Sound Soother White Noise Machine offers 20 digitally mastered sounds, including nature sounds like rain, ocean waves, thunderstorms, and white noise to help you relax or

sleep.

How many alarms can be set on the Sharper Image EC-B150 Sound Soother White Noise Machine?

The Sharper Image EC-B150 Sound Soother White Noise Machine has dual alarms, allowing you to set two different wake-up times.

What type of display does the Sharper Image EC-B150 Sound Soother feature?

The Sharper Image EC-B150 Sound Soother White Noise Machine features an extra-large digital display that shows the full titles of the selected sounds for easy identification.

What happens if the power goes out while using the Sharper Image EC-B150 Sound Soother?

The Sharper Image EC-B150 Sound Soother White Noise Machine has a battery backup option, ensuring that your settings are retained during power outages.

What is the power source for the Sharper Image EC-B150 Sound Soother?

The Sharper Image EC-B150 Sound Soother White Noise Machine is powered by an AC adapter and also offers a battery backup option for added convenience.

How many sounds does the Sharper Image EC-B150 Sound Soother provide for relaxation?

The Sharper Image EC-B150 Sound Soother White Noise Machine offers 20 relaxing sounds, including natural and ambient noises like rain, ocean, and white noise.

What are the dimensions of the Sharper Image EC-B150 Sound Soother White Noise Machine?

The Sharper Image EC-B150 Sound Soother White Noise Machine measures $8.1 \times 2.5 \times 4.6$ inches, making it a compact option for bedside use.

What materials is the Sharper Image EC-B150 Sound Soother made from?

The Sharper Image EC-B150 Sound Soother White Noise Machine is made from durable plastic and has a sleek, modern design suitable for any bedroom or office.

What kind of power adapter does the Sharper Image EC-B150 Sound Soother use?

The Sharper Image EC-B150 Sound Soother White Noise Machine uses a standard AC power adapter included with the product for convenient and consistent use.

How many sound titles are displayed on the screen of the Sharper Image EC-B150 Sound Soother?

The Sharper Image EC-B150 Sound Soother White Noise Machine features an extra-large display that clearly shows all 20 sound titles for easy navigation.

What makes the Sharper Image EC-B150 Sound Soother ideal for sleep?

The Sharper Image EC-B150 Sound Soother White Noise Machine is ideal for sleep because it offers a variety of calming sounds that help mask background noises, creating a peaceful sleeping environment.

How long does the Sharper Image EC-B150 Sound Soother timer run?

The Sharper Image EC-B150 Sound Soother White Noise Machine has an auto-off timer that can be set for 30, 60, or 90 minutes to suit your needs.

What is the weight of the Sharper Image EC-B150 Sound Soother White Noise Machine?

The Sharper Image EC-B150 Sound Soother White Noise Machine weighs approximately 1 pound, making it lightweight and easy to place anywhere in the home or office.

References

User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.