

Shelly-H&T-Gen-3-Mocha-Wi-Fi-and-Bluetooth-Temperature



# Shelly H&T Gen 3 Mocha Wi-Fi and Bluetooth Temperature Instruction Manual

[Home](#) » [Shelly](#) » Shelly H&T Gen 3 Mocha Wi-Fi and Bluetooth Temperature Instruction Manual 

## Contents

- [1 Shelly H&T Gen 3 Mocha Wi-Fi and Bluetooth Temperature](#)
- [2 Product Information](#)
- [3 Product Usage Instructions](#)
- [4 Introduction](#)
- [5 Waking the Device](#)
- [6 Documents / Resources](#)
  - [6.1 References](#)



**Shelly H&T Gen 3 Mocha Wi-Fi and Bluetooth Temperature**



## Product Information

### Specifications:

- **Product Name:** Shelly H&T Gen3
- **Control:** Shelly Smart Control
- **Display Units:** Celsius (default), can be changed to Fahrenheit

## Product Usage Instructions

### Waking the Device:

1. Open the device.
2. Press the Reset button.

### Changing the Temperature Units:

1. Open the Shelly Smart Control app.
2. Tap the Room where the H&T Gen3 is located.
3. Tap the Shelly H&T Gen3.
4. Tap the Sensor settings button represented by an icon displaying the device and a gear.
5. Tap Temperature units.
6. Wake the device as explained in the previous section of this document.
7. Tap the back arrow in the Smart Control app.
8. The device displays the temperature in Fahrenheit.

## FAQ

- **Q: Can I switch back to Celsius after changing to Fahrenheit?**

- **A:** Yes, you can switch back to Celsius by following the same steps but selecting Celsius as the temperature unit.
- **Q: Do I need to wake the device every time I change the temperature units?**
  - **A:** It is recommended to wake the device before making any changes to ensure proper functionality.

## Using Shelly Smart Control to change the Display Units on a Shelly H&T Gen3 to Fahrenheit.

### Introduction

By default, the Shelly H&T Gen 3 displays the temperature in Celsius. Use the following steps to change the displayed temperature units from Celsius (°C) to Fahrenheit (°F).

### Waking the Device

Before changing the temperature units displayed on the device, it is recommended to wake the device. To wake the device,

1. Open the device.




2. Press the Reset button.




### Changing the Temperature Units

1. Open the Shelly Smart Control app.
2. Tap the Room where the H&T Gen3 is located.
3. Tap the Shelly H&T Gen3.
4. Tap the Sensor setting button represented by an icon displaying the device and a gear.




5. Tap Temperature units.
6. Tap the °F button. A message is displayed: Setting saved successfully. The device is currently sleeping. It will update once it wakes up.



7. Wake the device as explained in the previous section of this document.
8. Tap the back arrow in the Smart Control app.
9. The device displays the temperature in Fahrenheit.



Documents / Resources

	<p><a href="#">Shelly H&amp;T Gen 3 Mocha Wi-Fi and Bluetooth Temperature</a> [pdf] Instruction Manual</p> <p>H T Gen 3 Mocha Wi-Fi and Bluetooth Temperature, H T, Gen 3 Mocha Wi-Fi and Bluetooth Temperature, Wi-Fi and Bluetooth Temperature, Bluetooth Temperature, Temperature</p>
---	--

References

- [User Manual](#)

[Manuals+.](#) [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.