



Shenzhen Chaowei Technology V10 Max Bluetooth Speaker User Manual

[Home](#) » [Shenzhen Chaowei Technology](#) » Shenzhen Chaowei Technology V10 Max Bluetooth Speaker User Manual 





SHENZHEN

Chaowei Technology V10 Max Bluetooth Speaker
User Manual

Contents


- [1 Accessory](#)
- [2 illustration](#)
- [3 Parameter](#)
- [4 Function Key](#)
- [5 How to pair your device?](#)
- [6 Documents / Resources](#)
- [7 Related Posts](#)

Accessory



◇ Type-C cable

illustration






1. Power ON/OFF
2. Mode Selection
3. EQ Switch
4. TWS Pairing
5. Play/Pause/End the call/Redial/Answer or Reject Phone call
6. Volume-/Previous Track
7. Volume+/Next Track
8. AUX in
9. TF port
10. Type-c port
11. USB port

Parameter

Wireless version	5.2	Sensitivity	-42dB
Transmission range	≥18M(Open field)	Frequency range	60HZ-18kHz
TWS range	≥8M	Waterproof	IPX6
Battery capacity	10400mAh	Decoding format	MP3/SBC
Input	Type-c 5V/3.0A	Support profile	A2DP V1.3,ACRCP V1.4,HFP V1.6
Rated power	80W	AUX mode	3.5mm plug
Standby time	Automatic shutdown after 60 minutes of inactivity	TF mode	64G max
Talking time	20 hours(70% volume)	USB mode	64G max
Playing time	12 hours(50% volume)	Size	260x106x86mm
Charging time	4-5 hours	Weight	1683G

Function Key

Key	Operation	Function
	Long press	Press for 2 seconds to power on and into wireless Search. (Blue light flashing)
		Press for 2 seconds to power off.
M	Short press	Short press the mode to switch: Wireless, TF, AUX, and USB
	Long press	Press 3 seconds to disconnect the wireless connection Press 8 seconds to restore the factory settings.
EQ	Short press	The default EQ is full-range, and a short press of the “EQ” button is 3D (Blue light on). and another short press is subwoofer(Green light on).
	Short press	Short press to enter TWS (Yellow light flashing)or disconnect the TWS(Blue light flashing).
	Short press	Short press to play or pause music/answer or end the call
	Long press	Press for 2 seconds to reject the call. Press for 3 seconds to activate the voice assistant.
	Double click	Double click to redial the last number dialed.
—	Press	Short press to reduce the volume, and long press for the previous song.
+	Press	Short press to increase the volume, long press for the next song.

Wireless Mode:

1. Wireless version: Wireless 5.2, support for ios, Android, and other devices.
2. Press the power button, then will enter Wireless mode, the speaker will emit Wireless tone, entering pairing status, the phone will search for the Wireless pairing name, click can be successfully connected.

TF card/AUX Mode:

1. Max support reading 64G Micro SD card, Insert any Micro SD card, and the speaker will play the audio files in the Micro SD card automatically. In the 3.5mm audio cable, the speaker will shift to AUX mode.
2. If the wireless of the mobile phone is connected to the "V10 Max" speaker, press the "M" mode button to switch TF card playback.


USB Mode:

1. Insert the usb flash drive after booting and automatically enter the USB playback mode.
2. Pull out the USB flash drive, and the USB mode ends.

What is TWS?

TWS means true wireless stereo. Let's say two Wireless speakers are able to be paired and play music synchronously.

How to pair your device?

1. Please make sure these two speakers are paired and disconnected from your Wireless device before you turn them on. Then please turn on two speakers.
2. Short press the matching button "", these will be voice prompt in the meantime, the yellow light will be shining to the matching mode.
3. When entering into the matching mode with the voice prompt, the yellow light is on. Main unit blue light flashes waiting for a handest connection, secondary unit blue light goes out.
4. Select searching mode on your device, finds " V8 Max ", select it and connect.
5. They will perform as a stereo-sounding system.
6. When the TWS is connected, press the "TWS" button to disconnect the TWS and the yellow light will go out.
7. Once the speakers are well paired and the first time, they will be automatically paired next time without the above pairing operation.
8. If the speaker used to be paired, it is suggested to press the matching button "**M**" for 8 seconds, and restart the machine after, cancel the automatic connection.

FCC Statement

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to protect reasonably against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. Suppose this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off. In that case, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Documents / Resources

	<p>Shenzhen Chaowei Technology V10 Max Bluetooth Speaker [pdf] User Manual V10MAX, 2A7N2-V10MAX, 2A7N2V10MAX, V10 Max Bluetooth Speaker, V10, Max Bluetooth Speaker</p>
---	---