



# Shenzhen Digidragon Technology K17A Smart Phone User Manual

[Home](#) » [Shenzhen Digidragon Technology](#) » Shenzhen Digidragon Technology K17A Smart Phone User Manual



# SHENZHEN

User Guide  
K17A

## Contents

- 1 Welcome
- 2 Know Your Phone
  - 2.1 Insert SIM Card
  - 2.2 Insert Memory Card
- 3 Basic Operations
  - 3.1 Switch Phone ON/OFF
  - 3.2 Unlock the phone
  - 3.3 Make a call
- 4 Notable Features
  - 4.1 Secure your Phone
  - 4.2 Blacklist and Whitelist
- 5 Contacts Features
  - 5.1 Add New Contacts
  - 5.2 Send SMS
  - 5.3 Call a Contact
  - 5.4 Delete Contacts
  - 5.5 Delete multiple contacts
  - 5.6 Delete Phone contacts
  - 5.7 Delete SIM1 contacts
  - 5.8 Delete SIM2 contacts
  - 5.9 Move contacts
  - 5.10 Add to Blacklist

5.11	Add to Whitelist
5.12	Import/Export Contacts
5.13	Send vCard
5.14	Others
5.15	Most used
5.16	Groups
6	Messages
6.1	Write message
6.2	Use message Templates
6.3	Voice mail server
6.4	Settings
6.5	Delete all
6.6	Message capacity
7	Call center
7.1	View Call center Menu > Call center
8	Settings
8.1	Call settings
8.2	Phone settings
8.3	Display settings
8.4	Security settings
8.5	Connections
9	Audio Player
10	Multimedia
10.1	Image Viewer
10.2	Video Recorder
10.3	Video player
10.4	Recorder
10.5	FM Radio
11	Games
11.1	Profiles
11.2	Files Manager
12	Organizer
12.1	Calendar
12.2	Alarm
12.3	Calculator
12.4	Torch
12.5	Bluetooth
12.6	World clock
12.7	Stopwatch
12.8	Timer
12.9	Ebook
13	Internet
14	Camera
15	Health and Safety Precautions
16	Taking Care of Your Device
17	FCC Caution:
18	Documents / Resources
19	Related Posts

## Welcome

Thank you for purchasing the phone. Your phone is packaged with the following state of the art features:

- VGA Camera
- 2.4 Inch screen

- AudioPlayer
- FM Radio
- Video and FM Recording
- Dual SIM (GSM + GSM)
- T-Flash Card support (up to 32 GB)
- Hindi Language Support

### Important:

1. Please read the contents of this manual to fully utilize the features of this phone.
2. Please read the Guidelines section provided with this Reference guide.

### Know Your Phone



### Insert SIM Card

1. Insert the SIM card correctly in the SIM slot(s).
2. Finally, insert the battery and replace the rear cover of the mobile phone.

### Insert Memory Card

1. Switch off the phone and remove the rear cover and the battery.
2. Insert the memory card into the slot.
3. Finally, insert the battery and the rear cover of the mobile phone.

**Note:** Use only compatible memory cards approved by K17A Incompatible cards may damage the slot or corrupt the data stored in the card.

### Basic Operations

#### Switch Phone ON/OFF

To switch ON/OFF your phone, press and hold the **End key** for a few seconds.

## Unlock the phone

If you do not use the phone for a while, the screen is replaced with a locked screen.

1. Press any key to activate the screen.
2. Press the **Left** key, and then press the \* key.

## Make a call

You can make a call in the following ways:

- Enter the desired number in standby mode and press the **Call key** to make the call.
- Go to **Menu > Phonebook** and then select and dial the desired number.
- Just press the **Call key** to dial the contacts listed in Call logs.
- You can also dial a contact from the messages.

## Notable Features

### Secure your Phone

#### Menu > Settings > Security settings> Phone Locked

Let you lock/unlock your phone via a security password which you can change anytime.

The default security code to unlock the phone is **1234**.

**Note:** After you activate the phone lock, you would be asked for a password when you power on your phone next time.

### Blacklist and Whitelist

#### Menu > Settings > Call settings > Advanced settings > Blacklist

Blacklist undesired SMS senders and callers so that you do not receive SMS and calling from them.

#### Menu > Settings > Call settings > Advanced settings > Whitelist

When you check the Whitelist settings, only the list in the Whitelist can call and send messages.

## Contacts Features

Your phonebook stores all your saved contacts for anytime use. Your phonebook data can be stored in your SIM card or your phone memory. You can manage your contacts from here.

### Menu > Phonebook

#### Add New Contacts

#### Menu > Phonebook > Left Key > New

#### Send SMS

#### Menu > Phonebook > Left Key >Write message > SMS

## **Call a Contact**

### **Menu > Phonebook > Left Key > Call>Voice call**

Allow you to make a call to the contact you are viewing. Or you can just highlight a number and press the **Call** key.

## **Delete Contacts**

### **Menu > Phonebook > Left Key> Delete**

In the Contacts list, select the entry you want to delete.

## **Delete multiple contacts**

### **Menu > Phonebook > Left Key> Delete multiple**

In the Contacts list, select the entry you want to delete.

## **Delete Phone contacts**

### **Menu > Phonebook > Left Key> Delete Phone**

In the Contacts list, select the entry you want to delete In phone.

## **Delete SIM1 contacts**

### **Menu > Phonebook > Left Key> Delete SIM1**

In the Contacts List, select the entry you want to delete In SIM1.

## **Delete SIM2 contacts**

### **Menu > Phonebook > Left Key> Delete SIM2**

In the Contacts list, select the entry you want to delete In SIM2.

## **Move contacts**

### **Menu > Phonebook > Left Key> Move**

In the Contacts list, select the entry you want to move to SIM or phone.

## **Add to Blacklist**

### **Menu > Phonebook > Left Key > Add to blacklist**

Allow you to blacklist selected numbers. In this case, the contact will be blocked from calling you up.

## **Add to Whitelist**

### **Menu > Phonebook> Left Key > Add to Whitelist**

Allow you to a white list of selected numbers. In this case, the other contacts will be blocked from calling you up.

## **Import/Export Contacts**

### **Menu > Phonebook> Left Key > Import/Export**

You can copy, Import, or Export contacts entries stored in the SIM card to the phone memory and vice-versa.

## Send vCard

### **Menu > Phonebook > Left Key > Send vCard**

Allow you to send vCard to other numbers and export vCard.

## Others

### **Speed dial**

**Menu > Phonebook> Left Key >Others> Speed dial** Set speed dial and view memory status.

### **Own number**

**Menu > Contacts > Left Key >Others> Own number** Set names of your own number.

### **Memory status**

**Menu > Phonebook > Left Key >Others> Memory status** Check the memory status of SIM, and Phone.

## Most used

### **Menu> Phonebook > Most used**

View the contacts that are most used.

## Groups

### **Menu> Phonebook > Groups**

Press the Left/Right navigation key to access the Group tab. Set up a list of numbers with similar preferences such as ringtone, profile, etc.

## Messages

### **Write message**

### **Menu > Messages > Write message > New SMS**

You can compose and send SMS. Pressing the **Left Key** during/after composing the message gives you a host of messaging features.

### **Use message Templates**

### **Menu > Messages > Templates**

Enter into preset message templates and use them. These preset templates can save you time if the theme of your message is the same as those existing in the template.

### **Voice mail server**

### **Menu > Messages > Voice mail server**

You can activate the voicemail service to redirect your incoming calls (based on your call settings) to a voicemail server and retrieve them later via SMS alerts.

To divert incoming calls to a voicemail server, go to Settings>Phone tab > Call Divert> Voice> (choose the desired call to divert condition)> Activate> Phone Number/Voicemail Number.

## Settings

## **Menu > Messages > Options>Settings**

You can set your desired parameters for SMS push messages and others.

### **Delete all**

## **Menu > Messages > Options>Delete all**

You can choose all messages in the Inbox or others to delete.

### **Message capacity**

**Menu > Messages >Options> Message capacity** View the memory status of your SMS.

## **Call center**

**View Call center Menu > Call center**

**Tip:** Directly access the call center by pressing the **Call** key in idle mode.

The Call center lists the calls you have recently dialed, received, missed for SIM1. and SIM 2.

Press the Left/right navigation keys to access various call centers and work on the call center.

## **Settings**

Choose various preferences to customize your handset according to your requirements. You can set:

### **Call settings**

## **Menu > Settings>Call settings**

To perform the Fixed dialing, call divert, call waiting, call barring, Hide **ID**, Advanced Settings.

### **Phone settings**

## **Menu > Settings>Phone settings**

To perform the Date&time, Language settings, Shortcut settings, Auto power on/off, Restore factory settings.

### **Display settings**

## **Menu > Settings>Display settings**

Perform related Settings shown as switch Animation effect, wallpaper settings, Idle display settings, according to some of the protective screen, backlight and the backlight time, key backlight time setting.

### **Security settings**

## **Menu > Settings>Security settings**

Execute related the SIM1/2 security, mobile security, automatic keyboard lock, and end keys locked fast, anti-theft tracking and fixed dialing, blacklist, and whitelist privacy protection.

### **Connections**

## **Menu > Settings>Connections**

You can set connectivity including B-tooth, data account.

## Audio Player

### Menu >Audio Player

The phone comes with inbuilt Music that plays all your favorite songs stored in the phone memory or memory card.

- While in music mode, press the Left key to choose various music options
- **Adjust Volume:** Press if and \* keys to change

## Multimedia

### Image Viewer

#### Menu > Multimedia > Image Viewer

Let you view your saved images. You can also send the Images via MMS or Bluetooth or use them as contact icons or wallpaper, etc.

### Video Recorder

#### Menu > Multimedia > Video Recorder

Press the **OK** Key to start recording.

- You can press **Options** to switch to **Camera** and vice
- You can also press the **Options** key to choose memory
- Press Left key to choosing various settings

Shortcut keys: Press the number keys as shortcuts on the phone's keypad to choose various video settings.

### Video player

#### Menu > Multimedia > Video player

Let you play videos stored on your phone or memory card.

Press the 2 key while playing a video to change the display mode.

### Recorder

#### Menu > Multimedia > Recorder

You can record surrounding sounds using this feature

### FM Radio

#### Menu > Multimedia > FM Radio

Your phone comes with an FM radio to let you listen to FM channels.

- Go to Options> Search Channels> Auto-Search and save to fill up the
- Press the number keys on your keypad in accordance with the channel list.
- Press the OK key to start/stop the radio.
- Press it or \* key to increase/decrease the volume.
- Press the Left key for various radio options.



## Games

### Menu > Games

You may play the built-in games and perform the game.

## Profiles

### Menu > Profiles

Activation and customize the required profile is general, silent, meeting, indoor, outdoor, headphones, Bluetooth style.

## Files Manager

### Menu > File manager

The File Manager lists all the files stored in your memory card.

## Organizer

## Calendar

### Menu > Organizer> Calendar

Call the other direction, you can hear the other side of the recording

## Alarm

### Menu > Organizer >Alarm

To use the alarm service available with your mobile phone.

## Calculator

### Menu > Organizer > Calculator

To arrange your journey according to the calendar.

## Torch

### Menu > Organizer > Torch

To turn on/off Torch.

## Bluetooth

### Menu > Organizer > Bluetooth

Open the Bluetooth, for file transfer and acceptance

## World clock

**Menu > Organizer > World clock** To use the world clock function.

## Stopwatch

**Menu > Organizer > Stopwatch** To use the stopwatch function.

## Timer

### Menu > Organizer > Timer

Set up time, time will have ring tone hint

## Ebook

Menu > Organizer > Ebook Tread TXT files on the card

## Internet

### Menu > Internet

To access this menu, enter the Main Menu in the standby mode and then select Internet. You can use the network-related services with this function.

## Camera

### Menu > Camera

Press the left key in camera mode to choose various settings

Shortcut keys: Press the number keys on the phone's keypad to choose.

## Health and Safety Precautions

Please read these simple guidelines. Not following them may be dangerous or illegal.

### SAIL Compliance

- Your phone is designed not to exceed the limits of emission of radio waves recommended by international guidelines.
- SAR (specific absorption rate) is the measurement of body-absorbed RF quantity when the phone is in SAR value is ascertained according to the highest RF level generated during laboratory tests.
- The SAR value of the phone may depend on factors such as proximity to the network tower, use of accessories, or other accessories.
- The highest SAR value of the device at the head and body is 0.15W/kg, 1.38 W/Kg respectively averaged over 1 g of human tissue.

### SAR Recommendations

- Use a wireless hands-free system (headphone, headset) with a low-power Bluetooth emitter.
- Please keep your calls short and use SMS whenever more convenient. This advice applies especially to children, adolescents, and pregnant women
- Prefer to use your cell phone when the signal quality is good.
- People having active medical implants should preferably keep the cell phone at least 5cm away from the
- Maintain a preferable distance of 5 mm from the device.

### Safe Driving

- Do not use the phone while driving. When you have to use the phone, please use the personal hands-free kit.

- Please do not put the phone onto any passenger seat or any place from which it may fall down in case of vehicular collision or emergency braking.

## **During Flight**

- Flight is influenced by the interference caused by the It is illegal to use a phone on the airplane. Please turn off your phone during a flight.

## **In Hospitals**

- Your Phone's radio waves may interfere with the functioning of inadequately shielded medical devices. Consult a physician or the manufacturer of the medical device to determine whether they are adequately shielded from external Radio Frequency. Switch off your device when regulations posted instruct you to do so.
- To avoid potential interference with implanted medical devices such as a pacemaker or cardioverter-defibrillator:
- Always keep your phone at least 3 centimeters (6 inches) from the medical device.
- Do not carry the wireless device in a breast pocket.
- Turn off the phone if there is any reason to suspect that interference is taking place.
- Follow the manufacturer's directions for the implanted medical device.
- If you have any questions about using your wireless device with an implanted medical device, consult your health care

## **Unsafe Areas**

- Please turn off your phone when you are close to a gas station or in the vicinity of any place where fuel and chemical preparations, or any other dangerous goods are stored.

## **Taking Care of Your Device**

Your device is a product of superior design and craftsmanship and should be handled with care: The following suggestions will help you protect your phone:

- Keep the device dry. Precipitation, humidity, and all types of liquids or moisture can contain minerals that will rust electronic circuits. If your device does get wet, remove the battery without turning on the device, wipe it with a dry cloth and take it to the service center.
- Do not store the device in high or cold High temperatures can shorten the life of electronic devices and damage batteries.
- Do not use or store the device in dusty, dirty areas. Its moving parts and electronic components can be damaged.
- Do not attempt to open the device other than as instructed in this guide. Repairing this phone by yourself other than our authorized service agents/centers goes against the warranty rules.
- Do not drop, knock, or shake the device. Rough handling can break internal circuit boards and fine mechanics.
- Do not use harsh chemicals, cleaning solvents, or strong detergents to clean the device. Only use a soft, clean, dry cloth to clean the surface of the device.

- Do not store your device near magnetic fields or allow your device to come in contact with magnetic fields for an extended period of time.

### **Battery Recommendations:**

- Please put the battery in a cool and well-ventilated place out of direct We recommend you to charge the battery at the room temperature range.
- Batteries have life cycles. If the time that the battery powers equipment becomes much shorter than usual, the battery life is at a Replace the battery with a new battery of the same make and specification.
- Do not discard the battery with household trash. Please dispose of used batteries according to your local environmental laws and
- Use manufacturer-approved batteries, chargers, accessories, and supplies. K17A will not be held responsible for users' safety when using unapproved accessories or supplies.



The WEEE logo (shown at the left) appears on the product (battery, handset, and charger) to indicate that this product must not be disposed of or dumped with your other household wastes. You are liable to dispose of all your electronic or electrical waste equipment by relocating over to the specified collection point for recycling. of such hazardous waste.

Specified collection points for recycling such hazardous waste. Collection and proper recovery of your electronic waste equipment at the time of disposal will allow us to help preserve the environment. Recycling electronic waste equipment will ensure the safety of human health and the environment. For more information on best practices for disposal of electronic and electrical waste, please visit our website: [www.micromaxinfo.com/weee.php](http://www.micromaxinfo.com/weee.php).respective owners.

2. K17A keeps the right to make modifications to any of the content in this user guide without public announcement in advance. The content of this manual may vary from the actual content displayed on the mobile phone. In such a case, the latter shall govern.

### **Copyrights**

All rights reserved. Reproduction, transfer, distribution, or storage of part or all of the contents in this document in any form without the prior written permission of K17A is strictly prohibited.

### **FCC Caution:**

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.


**Note:** This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference

in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and
- Connect the equipment into an outlet on a circuit different from that to which the receiver is
- Consult the dealer or an experienced radio/TV technician for help.

**Model — K17A**

**Documents / Resources**

	<a href="#">Shenzhen Digidragon Technology K17A Smart Phone</a> [pdf] User Manual K17A, 2AW7SK17A, K17A, Smart Phone
---	---