

Shenzhen Funpower General Technology FT0315R Remote Control Transmitter User Manual

Home » Shenzhen Funpower General Technology » Shenzhen Funpower General Technology FT0315R Remote Control Transmitter User Manual [™]

Contents


- 1 Shenzhen Fun power General Technology FT0315R Remote Control Transmitter
- **2 Operation Instructions**
- **3 FCC Instructions**
- 4 Documents / Resources
- **5 Related Posts**



Shenzhen Fun power General Technology FT0315R Remote Control Transmitter



Operation Instructions



1. UFan off

- 1. When operating, press the key \mathbf{U} to stop the fan.
- 2. This key for the fan off only.

2. Speed of the fan (1~6 level)

- 1. Press the key "1,2,3,4,5,6" to turn on the fan to the designated speed level.
- 2. After press speed level Keys, the fan will enter the corresponding speed level from other speed level or idle.
- 3. Key "1" is the lowest speed, and key"6 "is the highest speed.

3. IH 4H 8H Fan timing control

Set up the timer at 1hour,4 hours, 8 hours.

- 1. 1H Press this key, the fan will stop after 1 hour.
- 2. 4H press this key, the fan will stop after 4 hours.
- 3. 8H press this key, the fan will stop after 8 hours.
 - 1. The timing function of the key works when the fan is running.
 - 2. Press the key Uwill cancel the timer
 - 3. Timing function for the fan only.

4. The latest timer will take place the previous one.

4. S Natural wind

- 1. Press this key, the fan speed automatically changes between 1 to 6 speed.
- 5. The other optional functions as below:
 - Ĉ 1. Light off.

🗘 2. Light on.

☐ 3. Anti-theft function. The light will ON 5~20 minutes every 2 hours.

≈ 4. Direction of the fan change the running direction of the fan.

6. The transmitter use 2pcs of 1.5V AAA battery, please install the battery correctly.

Use precautions

- 1. When pressing the key of the transmitter, the LED indicator doesn't on, please inspect the battery installation.
- 2. When pressing the key of the transmitter, the LED indicator flashing, which means the battery gets low voltage, please replace a new one.
- 3. Please pull out of the battery from the transmitter when leaving it unused for a long time.

FCC Instructions

This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- 1. this device may not cause harmful interference, and
- 2. this device must accept any interference received, including interference that may cause undesired operation.

Warning:

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

Documents / Resources



<u>Shenzhen Funpower General Technology FT0315R Remote Control Transmitter</u> [pdf] User Manual

FT0315R, 2ABUP-FT0315R, 2ABUPFT0315R, FT0315R Remote Control Transmitter, Remote Control Transmitter

Manuals+,