Home » Shenzhen Xinglin Technology » Shenzhen Xinglin Technology U-A10 Universal Wireless Microphone Instruction Manual

Shenzhen Xinglin Technology U-A10 Universal Wireless Microphone Instruction Manual

Contents

- 1 Shenzhen Xinglin Technology U-A10 Universal Wireless Microphone
- **2 Product Information**
- **3 Product Usage Instructions**
- **4 PARTS NAME**
- **5 Documents / Resources**



Shenzhen Xinglin Technology U-A10 Universal Wireless Microphone



Product Information

• Channel Number: 614.1 - 662.5MHz

• Antenna Gain: 0dBi

• Antenna Type: Spring antenna

FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference.

2. This device must accept any interference received, including interference that may cause undesired operation.

Caution:

Any changes or modifications to this device not explicitly approved by the manufacturer could void your authority to operate this equipment.

RF Exposure Information

The device was evaluated to meet general RF exposure requirements. This equipment should be installed and used with a minimum distance of 0mm between the radiator and your body. **Statement for Microphone**The microphone operates in 600MHz guard bands and 600MHz duplex gap. Users should register with and check a white-space database to determine available channels prior to operation at a given location.


Product Usage Instructions

- 1. Ensure that the device is within the specified frequency range of 614.1 662.5MHz.
- 2. Attach the spring antenna securely to the device.
- 3. Make sure that the device is compliant with the FCC Rules and does not cause harmful interference.
- 4. Do not make any changes or modifications to the device without explicit approval from the manufacturer.
- 5. Maintain a minimum distance of 0mm between the device's radiator and your body to meet RF exposure requirements.
- 6. If using the microphone, register with and check a white-space database to determine available channels before operating it at a specific location.

Thank you very much for your purchase of the digital products of the company. In order to make you give full play to the machine to provide all of the features, please read the instructions carefully and complete set right. Please keep this manual for future reference when necessary.


PARTS NAME

HANDHELD MICROPHONE



- 1. MIC set: singing to a here, speech.
- 2. State display: display the current working condition and frequency.
- 3. Power switch: knob down to open and off.
- 4. **Battery cover:** open the bottom cover, and put in AA batteries (18650 batteries).
- 5. **Set frequency points:** Press this button to set the frequency.
- 6. Function keys: Adjust the frequency, Tune the sound, and Lock the ID code.

RECEIVER



- 1. Audio signal output: inserted the amplifier or effector of the 6.35mm microphone input when use.
- 2. Power switch: pull up to open, pull down to off.
- 3. Charging indicator: charging shows red, full of blue.
- 4. Charge port: use 5V mike USB cable to charge
- 5. Receive antenna: Receive the transmitted signal.

Documents / Resources



<u>Shenzhen Xinglin Technology U-A10 Universal Wireless Microphone</u> [pdf] Instruction Manual

2BBWB-U-A10, 2BBWBUA10, U-A10, U-A10 Universal Wireless Microphone, Universal Wireless Microphone, Wireless Microphone

Manuals+,