



Shenzhen Xiyu Technology T2 Remote Control Instruction Manual

[Home](#) » [Shenzhen Xiyu Technology](#) » Shenzhen Xiyu Technology T2 Remote Control Instruction Manual 


Shenzhen Xiyu Technology T2 Remote Control



Contents

- [1 Product Diagram](#)
- [2 Download and install APP](#)
- [3 Turn on](#)
- [4 Power off](#)
- [5 Answer or hung up](#)
- [6 Bluetooth connection between translator and mobile phone](#)
- [7 Translation language setting](#)
- [8 Explanation of indicator lamp for translator](#)
- [9 Warranty description](#)
- [10 Precautions](#)
- [11 Product Parameter](#)
- [12 Download and Install Interface](#)
- [13 FCC Statement](#)
- [14 Documents / Resources](#)
- [15 Related Posts](#)

Product Diagram



Download and install APP

- (1) iPhone: search for "ifanin" in APP Store or scan the QR code.
- (2) Android: search for "ifanin" in Google play or scan the QR code .

Turn on

Press the key of ON/OFF on the power for 5 seconds until the blue light or the indicator flashes and you hear the sound or 'toot'.

Power off

In the hoot state press the key oi ON/OFF on the power for 5 seconds you will hear the 'toot' sound and then see the indicator goes out:

Answer or hung up

When a phone calls in or dials, hold down the up and down buttons or volume adjustment simultaneously to answer or hang up the phone.

Bluetooth connection between translator and mobile phone

- (1) When the translator is turned on press the up and down buttons of the volume adjustment simultaneously until the blue light or the indicator flashes quickly (flickering 3 times per second is a fast flicker state).
- (2) Open the phone's Bluetooth interface (For Android phones, click search or refresh, and for iPhone just turn on the Bluetooth switch).
- (3) When a new device "TIP" appears. click "TIP" to pair up the connection, and the bottom of "TIP" is shown to be connected after the connection is successful.
- (4) If "TIP" is not searched. repeat the process, or restart the phone.

Translation language setting

- (1) When you enter APP you need to wait for the top of the interface to turn green (iPhone is automatic connection. Android phones need to click "connect equipment" button search and click to connect).
- (2) Enter "face to face translation" and choose the language in which you speak to each other. On the left is the language of your own speech, and on the right is the language of the other person. Then go to the setting interface to select the Speaking mode.

A. Stand-alone mode:

Your side speak: Press the down button of the voice input key on the translator. and start talking When you hear a "beep". At the end of the speech. release the button, the translator will automatically play the translated voice after two times of the "beep". The other side speaks: Press the up button of the voice input key on the translator. and you can start talking when you hear a "beep" prompt.

B. Duplex mode (manual)

Your side speak: Press the talk button in the APP interface to start talking and release the button after the end of the speech. The translator automatically plays the translated voice. The other side speaks: Press the translator's voice input key (both up and down key can work), and start talking when you hear the "beep" of a prompt. At the end of the speech. release the button and the translator prompts "beep" twice. The mobile phone automatically plays the translated voice.

- (3) Enter "Picture translation" and choose the language, On the left is the language which you want to translate, On the right is the language which you want to translate to. Then click the "MIC" button and follow the tips to take the picture.
- (4) Enter "Recording translation" and choose the language, On the left is the language which you want to translate, On the right is the language which you want to translate to. Then click the "Start" button. This function can record 5 minutes, then it will log out you need reenter.

Explanation of indicator lamp for translator

- (1) Blue lights flicker quickly: The translator went into pairing mode and flashed three times at 1 second.
- (2) Blue light flickering slowly: The translator goes into normal working condition and flashes once at 3 seconds (device already paired with mobile phone Bluetooth).
- (3) The green light is always on: the translator enters the speech state.

Warranty description

Ifanin translator strictly implement the national "new three guarantees" regulations.

Precautions

- (1) Do not disassemble. repair or refit yourself;
- (2) Do not make the machine wet or inlet water, if the translator inlet water please shut down as soon as possible and contact the dealer
- (3) This machine uses polymer battery, do not burn on fire:
- (4) Do not charge for long periods or time.


Product Parameter

Packing size:	1200mm*30mm*10mm
Battery:	810A
Working time:	24 hours
Standby lime:	7 days
Charging time:	30 minutes
App support system:	Apple iOS 8.0, Android 4.3

APP QR Code





Download and Install Interface




Press the key of ON/OFF on the power for 5 seconds until the blue light of the indicator flashes and you hear the sound of "toot".




Press the up and down buttons of the volume adjustment simultaneously until the blue light of the indicator flashes quickly(flickering 3 times per second is a fast flicker state)






12




13



14




15



16




17



18



19



Translation →

Translation


Picture translation:
when choosed the language
click the button below to
take the picture as the
next picture show.



20




21



Translation →

普通积分



Translation →

Translation

Ordinary points



22



23

Recording translation:
When you attend a meeting
or a conversation, you can
use this.
Upside is the language which
you want to translate.
Below is the lanuage you
translate to.

Start



24

FCC Statement

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

About us

Post code: 518000

Service email: service@ifanin.com

Official website: www.ifanin.com

Documents / Resources



[Shenzhen Xiyu Technology T2 Remote Control](#) [pdf] Instruction Manual
T2, 2A5NQ-T2, 2A5NQT2, T2 Remote Control, Remote Control

[Manuals+](#).