



SHIYUAN AD-01 Portable Wireless Speaker User Manual

[Home](#) » [SHIYUAN](#) » SHIYUAN AD-01 Portable Wireless Speaker User Manual 

Contents

1 SHIYUAN AD-01 Portable Wireless Speaker

2 Product Information

3 Product Usage Instructions

4 Technical specifications

5 Troubleshooting

6 Precautions

7 FCC Caution

8 Documents / Resources

8.1 References

9 Related Posts

SHIYUAN

SHIYUAN AD-01 Portable Wireless Speaker



Specifications

- Model: XYZ-1000
- Power: 120V, 60Hz
- Dimensions: 10 x 8 x 12 inches
- Weight: 5 lbs
- Material: Stainless Steel

Product Information

The XYZ-1000 is a versatile kitchen appliance designed to simplify food preparation tasks. With its durable stainless steel construction and compact design, it is suitable for both home and professional use. The appliance operates on a standard power supply of 120V, 60Hz, making it convenient for most households.

Product Usage Instructions

Assembly

Before using the XYZ-1000 for the first time, ensure all components are properly assembled according to the user manual. Make sure the appliance is placed on a stable surface to prevent accidents.

Power On

Plug the appliance into a power outlet with the provided power cord. Turn on the device using the power switch located on the control panel.

Operation

Follow the specific instructions for the task you wish to perform. Whether it's chopping, blending, or grinding, refer to the user manual for guidance on the appropriate settings and techniques.

Cleaning and Maintenance

After each use, make sure to unplug the appliance and clean it thoroughly according to the manufacturer's instructions. Regular maintenance will prolong the life of your XYZ-1000.

Frequently Asked Questions (FAQ)

• Q: Can I use the XYZ-1000 to crush ice?

A: Yes, the XYZ-1000 is equipped to crush ice. Ensure you follow the recommended guidelines in the user manual for optimal results.

• Q: Is the XYZ-1000 dishwasher safe?

A: Certain parts of the XYZ-1000 are dishwasher safe. Refer to the user manual to identify which components can be safely cleaned in a dishwasher.

Thank you for purchasing our company's wireless speaker. Please read this guide carefully to ensure safety and if you are satisfied with the operation, please keep this guide in a safe place for future reference.


Technical specifications

PORTAABLE WIRELESS SPEAKER	
Product Model:	AD-01
Bt Version:	V5.0
Working Distance:	Up to 10M
Voltage:	DC 5V
Loudspeaker:	4 Ω 5W
S/n Ratio	≥95db
Frequency Response:	120HZ-16KHZ
Charging Time:	1-2h
Playtime:	3-6h

Operation Guide

1. “-”, Press and hold to decrease the volume of the previous song.
2. “o”, Long press to turn on and off, press once to pause playback.
3. “+”, Press once to move on to the next track, long press to increase the volume. Pressing twice is the pairing function.
4. Quickly double-click the “O” button to switch between Bluetooth mode/TF card mode;
5. Without inserting a TF card: default Bluetooth mode;
6. When a TF card has been inserted: Double click the “O” key quickly to switch to the TF card playback mode; If you need Bluetooth playback, double-click the “O” button again to switch.

Sketch map of product




Connection method



1. Open the speaker first
2. Turn on the Bluetooth function of your phone and search for the speaker device model AD-01, click to connect.

Charging method



Supports Type-C interface for charging. When charging, the charging indicator light remains constant On, the indicator light turns off when fully charged.

Troubleshooting

If the following “actions” do not solve your problem, please stop using this product and contact the dealer who purchased the product.

1. The audio system cannot be tuned on?

Please check if there is power to the audio system. If there is no power, please charge it promptly before turning it on;

2. Unable to connect?

Check if the audio system is in the power on state or restart it. Open the Bluetooth device again and search for the audio model AD-01. Click on Connect to connect. If there are too many Bluetooth devices nearby, causing search difficulties, other Bluetooth devices can be turned off first.

3. Is the sound intermittent?

Check if the sound system and Bluetooth device exceed the effective distance, or if there are any obstacles that block the signal between them.

4. Is the sound too low?

Check the volume setting of the Bluetooth device and adjust its volume to the appropriate size.

Precautions

1. Do not bump, squeeze, puncture or disassemble this product on your own.
2. Internally containing batteries, please do not use this product in extreme environments such as high temperature, cold, steam, corrosion, etc.
3. Do not use high voltage and current devices to charge this product to avoid danger.

The pictures in the manual are for reference only. The actual product (including color, size, etc.) is subject to the actual product

FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

1. This device may not cause harmful interference, and
2. This device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.


NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant

to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Documents / Resources

	<p>SHIYUAN AD-01 Portable Wireless Speaker [pdf] User Manual AD-01, AD-01 Portable Wireless Speaker, Portable Wireless Speaker, Wireless Speaker, Speaker</p>
---	---

References

- [User Manual](#)

[Manuals+](#), [Privacy Policy](#)

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.