



shopify 12-Digit Multifunction Pointer Watch User Manual

[Home](#) » [shopify](#) » shopify 12-Digit Multifunction Pointer Watch User Manual 




Operating Manual of 12- Digit
Multifunctional Pointer Watch

Contents

- 1 Buttons and full display:
- 2 Function description:
- 3 Comparison table of English abbreviations in watch:
- 4 Product function modes:
- 5 Stopwatch function:
- 6 Alarm Set:
- 7 Time Set:
- 8 Documents / Resources
- 9 Related Posts

Buttons and full display:




Function description:

- Normally display the hour, minute, second, date, month, weekday
- 12/24-hour option
- El backlight
- Hourly chime and Daily alarm
- Chronographic

Comparison table of English abbreviations in watch:

SU-Sunday, MO-Monday, TU-Tuesday, WE-Wednesday, TH-Thursday, FR-Friday, SA-Saturday, SPL-split time, ALM-alarm, Sig Chime hourly chime, A(am)-morning, P (pm)-afternoon (for 12-hour system), H-24-hour system

Product function modes:



- In the Normal time mode, press the button C to shift with Frequencies as above;
- The EL backlight will be lightened for 3 seconds if button A pressed in any made.

Stopwatch function:

- In the Normal time mode, Press button C into stopwatch made;
- In the stopwatch mode, firstly press the button B to activate the stopwatch, and secondly press the button B to stop it; when the stopwatch stops, press the button D to make the stopwatch return to zero,
- In the stopwatch mode, press the button B to start timing and press D to enter the state of split timing,

secondly, press the button B to quit the split timing and enter the state of ending stopwatch; if quitted from the split timing, press the button D to display the time of stopwatch, and secondly press the button D to make the stopwatch return te zero; in operating, press the button C to return to the time display mode and stopwatch is working in the background;

- The display scope of stopwatch is 23 hours, 59 minutes, and 59.99 seconds;
- The stopwatch is accurate to 1/100 second.

Alarm Set:


- In the Norma! time mode, Press button C twice into Alarm set mode;
- press the button D to shift "minute" and "hour", press the button 6 to adjust the value;

- In the alarm mode, press the button B to open and close – the signal of alarm “ALM”, the signal “of Hourly chime © “SIG”; if the signal appears, it is started and if it disappears, it is closed; the signal of “ALM” and *S1G” will appear in the circle;
- Jn case the alarm is activated, the alarm will ring for 20 seconds and then stop when it comes to the set time;
- incase the hourly chime is activated, the alarm will ring once when It comes to the hourly o'clock.

Time Set:

- In the Normal time mode, Press button C 3 times into Time set mode, the “second” is flashing, press the button 8 to make the “second” return to zero; press the button D to select “minute” “hour”, “date”, “month”, and “weekday”, press B to adjust the chosen value, after set, press C to confirm, and return Normal time mode.

Documents / Resources

	<p>shopify 12-Digit Multifunction Pointer Watch [pdf] User Manual 12-Digit Multifunction Pointer Watch, Multifunction Pointer Watch, CAC-126, ES5473</p>
---	--