


# Shopify Material Testing Software User Guide

[Home](#) » [shopify](#) » Shopify Material Testing Software User Guide 

## Shopify Material Testing Software



## Contents

- 1 Material testing
- 2 Documents / Resources
  - 2.1 References
- 3 Related Posts

## Material testing


1. If you need to test the engraving result of the material, you can quickly test the material through the material test function.

**Step 1:** Click “Test” button on the menu on the right side of workspace.

**Step 2:** Set the required test parameters in the list.

**Step 3:** Set the title text engraving parameters in the material testing matrix.


**Step 4:** Frame to check whether the engraving area is proper, and click “Start” button to start engraving.



1. **Parameter.** Set the engraving parameters that need to be tested.
2. **Rows:** Set the number of “rows” in the test array.
3. **Columns:** Set the number of “columns” in the test array.
4. **Min:** test the minimum value of engraving parameters.
5. **Max:** Test the maximum value of the engraving parameters.

- 6. **Height:** Set the height of each engraved rectangular object in the test array.
- 7. **Width:** Set the width of each engraved rectangular object in the test array.

Documents / Resources

	<p><a href="#">Shopify Material Testing Software</a> [pdf] User Guide</p> <p>Material Testing Software, Material Testing Software, Testing Software, Software</p>
---	---

References

- [User Manual](#)

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.