

SHOWVEN SPARKULAR Portable Pack User Manual

Home » Showven » SHOWVEN SPARKULAR Portable Pack User Manual

Contents

- 1 SHOWVEN SPARKULAR Portable
- **Pack**
- 2 Interface
 - 2.1 Charging
 - 2.2 Maintenance
 - 2.3 FAQs
- 3 Documents / Resources
 - 3.1 References
- **4 Related Posts**

SHOWVEN

SHOWVEN SPARKULAR Portable Pack



Product Information

Technical Specifications

Version: V2.0

• Date: 2022/03/22

• Manufacturer: Showven Technologies Co., Ltd.

Description

This product is a portable device that requires regular charging to maintain functionality. It offers a low-power mode for extended use.

Interface

The product features a UPS ON-OFF switch that should be in the OFF position during charging.

Charging

It is important to maintain a certain amount of electricity in the device and remember to charge it timely after use. Remember to recharge it every month regardless of usage.

Product Usage Instructions

Low Power Mode

- 1. Ensure the device is turned ON.
- 2. Select the low-power mode option for extended usage.

Maintenance

Remember to recharge the device every month, whether in use or not, to ensure optimal performance and battery life.

Warranty Instructions

Sincere thanks for choosing our product. The warranty period is one year, with the battery inside covered for 6 months. Free maintenance services are provided for hardware malfunctions within the warranty period. Do not attempt to repair the machine without factory permission.

Contact Information

Showven Technologies Co., Ltd.

Tel: +86-731-83833068
Web: www.showven.cn
E-mail: info@showven.cn

Address: No.1 Tengda Road, Liuyang Economic & Technical Development Zone, Changsha, Hunan, 410300,

P.R.China

Thanks for choosing SPARKULAR® PORTABLE PACK, we hope it will spark up your show. Please read the following manual carefully before operating this product.

Safety Instructions

- Unauthorized repairs are prohibited, as they may cause serious incidents.
- · Keep SPARKULAR® Portable Pack dry and do NOT use in rain or snow
- Please remember to recharge it every month, no matter use it or not
- Always fully charge the SPARKULAR® PORTABLE PACK after each show
- Frequent over-discharge can cause the battery to fail. To prevent battery discharge
- please maintain a certain amount of electricity and remember to charge it timely after use

Description

SPARKULAR® PORTABLE PACK is a battery dock specially designed for SPARKULAR® mini and SPARKULAR®. It ensures SPARKULAR® series products get rid of the dependence on the main power supply, and achieve real wireless control. It is an ideal choice for outdoor events, weddings, mobile displays, etc.

Technical Specifications

• MODEL: SP0520 / SP0521

DIMENSION: 266×235×130mm

• WEIGHT: 7.5kg

OUTPUT: 220V(SP0520)/110V(SP0521), 500W \ BATTERY CAPACITY: 24V10AH

• Work Temp.: -10 ~ 50

• Casing Color: Black / White optional

Interface

- POWER IN/OUT: compatible with stage effects plugs, can also realize cascade charge and use with power link cables.
- 110V / 220V AC Output: Power output for SPARKULAR® / SPARKULAR® mini.
- 5V DC Output: Power supply for wireless DMX.
- LCD Screen: shows the voltage of the battery, which indicates the electricity quantity.
- · UPS Switch: charging switch



Charging

- 1. When connected with AC, SPARKULAR® Portable Pack will automatically switch to charging mode, it takes approximately 4h to be fully charged, and when the voltage on the LCD screen reaches 29V, means it is fully charged. Please continue to charge for about 1h when the voltage reaches 29V. When charging is complete, the internal charger will automatically switch to non-charging mode.
- 2. When charging, SPARKULAR® / SPARKULAR® mini can be used normally, it will not consume the power from the battery.
- 3. UPS ON-OFF should switch to OFF status when charging.

Usage

- 1. When using SPARKULAR® / SPARKULAR® mini on it (not connect AC), please turn on the UPS ON-OFF switch.
- 2. In a low battery, the device will alarm, please recharge it.
- 3. SPARKULAR® mini can be used on SPARKULAR® Portable Pack directly.
- 4. Due to the power limitation, for SPARKULAR®, please set it at low power consumption mode, otherwise will cause UPS halted. SPARKULAR® set up as below:
 - Press and hold the "ENTER" key for 3s, enter the SPARKULAR® factory menu, press "MENU" to change the interface find the "Low Power Mode" interface as below, and set it at "ON" status. If can't find the "Low Power Mode" interface (available for software version V2.2 and above), please contact the SHOWVEN service team for a software update.

Low Power Mode ON

Maintenance

- Please fully charge the SPARKULAR® PORTABLE PACK if not used for some time, and turn off the UPS ON-OFF to avoid system drain battery power.
- Remember to recharge it every month matter use it or not.

Warranty Instructions

Sincere thanks for choosing our products, you will receive quality service from us \ The product warranty period is one year (the battery inside is wearing part with a warranty of 6 months). If there are any quality problems within 7 days after shipping out from our factory,

we can exchange a brand new model machine for you \ We will offer free of charge maintenance service for machines with hardware malfunction (except for the instrument damage caused by human factors) in warranty period. Please don't repair the machine without factory permission Below are situations NOT included in warranty service:

Damage caused by improper transportation, usage, management, and maintenance, or damage caused by human factors; Disassemble, modify, or repair products without permission; Damage caused by external reasons (lightning strike, power supply, etc.) Damage caused by improper installation or use; For product damage not included in the warranty range, we can provide paid service. An invoice is necessary when applying for maintenance service from SHOWVEN®.



- Showven Technologies Co., Ltd.
- Tel: +86-731-83833068
- Web: www.showven.cn E-mail: info@showven.cn
- Add: No.1 Tengda Road, Liuyang Economic & Technical Development Zone, Changsha, Hunan, 410300,
 P.R.China

FAQs

What should I do if my device is damaged due to improper use?

Damage caused by improper transportation, usage, management, maintenance, disassembly, modification, or repair without permissiisare not covered under warranty. Please ensure proper installation and use of the product

to avoid damage.

Documents / Resources



<u>SHOWVEN SPARKULAR Portable Pack</u> [pdf] User Manual 20220322, SPARKULAR Portable Pack, SPARKULAR, Portable Pack, Pack

References

- Founder of Sparkular, Sparkular Machine Maker | Showven
- User Manual

Manuals+, Privacy Policy

This website is an independent publication and is neither affiliated with nor endorsed by any of the trademark owners. The "Bluetooth®" word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. The "Wi-Fi®" word mark and logos are registered trademarks owned by the Wi-Fi Alliance. Any use of these marks on this website does not imply any affiliation with or endorsement.